

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [OPPO](#) /
- > [OPPO BDP-83 Blu-ray Disc Player User Manual](#)

OPPO BDP-83

OPPO BDP-83 Blu-ray Disc Player User Manual

Model: BDP-83

PRODUCT OVERVIEW

The OPPO BDP-83 is a versatile Blu-ray Disc Player designed to provide comprehensive media support and high-fidelity audio and video performance. It supports a wide range of disc formats including Blu-ray, SACD, DVD-Audio, DVD, and CD, along with various file formats from USB drives. This player integrates advanced video processing technology from Anchor Bay for exceptional picture quality and supports multiple audio formats for an immersive sound experience.



Figure 1: Front view of the OPPO BDP-83 Blu-ray Disc Player.

This image displays the front panel of the OPPO BDP-83 Blu-ray Disc Player. It features a brushed black aluminum finish with the "OPPO" logo on the left. A power button with an illuminated indicator is located below the logo. The central section includes a digital display showing playback information and controls for disc navigation. On the right, there is an open/close button for the disc tray and a circular navigation pad. Logos for Blu-ray Disc, Super Audio CD, and DVD Video are also visible, indicating the player's broad compatibility.

KEY FEATURES

- **Universal Disc Playback:** Supports Blu-ray Disc (Profile 2.0), DVD, SACD, DVD-Audio, CD, Kodak Picture CD, AVCHD, and MKV.
- **Advanced Video Processing:** Features VRS by Anchor Bay technology for outstanding picture quality, Full HD 1080p output, True 24 Video, and multiple zoom modes.
- **High Fidelity Audio:** Decodes Dolby TrueHD and DTS-HD Master Audio, with 7.1-Channel Analog Output, dedicated stereo output, and digital optical/coaxial outputs.
- **Connectivity:** Equipped with HDMI 1.3, component video, composite video, dual USB ports (front and rear),

Ethernet RJ-45, external IR, and RS232 control.

- **Convenience:** Includes a back-lit remote control, universal power supply, and PAL/NTSC conversion capabilities.

SETUP GUIDE

1. Unpacking and Placement

1. Carefully remove the BDP-83 player and all accessories from the packaging.
2. Place the player on a stable, flat surface with adequate ventilation. Ensure there is sufficient space around the unit for heat dissipation.
3. Avoid placing the player near heat sources or in direct sunlight.

2. Connecting to Your TV/Display

For optimal video quality, use an HDMI cable to connect the BDP-83 to your TV or display.

- Connect one end of an HDMI cable to the HDMI OUT port on the rear of the BDP-83.
- Connect the other end of the HDMI cable to an available HDMI input on your TV or display.
- *Alternative:* For older displays, use component video or composite video connections. Refer to your TV's manual for appropriate input selection.

3. Connecting to Your Audio System

The BDP-83 offers multiple audio output options for connecting to your receiver or amplifier.

- **HDMI Audio:** If your receiver supports HDMI audio, connect the BDP-83's HDMI OUT to your receiver's HDMI IN.
- **7.1-Channel Analog Audio:** For high-fidelity multi-channel audio, connect the 7.1 analog audio outputs on the BDP-83 to the corresponding 7.1 analog inputs on your receiver.
- **Digital Audio:** Use an optical or coaxial digital audio cable to connect the BDP-83 to your receiver's digital audio input for stereo or compressed multi-channel audio.
- **Dedicated Stereo Output:** For two-channel audio, connect the dedicated stereo analog outputs to your stereo amplifier or receiver.

4. Network Connection (Optional)

To access BD-Live features, connect the player to your home network.

- Connect an Ethernet cable from the RJ-45 port on the rear of the BDP-83 to your router or network switch.

5. Power Connection

- Connect the supplied power cord to the AC IN port on the rear of the BDP-83.
- Plug the other end of the power cord into a wall outlet.

OPERATING INSTRUCTIONS

1. Basic Playback

1. Press the **POWER** button on the front panel or remote control to turn on the player.
2. Press the **OPEN/CLOSE** button to open the disc tray.
3. Place a disc (Blu-ray, DVD, CD, SACD, DVD-Audio) gently onto the disc tray with the label side facing up.
4. Press the **OPEN/CLOSE** button again to close the tray. The player will automatically begin loading the disc.

5. Use the remote control's navigation buttons (**PLAY**, **PAUSE**, **STOP**, **FF**, **REW**, **SKIP**) to control playback.

2. USB Media Playback

1. Insert a USB flash drive into either the front or rear USB port of the BDP-83.
2. The player will detect the USB drive and display a menu for media selection (video, music, photos).
3. Navigate through the folders and files using the remote control and press **ENTER** to select and play content.

3. BD-Live Features

If connected to the internet, the BDP-83 supports BD-Live features for compatible Blu-ray discs.

- Ensure the player is connected to your home network via Ethernet.
- Insert a BD-Live enabled Blu-ray disc.
- Follow the on-screen prompts to access online content, such as bonus features, games, or interactive experiences.

4. Remote Control Functions

The included backlit remote control provides full functionality for the BDP-83.

- Familiarize yourself with the button layout. Key buttons include:
 - **Power:** Turns the unit on/off.
 - **Open/Close:** Opens and closes the disc tray.
 - **Navigation Pad:** For menu navigation and selection.
 - **Playback Controls:** Play, Pause, Stop, Fast Forward, Rewind, Skip.
 - **Resolution:** Quickly changes video output resolution.
 - **Audio/Subtitle:** Selects audio tracks and subtitle options.
- The backlight feature can be activated for use in dark environments.

MAINTENANCE

1. Cleaning the Player

- Before cleaning, ensure the player is powered off and unplugged from the wall outlet.
- Use a soft, dry cloth to wipe the exterior of the player. Do not use liquid cleaners, abrasive cloths, or chemical solvents, as these may damage the finish.
- For the disc tray, use a soft, lint-free cloth to gently wipe away any dust. Avoid touching the internal lens.

2. Disc Care

- Always handle discs by their edges to avoid fingerprints and scratches on the playing surface.
- Store discs in their cases when not in use to protect them from dust and damage.
- If a disc is dirty, gently wipe it from the center outwards with a soft, lint-free cloth. Do not use abrasive materials or harsh chemicals.

3. Firmware Updates

OPPO may release firmware updates to improve performance or add new features. Check the official OPPO website periodically for the latest firmware for your BDP-83 model.

- Follow the instructions provided with the firmware update carefully. Incorrect updates can damage the player.

- Typically, updates involve downloading a file to a USB drive and inserting it into the player.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cord not connected; Power outlet not active.	Ensure power cord is securely connected. Try a different power outlet.
No video output	Incorrect input selected on TV; Loose HDMI/video cable; Player output resolution mismatch.	Select the correct input on your TV. Check all video cable connections. Try pressing the "Resolution" button on the remote to cycle through output resolutions.
No audio output	Loose audio cables; Incorrect audio output settings on player/receiver; Muted volume.	Check all audio cable connections. Verify audio settings on the player and your receiver. Ensure volume is not muted.
Disc not playing/loading	Disc is dirty or scratched; Disc format not supported; Disc inserted incorrectly.	Clean the disc. Ensure the disc format is supported by the BDP-83. Insert the disc with the label side facing up.
Remote control not working	Batteries are dead or inserted incorrectly; Obstruction between remote and player.	Replace batteries. Ensure correct polarity. Remove any obstructions and point the remote directly at the player's IR sensor.

SPECIFICATIONS

- **Model:** OPPO BDP-83
- **Supported Disc Formats:** Blu-ray Disc (Profile 2.0), DVD-Video, DVD-Audio, SACD, CD, HDCD, Kodak Picture CD, AVCHD, MKV.
- **Video Output:** HDMI 1.3 (1080p, 1080i, 720p, 480p, 480i), Component Video, Composite Video.
- **Audio Output:** 7.1-Channel Analog Audio, Dedicated Stereo Analog Audio, Digital Optical, Digital Coaxial, HDMI Audio (bitstream and LPCM).
- **Connectivity:** 2 x USB (front and rear), Ethernet (RJ-45), External IR, RS232.
- **Dimensions (W x H x D):** 17.0 x 3.0 x 13.25 inches (432 x 76 x 337 mm).
- **Weight:** Approximately 11.2 pounds (5.1 kg).
- **Power Supply:** Universal AC 100V - 240V, 50/60 Hz.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official OPPO website or contact OPPO customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

- **Online Support:** Visit the OPPO official website for FAQs, firmware downloads, and support resources.
- **Customer Service:** Contact details for phone or email support can be found on the OPPO website.