

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Everstar](#) /

› Everstar Set of 50 Red Mini Christmas Lights - Green Wire Instruction Manual (Model 009312408450)

Everstar 009312408450

Everstar Set of 50 Red Mini Christmas Lights - Green Wire Instruction Manual

Model: 009312408450

1. PRODUCT OVERVIEW

The Everstar Set of 50 Red Mini Christmas Lights (Item #ES66-481, Model 009312408450) is designed to provide festive illumination for both indoor and outdoor environments. This set features 50 incandescent mini-bulbs with a vibrant red color on a green wire. The lights are UL listed, ensuring compliance with safety standards.

- **Bulb Count:** 50 Red Mini-Bulbs
- **Wire Color:** Green
- **Bulb Spacing:** 3.5 inches
- **Lighted Length:** 14.5 feet (4.4 meters)
- **Total String Length:** 17 feet (5.1 meters)
- **Features:** Steady burning or single flashing, Lamp lock and twist-proof bulbs, End-to-end connectors
- **Power:** 120V, 60Hz
- **Usage:** UL listed for Indoor and Outdoor use

2. SAFETY INFORMATION

Please read and follow all safety instructions carefully to prevent fire, electric shock, and personal injury.

- **UL Listed:** This product is UL listed for both indoor and outdoor use.
- **Electrical Safety:** Always plug the lights into a 120V, 60Hz power source. Do not overload circuits.
- **Inspection:** Before each use, inspect the light string for any damage to the insulation, plugs, or bulbs. Do not use if damaged.
- **Placement:** Ensure lights are securely fastened and not placed in areas where they can be stepped on or damaged. Keep away from heat sources.
- **Connecting Multiple Sets:** Use the end-to-end connectors provided. Do not exceed the maximum recommended number of connected sets (refer to product packaging or label for specific limits).
- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

- **Unplug When Not In Use:** Always unplug the light string from the power outlet when leaving the house, when retiring for the night, or if left unattended.

3. PACKAGE CONTENTS

Your Everstar Set of 50 Red Mini Christmas Lights package includes:

- 1 x Everstar Set of 50 Red Mini Christmas Lights with Green Wire

4. SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the light string from its packaging. Untangle the wire gently to avoid damage.
2. **Inspect:** Before plugging in, visually inspect the entire light string for any broken bulbs, frayed wires, or damaged plugs. Do not use if any damage is found.
3. **Placement:**
 - **Indoor Use:** Drape lights on Christmas trees, wreaths, garlands, or other decorative items. Ensure lights are not pinched by doors or windows.
 - **Outdoor Use:** Securely attach lights to structures using appropriate clips or fasteners. Avoid placing lights in standing water or areas prone to heavy moisture accumulation.
4. **Connecting Multiple Sets (Optional):** If connecting multiple sets, use the end-to-end connectors. Insert the male plug of one string into the female receptacle of another. Ensure the total wattage of connected strings does not exceed the maximum allowed (typically indicated on the product label or packaging).
5. **Tree Lighting Recommendation:** For a well-lit Christmas tree, it is generally recommended to use approximately 100 bulbs per foot of tree height. Adjust the number of sets accordingly.



Figure 1: Close-up view of the red mini-bulbs and green wire.




Figure 2: The red mini-lights illuminated.

5. OPERATING INSTRUCTIONS

1. **Power On:** Once the lights are properly placed and inspected, plug the male end of the light string into a standard 120V AC electrical outlet.
2. **Light Modes:** This light set offers two modes:
 - **Steady Burning:** All bulbs remain continuously lit.
 - **Single Flashing:** The lights will flash on and off.

The mode is typically controlled by a flasher bulb or a switch on the string. Refer to the specific packaging for details on how to select the desired mode.

3. **Power Off:** To turn off the lights, simply unplug the string from the electrical outlet.

6. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your Christmas lights.

- **Bulb Replacement:** These lights feature lamp lock and twist-proof bulbs. If a bulb burns out, carefully twist and pull the bulb straight out from its socket. Replace with a new bulb of the same type and voltage. Ensure the replacement bulb is fully seated.
- **Cleaning:** Unplug the lights before cleaning. Gently wipe bulbs and wires with a soft, dry cloth. Do not immerse in water.
- **Storage:** When not in use, unplug the lights and allow them to cool completely. Carefully coil the string to prevent tangling and damage to the wires or bulbs. Store in a cool, dry place, away from direct sunlight and extreme temperatures.

- **Seasonal Inspection:** Before each holiday season, perform a thorough inspection of the entire light string for any signs of wear, damage, or corrosion.

7. TROUBLESHOOTING

If your Everstar Christmas lights are not functioning as expected, refer to the following common issues and solutions:

- **Lights Not Lighting Up:**
 - Ensure the plug is fully inserted into a working electrical outlet.
 - Check the fuse in the plug. If blown, replace with a fuse of the same rating.
 - Inspect all bulbs. A single loose or burnt-out bulb can sometimes cause a section or the entire string to go out. Replace any burnt-out bulbs.
 - If connecting multiple sets, ensure all connections are secure and the total wattage does not exceed the limit.
- **Lights Flickering or Dim:**
 - Check for loose bulbs and ensure they are securely seated in their sockets.
 - Verify the power source is stable and not overloaded.
- **Section of Lights Out:**
 - This often indicates a burnt-out bulb or a loose connection within that specific section. Systematically check each bulb in the affected section.

8. SPECIFICATIONS

Feature	Detail
Brand	Everstar
Model Number	009312408450 (Item #ES66-481)
Bulb Type	Mini-Bulb, Incandescent
Bulb Color	Red
Wire Color	Green
Number of Bulbs	50
Bulb Spacing	3.5 inches
Lighted Length	14.5 feet (4.4 meters)
Total String Length	17 feet (5.1 meters)
Voltage	120V, 60Hz
Indoor/Outdoor Use	UL Listed for Indoor and Outdoor
UPC	009312408450

9. WARRANTY AND SUPPORT

Specific warranty information for Everstar products is typically provided with the product packaging or can be found on the manufacturer's official website. For technical support, replacement parts, or warranty claims, please contact Everstar customer service directly.

Keep your purchase receipt as proof of purchase for any warranty-related inquiries.