

iLive Electronics S809B

iLive Electronics S809B Wireless Outdoor Speaker Instruction Manual

Model: S809B

1. INTRODUCTION

Thank you for purchasing the iLive Electronics S809B Wireless Outdoor Speaker. This manual provides essential information for the proper setup, operation, and maintenance of your speaker. Please read this guide thoroughly before use to ensure optimal performance and longevity of your device. This speaker is designed for outdoor use, offering portable audio with Bluetooth connectivity.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- 2 x iLive S809B Wireless Outdoor Speakers
- Power Adapter (not explicitly listed but implied for battery-powered devices)
- Instruction Manual (this document)

3. PRODUCT OVERVIEW

The iLive S809B is a wireless outdoor speaker designed for robust audio performance in various environments. It features a durable design and Bluetooth connectivity for seamless audio streaming from compatible devices.



Image: Front view of the iLive S809B Wireless Outdoor Speaker, showcasing its black finish and compact design. The iLive logo is visible on the upper front panel, with a small indicator light below it. The speaker features an open design at the bottom for sound projection.

4. SETUP

4.1. Charging the Speaker

1. Connect the power adapter to the speaker's charging port.
2. Plug the power adapter into a standard electrical outlet.
3. Allow the speaker to charge fully before initial use. The indicator light will change to indicate a full charge.

4.2. Powering On/Off

- To power on, press and hold the Power button until the indicator light illuminates.
- To power off, press and hold the Power button until the indicator light turns off.

4.3. Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode (the indicator light may flash).
2. On your Bluetooth-enabled device (e.g., smartphone), navigate to the Bluetooth settings.
3. Search for available devices and select "S809B" from the list.
4. Once paired, the speaker will emit a confirmation tone, and the indicator light will become solid.

4.4. Speaker Placement

For optimal sound quality, place the speaker on a stable, flat surface. For outdoor use, consider placing it in a location where sound can disperse effectively without obstruction.

5. OPERATION

5.1. Audio Playback

- After successful Bluetooth pairing, begin playing audio from your connected device.

- The audio will stream wirelessly to the S809B speaker.

5.2. Volume Control

- Adjust the volume directly from your connected Bluetooth device.
- The speaker may also have integrated volume controls (refer to specific button layout on the device).

5.3. Smartphone Charging Feature

The S809B speaker includes a smartphone-charging feature. Connect your smartphone to the designated USB output port on the speaker using a compatible USB cable (not included) to charge your device.

6. MAINTENANCE

6.1. Cleaning

- Wipe the speaker's exterior with a soft, dry cloth.
- Do not use abrasive cleaners, waxes, or solvents.
- Avoid exposing the speaker to excessive moisture.

6.2. Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery drained; Power adapter not connected	Charge the speaker; Ensure power adapter is securely connected to speaker and outlet
No sound	Volume too low; Speaker not paired; Device not playing audio	Increase volume on speaker and device; Re-pair Bluetooth; Start audio playback on device
Bluetooth pairing fails	Speaker not in pairing mode; Device too far; Interference	Ensure speaker is in pairing mode; Move device closer to speaker; Turn off other Bluetooth devices
Poor sound quality	Weak Bluetooth signal; Obstructions; Low battery	Move device closer; Remove obstructions; Charge speaker

8. SPECIFICATIONS

- **Model:** S809B
- **Brand:** iLive Electronics
- **Connectivity Technology:** Bluetooth
- **Power Source:** Battery Powered
- **Speaker Type:** Outdoor
- **Special Feature:** Portable, Smartphone-charging
- **Recommended Uses:** Outdoor
- **Included Components:** 2 ILIVE S809B wireless outdoor speakers
- **Item Weight:** 4.75 pounds

- **Product Dimensions:** 7.87 x 10.86 x 8.81 inches
- **Surround Sound Channel Configuration:** 2.0
- **Control Method:** Touch
- **Audio Driver Type:** Dynamic Driver
- **UPC:** 047323121609

9. WARRANTY AND SUPPORT

This product comes with a Standard Warranty. For detailed warranty information, please refer to the warranty card included with your purchase or visit the official iLive Electronics website. For technical support or customer service inquiries, please contact iLive Electronics directly through their official support channels.

Please retain this manual for future reference.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question