

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Wahl](#) /

> [Wahl Men's Nose Hair Trimmer, for Eyebrows, Neckline, Nose & Ear Hair, Precision Detail Trimming with Interchangeable Heads, Battery Included - Model 5545-400](#)

Wahl 5545-400

Wahl Men's Nose Hair Trimmer Instruction Manual

Model: 5545-400

PRODUCT OVERVIEW

The Wahl 3-in-1 Battery Ear, Nose, & Brow Trimmer is designed for precise personal grooming. It features three interchangeable heads: a reciprocating head, a detail trimming head, and a rotary head, allowing for versatile use on necklines, sideburns, eyebrows, nose, and ear hair. The long-lasting steel blades are easy to maintain, and the trimmer is battery-operated for cordless convenience.



Image: The Wahl 3-in-1 Trimmer showing the main unit and its three interchangeable heads (detail, reciprocating, rotary) along with the eyebrow guide.

SETUP

Battery Installation

1. Locate the battery compartment on the trimmer handle.
2. Gently slide open the battery cover.
3. Insert one AA alkaline battery, ensuring the positive (+) and negative (-) ends are aligned correctly as indicated inside the compartment.
4. Close the battery cover securely.

BATTERY OPERATED

FOR CORDLESS TRIMMING



**1 AA BATTERY
INCLUDED**

**The Brand Used
By Professionals®**

Image: The trimmer next to an AA battery, illustrating its battery-operated nature.

Attaching Trimmer Heads

The trimmer comes with three interchangeable heads: Detail, Reciprocating, and Rotary. To attach a head, align the head with the trimmer body and twist until it locks securely into place. To remove, twist in the opposite direction and pull off.

OPERATING INSTRUCTIONS

General Operation

- Ensure a fresh AA battery is installed.
- Select and attach the desired trimmer head.
- Slide the power switch to the "ON" position to activate the trimmer.
- After use, slide the power switch to the "OFF" position.

Using the Detail Trimming Head

The detail head is ideal for precise trimming of necklines, sideburns, and eyebrows. For eyebrow trimming, attach the 2-position eyebrow guide to the detail head. This guide helps achieve short to medium precision trimming and prevents over-trimming.

DETAIL TRIMMER

FOR TRIMMING NECKLINES,
SIDEBURNS, AND EYEBROWS

**PRECISION
BLADES FOR
BETTER RESULTS**

**2 POSITION
GUIDE COMB**

**WAHL®
WET / DRY**

**The Brand Used
By Professionals**

Image: A man using the detail trimmer head to trim his neckline, highlighting its precision for fine areas. The 2-position eyebrow guide comb is also shown.

Using the Reciprocating Head

The reciprocating head is excellent for detailing, edging, and trimming hair around the ears and eyebrows. Use gentle, controlled movements for best results.

RECIPROCATING HEAD

FOR DETAILING AROUND
EARS AND EYEBROWS



Image: A man using the reciprocating head to trim hair around his ear, demonstrating its use for detailing.

Using the Rotary Head

The rotary head is specifically designed for hygienic nose and ear hair trimming. Carefully insert the tip into the nostril or ear canal and gently move it to trim unwanted hair without nicking or pulling.

EAR/NOSE TRIMMER

FOR EAR & NOSE TRIMMING



Image: A man using the rotary head to trim nose hair, illustrating its primary function.

Wet/Dry Use

This trimmer is designed for both wet and dry use. Its rinseable stainless steel blades allow for convenient use in the shower or for quick dry trims.

WET/DRY TRIMMER

RINSEABLE STAINLESS STEEL
BLADES FOR EASY CLEANING

The Brand Used
By Professionals®

Image: The trimmer's head being rinsed under running water, demonstrating its wet/dry capability and ease of cleaning.

MAINTENANCE

Cleaning the Trimmer Heads

For optimal hygiene and performance, clean the trimmer heads after each use. Simply remove the trimmer head from the main unit and rinse it thoroughly under running water. Allow the head to air dry completely before reattaching or storing.

General Care

- Do not submerge the entire trimmer unit in water. Only the removable heads are rinseable.
- Store the trimmer in a cool, dry place when not in use.
- Keep out of reach of children.

TROUBLESHOOTING

Common Issues

- **Trimmer not turning on:** Ensure the AA battery is correctly installed and has sufficient charge. Replace the battery if necessary.
- **Loud audible hum during operation:** The Wahl Trimmer uses a powerful motor that delivers nearly 10,000 cycles per minute to the cutter head. A strong audible hum is completely normal to its operation and does not indicate a defect.
- **Reduced cutting performance:** Clean the trimmer head thoroughly. If performance does not improve, the blades may be dull and require replacement.

SPECIFICATIONS

Feature	Detail
Model Number	5545-400
Brand	Wahl
Power Source	1 AA Battery (included)
Product Dimensions	1.5 x 4.65 x 8.89 inches
Item Weight	4 Ounces
Blade Material	Stainless Steel
Usage	Wet/Dry
UPC	043917554549

WARRANTY AND SUPPORT

Warranty Information

The Wahl 3-in-1 Trimmer comes with a **3-year limited warranty**. This warranty is valid in the U.S.A. only and is not intended for professional use; warranty is void if used commercially. If your trimmer blades ever pull or snag hair within the first year, return it for a replacement at no cost to you.



3 YEAR

LIMITED WARRANTY

Valid in U.S.A. only.
This product is not intended for professional use;
warranty void if used commercially.



NO PULL, NO PAIN

GUARANTEED

If your trimmer blades ever pull or snag
your hair within the first year, return it for
a replacement at no cost to you.

The Brand Used By Professionals® Since 1919

Image: Details of the 3-year limited warranty and the "No Pull, No Pain" guarantee.

Customer Support

For any issues with your product or for further assistance, please reach out to Wahl directly. Contact information can be found on the product packaging and in the included instruction book. You can also visit the official Wahl website for product tutorials and support: wahlusa.com.

SAFETY INFORMATION

For external use only. Always ensure the trimmer is off before changing heads or cleaning. Do not attempt to repair the unit yourself; refer to qualified service personnel.



