

Panasonic RP-HS46E-K

Panasonic RP-HS46E-K Slim Clip-On Earphones User Manual

Model: RP-HS46E-K

INTRODUCTION

Thank you for purchasing the Panasonic RP-HS46E-K Slim Clip-On Earphones. These earphones are designed to provide clear audio with a secure and comfortable fit, ideal for various activities. This manual provides essential information for the proper setup, operation, and maintenance of your earphones.

PRODUCT OVERVIEW

The Panasonic RP-HS46E-K earphones feature an ultra-slim housing and a 30mm driver unit for powerful sound. The ergonomic ear hook design ensures a secure and comfortable fit.

Included Components:

- **Clip-On Earphones:** The main unit comprising earbuds and ear clips.
- **Earbuds:** The sound-delivering earpieces.
- **Clip:** Designed for secure and stable attachment to your ears.
- **Cord:** The connecting cable between the earbuds.



Image: Panasonic RP-HS46E-K Slim Clip-On Earphones. This image displays the black earphones with their distinctive clip-on design, highlighting the slim profile and the ear hook mechanism for secure wear.

SETUP

1. **Identify Left and Right:** Each earphone is marked with 'L' for left and 'R' for right. Ensure correct placement for optimal sound.
2. **Position the Ear Clip:** Gently place the earphone over your ear, guiding the ear clip around the back of your earlobe. The clip should rest comfortably and securely.
3. **Insert Earbud:** Carefully insert the earbud into your ear canal. Adjust the position until it feels snug and comfortable, and the sound is clear.
4. **Connect to Audio Device:** Plug the 3.5mm audio jack into the headphone port of your audio device (e.g., smartphone, tablet, MP3 player).

Ensure the connection is firm to prevent audio interruptions.

OPERATING INSTRUCTIONS

These earphones are designed for simple plug-and-play operation with any device featuring a standard 3.5mm audio jack.

1. **Volume Control:** Adjust the volume directly on your connected audio device. These earphones do not feature inline volume controls.
2. **Audio Playback:** Start or stop audio playback using the controls on your audio device.
3. **Secure Fit:** For active use, ensure the ear clips are securely positioned to prevent the earphones from dislodging.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the earphones and cord with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Water Resistance:** These earphones are water resistant, meaning they can withstand light splashes or sweat. They are not designed for submersion in water. Avoid exposing them to heavy rain or direct water streams.
- **Storage:** When not in use, store the earphones in a clean, dry place, away from extreme temperatures and direct sunlight. Avoid tangling the cord.
- **Cable Care:** Do not pull on the cable to disconnect the earphones from your device. Always grasp the plug firmly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound or low volume	Audio jack not fully inserted.	Ensure the 3.5mm jack is fully inserted into the audio device.
	Volume on device is too low or muted.	Increase the volume on your audio device and check if it's muted.
	Earphones are damaged.	Test with another audio device. If still no sound, the earphones may be damaged.
Sound distortion	Volume on device is too high.	Lower the volume on your audio device.
	Poor connection.	Ensure the audio jack is clean and fully inserted.
Earphones fall off easily	Improper fit.	Adjust the ear clips and earbuds for a more secure and comfortable fit around your ears.

SPECIFICATIONS

Model Name	RP-HS46E-K
Connectivity Technology	Wired
Headphones Jack	3.5 mm Jack
Driver Unit Size	30 mm
Frequency Response	20 Hz - 20 kHz
Sensitivity	108 dB
Impedance	20 Ohms
Water Resistance Level	Water Resistant
Item Weight	16 Grams (0.564 ounces)

Color	Black
Material	Plastic
Product Dimensions	6.7 x 3.86 x 0.59 inches

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or visit the official Panasonic website. Keep your proof of purchase for warranty claims.

Panasonic Official Website: www.panasonic.com

SAFETY INFORMATION

- **Hearing Protection:** Avoid listening at high volume levels for extended periods to prevent hearing damage.
- **Environmental Awareness:** Do not use earphones in situations where inability to hear ambient sounds could be dangerous, such as while driving, cycling, or walking in traffic.
- **Choking Hazard:** Keep earphones and their components out of reach of small children and pets.
- **Proper Disposal:** Dispose of this product according to local regulations. Do not dispose of with household waste.