

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [STANLEY FATMAX](#) /

› [STANLEY FATMAX 1-95-152 Aluminium Torch User Manual](#)

STANLEY FATMAX 1-95-152

STANLEY FATMAX 1-95-152 Aluminium Torch User Manual

Model: 1-95-152

INTRODUCTION

This manual provides essential instructions for the safe and effective use, setup, and maintenance of your STANLEY FATMAX 1-95-152 Aluminium Torch. Please read this manual thoroughly before operating the device and retain it for future reference.

SAFETY INFORMATION

- Do not look directly into the LED light.
- Keep out of reach of children.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the torch will not be used for an extended period.
- Dispose of batteries according to local regulations.
- Do not attempt to disassemble or modify the torch.

PACKAGE CONTENTS

- STANLEY FATMAX Aluminium Torch
- Requires 3 x AAA Alkaline Batteries (not included)

SETUP

Battery Installation

1. Unscrew the tail cap of the torch by turning it counter-clockwise.
2. Insert three (3) AAA alkaline batteries into the battery holder, ensuring correct polarity (+/-).
3. Place the battery holder with the installed batteries into the torch body.
4. Screw the tail cap back on clockwise until securely tightened.



Image 1: Stanley Fatmax 3AAA Aluminium Torch. The tail cap, where batteries are inserted, is visible on the right.

OPERATING INSTRUCTIONS

Turning On/Off

Press the button located on the tail cap to turn the torch on. Press the button again to turn the torch off.

Adjusting the Beam

The head of the torch can be rotated to adjust the focus of the light beam. Rotate the head clockwise or counter-clockwise to achieve a wider floodlight or a more focused spotlight.



Image 2: The Stanley Fatmax torch, showing its robust aluminum body and textured grip for secure handling during operation.

MAINTENANCE

Cleaning

Wipe the torch body with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure the lens is clean for optimal light output.

Battery Replacement

When the light output diminishes, replace the AAA batteries following the installation steps in the "Setup" section. Always replace all three batteries at the same time with new, fresh alkaline batteries.

Storage

Store the torch in a cool, dry place. If storing for an extended period, remove the batteries to prevent leakage and potential damage to the torch.

TROUBLESHOOTING

- **Torch does not turn on:**

- Check if batteries are inserted correctly with proper polarity.
- Ensure batteries are fresh and not depleted.
- Verify the tail cap is securely tightened.

- **Light is dim or flickers:**

- Replace batteries with new ones.
- Clean battery contacts and terminals.
- Ensure the lens is clean.

- **Beam adjustment is stiff:**

- Gently clean any debris from the head mechanism.
- Avoid forcing the adjustment.

SPECIFICATIONS

Feature	Detail
Model Number	1-95-152
Material	Aluminum
Power Source	Battery Powered
Battery Type	3 x AAA Alkaline (not included)
Voltage	4.5 Volts
Bulb Type	LED
Brightness	120 Lumens
Product Dimensions	12 x 4 x 22 cm (approximate)
Item Weight	140 g
Special Features	Durable, Textured handle, Shatter resistant lens

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official STANLEY FATMAX website or contact their customer service department. Keep your purchase receipt as proof of purchase.