JOOLA 11200

JOOLA Inside 15mm MDF Indoor Table Tennis Table - Model 11200 Instruction Manual

Your guide to assembly, operation, and maintenance.

Introduction

Thank you for choosing the JOOLA Inside 15mm MDF Indoor Table Tennis Table, Model 11200. This table is designed for recreational and competitive play in indoor environments. It features a 15mm MDF playing surface, a sturdy frame, and a quick-clamp net system. This manual provides essential information for the safe and efficient use of your table.

The JOOLA Inside 15 table is engineered for quick setup, with approximately 95% of the assembly completed at the factory, allowing you to begin playing in about 10 minutes. Its design includes separable halves for compact storage and adjustable leg levelers for a balanced playing surface.



Image: The JOOLA Inside 15mm MDF Indoor Table Tennis Table in playing position, featuring its blue playing surface and black frame.

Safety Instructions

- Always ensure the table is placed on a flat, stable surface to prevent tipping.
- Keep children and pets away from the table during assembly and when moving it.
- Engage all locking mechanisms on the wheels when the table is in playing or storage position to ensure stability.
- Do not climb on or sit on the table.
- Exercise caution when folding or unfolding the table halves to avoid pinching fingers or hands.
- Regularly inspect all bolts and fasteners to ensure they are tight.

Package Contents

Please verify that all components are present before beginning assembly:

- JOOLA Inside 15mm Table Tennis Table (two halves)
- Easy Net and Post Set (quick-clamp style)
- Necessary Nuts, Bolts, and Bolt Plate (pre-installed or minimal attachment required)

Setup and Assembly

The JOOLA Inside 15mm table is designed for quick and easy setup. Most of the table comes pre-assembled, requiring only about 10 minutes to prepare for play.

1. **Unpack the Table:** Carefully remove all packaging materials. Place the two table halves on a flat, clear surface.
2. **Unfold Table Halves:** Gently unfold each table half from its compact storage position. Ensure the legs are fully extended and locked into place.
3. **Position Table Halves:** Bring the two table halves together, aligning them to form the full playing surface.
4. **Attach the Net:** The included quick-clamp net and post set is designed for easy attachment. Securely clamp the net posts to the center of the table, ensuring the net is taut and at the correct height.



Image: Illustration showing the JOOLA table tennis table ready for play in approximately 10 minutes, highlighting the single-player playback mode.



Image: Close-up of the clamp-style net attachment, demonstrating its hassle-free design for securing the net to the table.

Operating Instructions

Playing Mode

Once assembled, the table is ready for standard two-player table tennis. Ensure the net is properly installed and taut.

Single Player Playback Mode

To practice alone, one half of the table can be folded up into a vertical position, creating a rebound surface. This allows for solo practice and skill development.

1. Ensure the table is in its full playing position with the net removed.
2. Carefully unlock and fold one half of the table upwards until it is vertical.
3. Secure the folded half in its upright position using the integrated safety locking mechanisms.
4. Ensure the remaining half is stable and its wheels are locked.

Moving and Storage

The JOOLA Inside 15mm table is designed for easy mobility and compact storage.

- **Moving:** Unlock the 7.6 cm (3 inch) locking wheels. Carefully push the table to its desired location. Re-engage the wheel locks once positioned.
- **Storage:** For compact storage, both table halves can be folded and nested together. This significantly reduces the footprint of the table when not in use.



Image: The JOOLA table tennis table shown in its space-saving storage configuration, with both halves folded and nested together.



Image: Close-up of the premium locking wheels on the JOOLA table, emphasizing their role in providing safety and stability during movement and storage.

Maintenance

- **Cleaning the Surface:** Wipe the playing surface with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the MDF finish.
- **Frame Care:** Clean the metal frame with a damp cloth. Dry thoroughly to prevent rust.
- **Net Care:** The net can be gently hand-washed with mild soap and water if needed. Ensure it is completely dry before reattaching.
- **Hardware Check:** Periodically check all bolts, screws, and locking mechanisms to ensure they are secure. Tighten any loose fasteners.
- **Storage:** Store the table in a dry, indoor environment to protect it from moisture and extreme temperature fluctuations.

Troubleshooting

Table is Uneven

Solution: Adjust the leg levelers located at the bottom of each leg until the playing surface is perfectly level.

Net is Loose

Solution: Ensure the quick-clamp posts are securely fastened to the table. Adjust the tension system on the net to achieve desired tautness.

Difficulty Folding/Unfolding

Solution: Check for any obstructions. Ensure all locking mechanisms are disengaged before attempting to fold or unfold. Apply a small amount of silicone lubricant to moving parts if resistance persists.

Specifications

Brand	JOOLA
Model Number	11200
Playing Surface Material	Engineered Wood (MDF)
Playing Surface Thickness	15 mm
Frame Material	Engineered Wood / Steel
Dimensions (L x W x H)	274.32 cm x 152.4 cm x 76.2 cm (108 inches x 60 inches x 30 inches)
Product Weight	59 Kilograms (137 Pounds)
Wheel Size	7.6 cm (3 inches) locking casters
Assembly Required	Yes (minimal, approximately 10 minutes)
Number of Players	2 (or 1 in playback mode)
Included Components	Table Tennis Table, Easy Net and Post Set, Nuts, Bolts, Bolt Plate

Warranty and Support

JOOLA is committed to providing high-quality table tennis equipment. Your JOOLA Inside 15mm MDF Indoor Table Tennis Table is backed by a commitment to customer satisfaction.
For specific warranty details, including coverage period and terms, please refer to the warranty card included with your product or visit the official JOOLA website. If you have any questions, require assistance with assembly, or encounter any issues with your table, please contact JOOLA customer service.
JOOLA Customer Service: Please visit www.joola.com for contact information and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question