

[manuals.plus](#) /

- › [palmpower](#) /
- › [PALMPERFECT Electric Shaver User Manual](#)

**palmpower 3801**

# PALMPERFECT Electric Shaver User Manual

Model: 3801

## PRODUCT OVERVIEW

The PALMPERFECT Electric Shaver is a compact, cordless, and water-resistant device designed for smooth and irritation-free hair removal across various body areas. Its ergonomic design ensures comfortable handling, making it ideal for everyday grooming and travel.



Image: PALMPERFECT Electric Shaver, available in multiple colors, showcasing its compact design.

Equipped with dual clipper blades, this shaver effectively removes fine or coarse hair without pulling or causing nicks, providing a close shave for sensitive zones like the bikini area, underarms, legs, and face.

## SETUP

### 1. Battery Installation:

The PALMPERFECT Electric Shaver is powered by two AAA batteries (not included). To install, locate the battery compartment at the bottom of the shaver. Twist and pull the cap to open. Insert the batteries according to the polarity indicators (+/-) inside the compartment. Replace the cap by aligning and twisting until secure.

### 2. Initial Use:

Before first use, ensure the shaver is clean and dry. It can be used wet or dry, with or without shaving cream, offering versatile performance.

## OPERATING INSTRUCTIONS

The PALMPERFECT Electric Shaver features a simple one-button operation for ease of use.

### 1. Turning On/Off:

Press the central button on the shaver to turn it on. Press the button again to turn it off.

### 2. Shaving Technique:

Gently glide the shaver over the skin against the direction of hair growth. The dual blade system allows for smooth shaving in any direction. For longer hair, it is recommended to trim first with the clipper blades before using the foil shaver for a closer finish.



Image: Detailed view of the dual blades, designed for efficient removal of both fine and coarse hair.

### 3. Recommended Areas:

This shaver is suitable for legs, underarms, bikini area, and face. Its compact size and ergonomic grip provide full control, even in delicate areas.

# ONE TOOL, EVERY ZONE



Image: Visual guide illustrating the versatility of the shaver for various body zones including face, armpit, bikini line, and legs.

#### 4. Wet or Dry Use:

The water-resistant design allows for convenient use in the shower or on dry skin. No shaving cream is required, making it perfect for quick touch-ups anytime, anywhere.

# SHAVE WET OR DRY

Use Anytime, No Cream Required



Image: Demonstrates the shaver's capability for both wet and dry use, highlighting its adaptability.

## MAINTENANCE

Regular cleaning ensures optimal performance and longevity of your shaver.

### 1. Cleaning the Blades:

After each use, turn off the shaver. Carefully remove the shaver head. Use the small cleaning brush (if included) to brush away any trapped hairs from the blades and foil. You can also rinse the shaver head under running water, as it is water-resistant. Ensure it is completely dry before reattaching or storing.

### 2. Storage:

Store the shaver in a dry place. The included rope allows for convenient hanging in the shower or on a hook. Always replace the protective cap over the blades when not in use to prevent damage.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Dead or incorrectly installed batteries.	Check battery polarity. Replace with fresh AAA batteries.
Poor shaving performance / pulling hair.	Blades are dull or clogged with hair.	Clean the shaver head thoroughly. If performance does not improve, consider replacing the shaver.
Skin irritation after shaving.	Improper technique or sensitive skin.	Ensure gentle gliding motion. Try shaving on wet skin with shaving cream.

If issues persist, please refer to the full user guide PDF for more detailed troubleshooting steps.

## SPECIFICATIONS

- Brand:** palmperfect
- Model Name:** 3801
- Power Source:** Battery Powered (2 x AAA batteries)
- Special Feature:** Cordless, Water-resistant
- Recommended Uses:** Armpit, Face, Leg, Bikini Area
- Product Dimensions:** 3.9 x 1.93 x 7.83 inches
- Weight:** 3.53 ounces
- Country of Origin:** China
- UPC:** 843445038005




## WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the product packaging or contact PALMPERFECT customer service directly. A comprehensive user guide is also available for download:

Download User Guide  
(PDF)

© 2024 PALMPERFECT. All rights reserved.

## Related Documents - 3801

	<p><a href="#">PalmPerfect Electric Shaver Model 3801 Owner's Manual - Usage and Care Guide</a></p> <p>Official owner's manual for the PalmPerfect Electric Shaver, Model 3801. Includes detailed instructions for battery installation, safe usage, cleaning, and warranty information from Beacon Wellness Brands.</p>
	<p><a href="#">PALMPERFECT Electric Shaver Model 3801 Owner's Manual - Usage, Cleaning, and Warranty</a></p> <p>Comprehensive owner's manual for the PALMPERFECT Electric Shaver (Model 3801). Learn about product features, battery installation, usage, cleaning instructions, and warranty information from Beacon Wellness Brands.</p>
	<p><a href="#">AT&amp;T Wi-Fi Gateway Replacement Guide</a></p> <p>A step-by-step guide for replacing your AT&amp;T Wi-Fi Gateway, including setup, power-up, Wi-Fi configuration, and equipment return instructions.</p>
	<p><a href="#">AT&amp;T Wi-Fi Gateway Replacement Guide</a></p> <p>A step-by-step guide for replacing your AT&amp;T Wi-Fi Gateway, including setup, power up, Wi-Fi connection, and equipment return instructions.</p>