

[manuals.plus](#) /

› [Oreck](#) /

› [Oreck XL Upright Brush Roller and Belt Replacement Manual](#)

**Oreck 016-1152**

# Oreck XL Upright Brush Roller and Belt Replacement Manual

Model: 016-1152

## 1. INTRODUCTION

This manual provides detailed instructions for the proper installation and maintenance of your Oreck XL Upright Brush Roller and replacement belts. Adhering to these guidelines will ensure optimal performance and longevity of your vacuum cleaner.



**Image 1.1:** The Oreck XL Upright Brush Roller, featuring red bristles spiraling around a wooden core with black end caps.

## **2. COMPATIBILITY**

This replacement brush roller is designed for Oreck XL Upright Vacuum Cleaners. **It will NOT fit Oreck XL21 models.** Please verify your vacuum model number before proceeding with installation.

### 3. PACKAGE CONTENTS

Your package should contain the following items:

- 1 x Oreck XL Upright Brush Roller (Model 016-1152)
- 3 x Replacement Drive Belts

### 4. INSTALLATION INSTRUCTIONS

Replacing the brush roller and drive belt requires a T20 Torx screwdriver. Follow these steps carefully:

1. **Safety First:** Always unplug your Oreck XL vacuum cleaner from the power outlet before performing any maintenance or installation.
2. **Access the Brush Housing:** Lay the vacuum cleaner flat on its front. Locate the screws securing the bottom plate of the brush housing. There are typically five screws: two at the back and three at the front.
3. **Remove the Bottom Plate:** Use a T20 Torx screwdriver to remove all five screws. Note that some screws may be deeper than others, requiring a longer driver. Carefully lift off the bottom plate.
4. **Remove Old Components:** Once the bottom plate is removed, you will see the old brush roller and drive belt. Gently pull out the old brush roller. Remove the old drive belt from the motor shaft and the brush roller.
5. **Install New Drive Belt:** Place one of the new drive belts around the motor shaft.
6. **Install New Brush Roller:** Align the notches on the ends of the new brush roller with the corresponding slots in the vacuum's housing. Ensure the drive belt is properly seated around the brush roller.
7. **Reattach Bottom Plate:** Place the bottom plate back onto the vacuum, ensuring all components are correctly aligned. Secure it with the five T20 Torx screws. Do not overtighten.
8. **Test:** Plug in the vacuum cleaner and test its operation to ensure the new brush roller spins correctly.

### Installation Video Guide

Your browser does not support the video tag.

**Video 4.1:** This video demonstrates the process of replacing the brush roller and drive belt in an Oreck XL vacuum, including the specific T20 Torx screwdriver required for the task.

### 5. MAINTENANCE

Regular maintenance of your brush roller will extend its lifespan and maintain cleaning efficiency:

- **Hair and Debris Removal:** Periodically inspect the brush roller for tangled hair, strings, or other debris. Use scissors to carefully cut away any obstructions.
- **Brush Wear:** Over time, the bristles on the brush roller will wear down. Replace the brush roller when bristles appear significantly worn or when cleaning performance diminishes.
- **Belt Inspection:** Check the drive belt for signs of wear, stretching, or breakage. Replace the belt immediately if any damage is observed.

## 6. TROUBLESHOOTING

If you encounter issues after replacing the brush roller or belt, consider the following:

- Brush Roller Not Spinning:** Ensure the drive belt is correctly installed around both the motor shaft and the brush roller. Check for any obstructions preventing the brush from rotating freely.
- Reduced Suction/Cleaning Performance:** This could indicate a worn brush roller, a loose or broken drive belt, or other issues unrelated to these components (e.g., clogged filter or bag).
- Unusual Noises:** A new brush roller or belt should operate smoothly. If you hear grinding, squealing, or other unusual noises, re-check the installation for proper alignment and ensure no foreign objects are present.

## 7. SPECIFICATIONS

<b>Model Number</b>	016-1152
<b>Brand</b>	Oreck
<b>Item Weight</b>	8.8 ounces
<b>Package Dimensions</b>	12.44 x 5.63 x 3.58 inches
<b>Color</b>	Red (bristles)
<b>Bristle Material</b>	Rubber
<b>Handle Material</b>	Rubber
<b>Batteries Required</b>	No

## 8. WARRANTY AND SUPPORT



Specific warranty information for this replacement part is not provided in the product data. For details regarding warranty coverage or technical support, please refer to the original product documentation for your Oreck XL vacuum cleaner or contact Oreck customer service directly.

### Related Documents - 016-1152



#### [Oreck Elevate Conquer Upright Vacuum User Manual](#)

Comprehensive user manual for Oreck Elevate Conquer upright vacuum models UK30300, UK30300COM, and UK30370. Includes assembly, operation, safety instructions, maintenance, troubleshooting, and warranty information.

 <p><b>ORECK</b> Classic Pro User's Guide Important Read carefully before Assembly and use</p>	<p><a href="#"><u>Oreck Classic Pro Upright Vacuum Cleaner User's Guide</u></a></p> <p>Comprehensive user's guide for the Oreck Classic Pro upright vacuum cleaner, covering safety instructions, operation, maintenance, troubleshooting, and warranty information. Features HEPA filtration and odor-fighting bags.</p>
 <p><b>ORECK XI</b> SIMPLY AMAZING Service Parts List Upright Vacuum Cleaner Models XL3600HH XL3600RH XL3610HH U3700HH U3710HH U3720HG U3720HR L3760HH XL3640HH U3640RH XL3800H2B XL3900H2B XL3910H2B U3980H2B U3990H2B BY AA: Please disregard all earlier versions. Oreck Upright Vacuum Cleaner Models Type 4, 5, 6 &amp; 7</p>	<p><a href="#"><u>Oreck XL Upright Vacuum Cleaner Service Parts List and Diagrams</u></a></p> <p>Comprehensive service parts list and diagrams for Oreck XL Upright Vacuum Cleaner Models, including XL3600HH, XL3600RH, XL3610HH, U3700HH, U3710HH, U3720HG, U3720HR, L3760HH, XL3640HH, U3640RH, XL3800H2B, XL3900H2B, XL3910H2B, U3980H2B, U3990H2B, and Silver Series Uprights U3770HH, U3771HH. Includes part numbers, descriptions, order numbers, and troubleshooting tips.</p>
 <p><b>ORECK</b> FLOOR MACHINES User's Guide AIR94 &amp; AIR95 Important Read carefully before Assembly and use</p>	<p><a href="#"><u>Oreck Floor Machines XL300/XL400/XL480 Parts List</u></a></p> <p>Detailed parts list and diagram for Oreck Floor Machines models XL300, XL400, and XL480, including part numbers and descriptions.</p>
 <p><b>ORECK</b> OptiMax® Air Purifier User's Guide AIR94 &amp; AIR95 Important Read carefully before Assembly and use</p>	<p><a href="#"><u>Oreck OptiMax Air Purifier User's Guide AIR94 AIR95</u></a></p> <p>Comprehensive user's guide for the Oreck OptiMax Air Purifier, models AIR94 and AIR95. Learn about features, operation, maintenance, safety precautions, troubleshooting, and warranty details.</p>
 <p><b>VersaVac</b> High-Performance Bagless Vacuum &amp; Steam Mop User's Manual POWERFUL EASY TO USE ALL-IN-ONE LARGE TANK ORECK</p>	<p><a href="#"><u>Oreck VersaVacTM High-Performance Bagless Vacuum &amp; Steam Mop User Manual</u></a></p> <p>Comprehensive user manual for the Oreck VersaVacTM, detailing assembly, operation, safety instructions, maintenance, and troubleshooting for this high-performance bagless vacuum and steam mop. Includes guidance on use for various floor types and part replacement.</p>