

## Kohler 73094

# Kohler 73094 Adapter: Genuine Part Instruction Manual

Model: 73094

## 1. INTRODUCTION


---

This instruction manual provides important information regarding the installation, operation, and maintenance of your Kohler 73094 Adapter. This genuine Kohler part is engineered to ensure compatibility and maintain the original performance and longevity of your Kohler products. Please read this manual thoroughly before proceeding with installation or use.

## 2. PRODUCT OVERVIEW

---

The Kohler 73094 Adapter is a genuine replacement component designed for specific Kohler bathroom sink faucet applications. It serves as a critical connection point, ensuring proper function and fit within your plumbing system. Using genuine Kohler parts helps protect your product's warranty and ensures optimal performance.



**Image 2.1:** The Kohler 73094 Adapter. This image displays the adapter, a small, cylindrical component, typically black or dark in color, with threaded ends for connection.

### Key Features:

- **Genuine Kohler Part:** Ensures compatibility and maintains product warranty.
- **Engineered for Longevity:** Designed to uphold original product performance.
- **Durable Materials:** Constructed with premium materials for enhanced durability.
- **Specific Application:** Functions as an essential adapter for compatible Kohler fixtures.

### 3. PACKAGE CONTENTS

---

Please verify that all components are present before beginning installation:

- 1 x Kohler 73094 Adapter
- This instruction manual

## 4. SAFETY INFORMATION

---

Always observe the following safety precautions:

- Turn off the water supply to the fixture before beginning any installation or repair work.
- Wear appropriate personal protective equipment, such as safety glasses and gloves.
- If you are unsure about any step, consult a qualified plumber.
- Keep small parts away from children.

## 5. SETUP AND INSTALLATION

---

The Kohler 73094 Adapter is designed for straightforward installation. Specific steps may vary depending on the Kohler fixture it is being installed with. Always refer to the primary fixture's installation guide for detailed instructions.

### General Installation Steps:

1. **Prepare the Area:** Ensure the water supply to the fixture is turned off. Clear the workspace around the installation area.
2. **Remove Old Part (if applicable):** Carefully disconnect and remove the old or damaged adapter from the fixture, if replacing an existing part. Be prepared for residual water.
3. **Inspect Connections:** Check the threads on both the fixture and the connecting pipe for cleanliness and damage. Clean as necessary.
4. **Install New Adapter:** Thread the Kohler 73094 Adapter onto the appropriate connection point. Hand-tighten first, then use a wrench for a snug fit. **Do not overtighten**, as this can damage the adapter or the fixture.
5. **Check for Leaks:** Slowly turn the water supply back on and carefully inspect all connections for any signs of leaks. Tighten slightly if necessary.

## 6. OPERATING INSTRUCTIONS

---

The Kohler 73094 Adapter is a passive component that facilitates the proper function of your Kohler fixture. Once correctly installed, it operates as part of the overall plumbing system, requiring no direct user interaction. Its primary function is to provide a secure and leak-free connection.

## 7. MAINTENANCE

---

The Kohler 73094 Adapter requires minimal maintenance. Regular inspection of the adapter and surrounding connections is recommended to ensure continued optimal performance.

### Maintenance Tips:

- **Periodic Inspection:** Periodically check the adapter and its connections for any signs of leaks, corrosion, or wear.
- **Cleaning:** If necessary, clean the exterior of the adapter with a soft cloth and mild soap and water. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish or material.
- **Tightness Check:** If a minor leak is detected, gently tighten the connection. If the leak persists, turn off the water supply and re-evaluate the installation.

## 8. TROUBLESHOOTING

Most issues related to the adapter are typically associated with improper installation or connection.

Problem	Possible Cause	Solution
Water leak at connection point	Loose connection, damaged threads, missing or improperly seated washer/seal.	Turn off water supply. Check if the adapter is tightened correctly. Inspect threads for damage. Ensure any necessary washers or seals are properly in place. Replace adapter if damaged.
Adapter does not fit	Incorrect adapter model for the fixture.	Verify that the Kohler 73094 Adapter is the correct part for your specific Kohler fixture. Consult your fixture's manual or Kohler support.

## 9. SPECIFICATIONS

Attribute	Detail
Manufacturer	Kohler
Part Number	73094
Item Model Number	73094
Item Weight	1.58 ounces
Product Dimensions	2.85 x 2.35 x 1.25 inches
Color	Black
Finish	Unpolished
Item Package Quantity	1
Included Components	Repair part
Batteries Required?	No

## 10. WARRANTY AND SUPPORT

As a genuine Kohler part, the 73094 Adapter is covered by Kohler's standard warranty for replacement parts. Using genuine Kohler parts is essential to maintain the warranty of your original Kohler product.

### For Warranty Information and Technical Support:

- Visit the official Kohler website: [www.kohler.com](http://www.kohler.com)
- Refer to the warranty documentation included with your original Kohler fixture.
- Contact Kohler Customer Service directly for assistance with genuine parts or troubleshooting.

