

**Presto 06900**

# Presto 06900 Electric Griddle Heat Control User Manual

Model: 06900

## INTRODUCTION

This manual provides essential information for the safe and effective use of your Presto 06900 Electric Griddle Heat Control. This heat control unit is designed for use with compatible Presto Control Master electric appliances, including griddles and pressure cookers, to regulate cooking temperature precisely. Please read all instructions carefully before use.

## IMPORTANT SAFETY INFORMATION

**WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these basic safety precautions:**

- Always unplug the heat control from the wall outlet before cleaning or when not in use.
- Do not immerse the heat control unit in water or other liquids.
- Ensure the heat control is securely inserted into the appliance's receptacle before plugging into an electrical outlet.
- Do not operate the heat control if it has a damaged cord or plug, or if it malfunctions or has been damaged in any manner.
- Keep the cord away from heated surfaces.
- This heat control is intended for household use only.

## PARTS LIST

The Presto 06900 Electric Griddle Heat Control consists of the following main components:

- **Heat Control Unit:** The main body housing the thermostat and electrical components.
- **Temperature Probe:** The metal rod that inserts into the appliance to sense temperature.
- **Temperature Dial:** A rotary knob for setting the desired cooking temperature.
- **Power Cord and Plug:** For connecting the unit to an electrical outlet.



An overview of the Presto 06900 Electric Griddle Heat Control, showing the unit, its power cord, and original packaging. Small screws are also visible, though not part of the main control unit.

## SETUP

---

Follow these steps to properly set up your Presto 06900 Electric Griddle Heat Control:

1. **Ensure Compatibility:** Verify that your Presto appliance is designed to accept the 06900 Control Master heat control. This unit is specifically made for Presto appliances with a compatible receptacle.
2. **Insert Heat Control:** With the appliance unplugged, firmly insert the heat control probe into the receptacle on your electric griddle or pressure cooker. Ensure it is fully seated and secure.
3. **Position Appliance:** Place your appliance on a dry, stable, heat-resistant surface, away from walls or cabinets that could be damaged by heat or steam.
4. **Plug In:** Once the heat control is securely attached to the appliance, plug the power cord into a standard 120V AC electrical outlet.

## OPERATING INSTRUCTIONS

---

Using your Presto 06900 Electric Griddle Heat Control is straightforward:

1. **Set Temperature:** Rotate the temperature dial to your desired setting. The dial features temperature markings from 'Warm' up to 400 degrees Fahrenheit.
2. **Preheating:** Allow the appliance to preheat to the selected temperature. A small indicator light on the control unit (if present on your model) may illuminate during heating and turn off once the set temperature is reached.
3. **Cooking:** Once preheated, begin cooking according to your recipe. The heat control will automatically maintain the set temperature, cycling the heating element on and off as needed.
4. **Adjusting Temperature:** You can adjust the temperature at any time during cooking by rotating the dial.

5. **Turning Off:** To turn off the appliance, rotate the temperature dial to the 'OFF' position. Always unplug the unit from the wall outlet after use.



A close-up view of the temperature dial on the Presto 06900 heat control, showing settings from 'Warm' to 400 degrees Fahrenheit and the 'OFF' position.

## MAINTENANCE

Proper care and maintenance will ensure the longevity and performance of your heat control unit:

- **Cleaning:** Always unplug the heat control and allow it to cool completely before cleaning. Wipe the exterior of the heat control unit with a damp cloth. Do not use abrasive cleaners or scouring pads.
- **Do Not Immerse:** Never immerse the heat control unit, cord, or plug in water or any other liquid.
- **Storage:** Store the heat control in a dry place when not in use. Ensure the cord is not tightly wrapped around the unit, which could cause damage over time.

## TROUBLESHOOTING

If you encounter issues with your Presto 06900 Electric Griddle Heat Control, try these common troubleshooting steps:

Problem	Possible Cause	Solution
Appliance not heating	Heat control not fully inserted; Power outlet issue; Appliance malfunction	Ensure heat control is fully seated. Check if outlet is working. Test appliance with another compatible control if available.
Inconsistent heating	Loose connection; Faulty heat control	Verify secure connection. If problem persists, the heat control may need replacement.

Problem	Possible Cause	Solution
Temperature dial feels loose	Normal wear; Internal component issue	Minor play is normal. If it affects function, contact customer support.

If these steps do not resolve the issue, please refer to the Warranty and Support section.

## SPECIFICATIONS

- **Model Number:** 06900
- **Product Dimensions:** Approximately 11 x 9 x 5 inches (packaging dimensions)
- **Item Weight:** 6.7 ounces
- **Manufacturer:** Presto
- **Compatibility:** Designed for Presto Control Master electric appliances and pressure cookers.



The packaging box for the Presto Control Master Heat Control, clearly showing the model number 06900.

## WARRANTY AND SUPPORT





Presto products are manufactured to high-quality standards. For specific warranty information regarding your Presto 06900 Electric Griddle Heat Control, please refer to the documentation included with your original purchase or visit the official Presto website.

For technical assistance, replacement parts, or general inquiries, you may contact Presto customer service. Contact information is typically available on the manufacturer's website or through the customer support section of the retailer where the product was purchased.

**Online Resources:** For additional information and support, visit the [Presto Store on Amazon](#).



Related Documents

	<p><a href="#">Presto 12-inch Electric Skillet with Glass Cover</a></p> <p>Discover the versatility of the Presto 12-inch Electric Skillet with glass cover. Perfect for roasting, frying, grilling, stewing, baking, and making one-dish meals, it features a premium nonstick surface, Control Master® heat control, and a durable cast aluminum base. Ideal for everyday use and entertaining.</p>
	<p><a href="#">Presto 40 (4QT) Pressure Cooker Owner's Manual</a></p> <p>Owner's manual for the Presto 40 (4QT) aluminum pressure cooker, detailing its features, components, and benefits for fast, healthy cooking. Includes information on different models, parts, and warranty.</p>
	<p><a href="#">Presto Cordless-Serve 12-Cup Stainless Steel Coffee Maker: Instructions and Care</a></p> <p>Official instructions and user guide for the Presto Cordless-Serve 12-cup stainless steel coffee maker. Learn about features, important safety precautions, how to use, clean, and troubleshoot your Presto coffee maker.</p>
	<p><a href="#">Presto FryDaddy Plus Electric Deep Fryer: Instructions and Safety Guide</a></p> <p>Comprehensive guide to using the Presto FryDaddy Plus electric deep fryer, covering setup, operation, safety precautions, cleaning, and troubleshooting. Learn how to make delicious fried foods quickly and easily.</p>

Documents - Presto – 06900



[\[pdf\]](#) Guide

Borg Buyer s Guide yourtiresupply files |||

EQUIPMENT SUPPLY CO. BUYER S GUIDE YOUR ONE SOURCE FOR QUALITY BRAND NAME EQUIPMENT, TOOLS SUPPL ... 0 OAL 469-01910 N-1910 Large Bore Core Remover. Plastic Handle For Positive Grip. 5 - 6 OAL 469-**06900** TL-690 Four-Way Large Bore Core Tool. Thread Repair For Core And Cap Threads And Core Remover...

lang:en **score:18** filesize: 127.95 M page\_count: 444 document date: 2014-02-20

