

## Skilcraft 7520-01-554-8208

# SKILCRAFT Retractable Chisel Tip Highlighter User Manual

Model: 7520-01-554-8208

## 1. INTRODUCTION

The SKILCRAFT Retractable Chisel Tip Highlighters are designed for efficient and precise highlighting. Featuring a convenient single-handed operation, these highlighters eliminate the need for traditional caps, ensuring quick access and preventing lost caps. The quick-drying ink is formulated to resist smearing and leaking, providing clean and crisp marks on various materials.

Key features include:

- Quick drying ink that will not smear or leak.
- Durable polyester tip that maintains its shape during use.
- Integrated safety clip to protect against pocket leakage and for portability.
- Constructed with marker barrels and plungers made from 50 percent pre-consumer recycled plastic.
- Proudly made by Americans who are blind.



An array of ten SKILCRAFT retractable highlighters in various colors including pink, yellow, orange, blue, and green, showcasing their sleek design and chisel tips.

## 2. SETUP

---

Your SKILCRAFT retractable highlighters are ready for immediate use. No assembly is required.

1. Remove the highlighter from its packaging.
2. To extend the chisel tip, simply press the button located at the top of the highlighter barrel. The tip will click into place, ready for use.

## 3. OPERATING INSTRUCTIONS

---

The chisel tip design allows for versatile highlighting, enabling broad, medium, and fine lines.

1. **Broad Line:** Hold the highlighter flat against the paper, using the full width of the chisel tip to create a wide, bold highlight.
2. **Medium Line:** Angle the highlighter slightly, using a portion of the chisel tip to create a line of medium thickness.
3. **Fine Line:** Hold the highlighter vertically, using only the narrow edge of the chisel tip to create a thin, precise line for underlining or fine details.
4. **Retracting the Tip:** When finished highlighting, press the side clip to retract the tip back into the barrel. This protects the tip and prevents the ink from drying out.

## 4. MAINTENANCE AND CARE

---

Proper care will extend the life of your highlighters:

- Always retract the tip after each use to prevent the ink from drying out.
- Store highlighters at room temperature, away from direct sunlight or extreme heat/cold, which can affect ink performance.
- Avoid dropping the highlighters, especially on the tip, as this can damage the chisel point.

## 5. TROUBLESHOOTING

---

If you encounter issues with your highlighter, consider the following:

- **Ink appears dry or faded:** Ensure the tip was fully retracted after the last use. If the highlighter has been left exposed to air for an extended period, the ink may have dried.
- **Tip is damaged:** Avoid applying excessive pressure or dropping the highlighter, as this can fray or damage the polyester tip.

## 6. SPECIFICATIONS

---

Attribute	Detail
Brand	Skilcraft
Model Number	7520-01-554-8208
Item Weight	2.4 ounces
Package Dimensions	6.6 x 6 x 1.5 inches

Color	Assorted (Blue, Pink, Yellow, Green, Orange)
Material Type	Plastic
Number of Items	10 Count (Pack of 1)
Point Type	Chisel
Ink Color	Blue, Pink, Yellow, Green, Orange
Manufacturer	National Industries for the Blind
Date First Available	November 5, 2013

## 7. WARRANTY AND SUPPORT

---

Specific warranty information for the SKILCRAFT 7520-01-554-8208 highlighters is not provided in the product details. For any product support or inquiries, please refer to the contact information provided by your retailer or the manufacturer, National Industries for the Blind.

SKILCRAFT products are known for their quality and purpose, supporting employment for Americans who are blind.