Ronson Comet

Ronson Comet Refillable Butane Lighter Instruction Manual

Introduction

Thank you for choosing the Ronson Comet Refillable Butane Lighter. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your new lighter. Please read these instructions carefully before initial use and retain them for future reference.

Safety Information

Your Ronson Comet Lighter is designed with safety in mind, including a child-resistant mechanism. However, improper use can lead to serious injury. Always adhere to the following safety guidelines:

- **KEEP OUT OF REACH OF CHILDREN:** This lighter is not a toy. Ensure it is stored in a secure location inaccessible to children.
- **IGNITE AWAY FROM FACE AND CLOTHING:** Always direct the flame away from your body and flammable materials when igniting.
- **DO NOT PUNCTURE OR INCINERATE:** The lighter contains pressurized flammable gas. Never puncture, drop, or throw into a fire.
- **DO NOT EXPOSE TO HEAT:** Avoid prolonged exposure to direct sunlight or temperatures exceeding 120°F (49°C).
- **ENSURE FLAME IS EXTINGUISHED:** Always confirm the flame is completely out after each use.
- **USE IN WELL-VENTILATED AREA:** Refill and operate the lighter in an area with adequate ventilation.
- **USE ONLY BUTANE FUEL:** Only use high-quality butane fuel for refilling. Ronson Butane Fuel is recommended for optimal performance.

Setup: Refilling Instructions

The Ronson Comet Lighter is refillable, allowing for extended use. For best results, use Ronson Butane Fuel.

1. **Prepare the Lighter:** Ensure the lighter is completely cool before refilling. Hold the lighter upside

down.

2. **Prepare Butane Canister:** Shake the butane fuel canister.
3. **Refill:** Insert the nozzle of the butane canister directly into the refill valve located at the bottom of the lighter. Press firmly for approximately 5-10 seconds. You may hear a slight hiss as the fuel transfers.
4. **Allow to Settle:** After refilling, wait at least 2-3 minutes before attempting to ignite the lighter. This allows the gas to stabilize and reach room temperature.



This image displays the packaging for the Ronson Comet Refillable Butane Lighter. It features two lighters, one in red and one in yellow, highlighting key features such as 'Refillable Butane Lighter,' 'Electronic Ignition,' 'Adjustable Flame,' 'Fuels in Seconds,' and 'Child Resistant,' along with a '1 Year Warranty' notice.

Operating Instructions

Ignition

Your Ronson Comet Lighter features electronic ignition for reliable lighting.

1. **Hold Lighter:** Hold the lighter upright, away from your face and any flammable objects.
2. **Activate Ignition:** Press the ignition button or lever firmly and quickly. A spark will be generated, igniting the butane gas.
3. **Release:** Release the ignition button/lever once the flame is established. The flame should extinguish automatically upon release.

Flame Adjustment

The Ronson Comet Lighter features an adjustable flame to suit various needs.

- Locate the flame adjustment mechanism, typically a small dial or lever, on the bottom of the lighter near the refill valve.
- Use a small screwdriver or a similar tool to turn the adjuster. Turn towards the '+' symbol for a larger flame, and towards the '-' symbol for a smaller flame.
- Test the flame after each adjustment to achieve the desired height.

Maintenance

Proper care will ensure the longevity and performance of your Ronson Comet Lighter.

- **Cleaning:** Periodically wipe the exterior of the lighter with a soft, dry cloth to remove dirt or residue. Do not use abrasive cleaners or solvents.
- **Storage:** Store the lighter in a cool, dry place, away from direct sunlight and heat sources. Ensure it is out of reach of children.
- **Avoid Dropping:** Dropping the lighter can damage internal components or compromise its integrity.

Troubleshooting

If you encounter issues with your Ronson Comet Lighter, try the following solutions:

- **Lighter Not Igniting:**
  - Check fuel level. If low, refill the lighter following the instructions in the 'Setup' section.
  - Ensure the ignition button/lever is pressed firmly and completely.
  - Verify that the flame adjustment is not set to the lowest possible setting.
- **Flame Too Low or Too High:**
  - Adjust the flame using the flame adjustment mechanism as described in the 'Operating Instructions' section.
- **Gas Leaking During Refill:**
  - Ensure the butane canister nozzle is properly aligned and pressed firmly into the refill valve.
  - Use a butane canister with the correct adapter tip for a snug fit.

If problems persist after attempting these solutions, please refer to the warranty information.

Specifications

- **Model:** Comet
- **Brand:** Ronson
- **Ignition Type:** Electronic Ignition
- **Fuel Type:** Butane (Liquefied Petroleum Gas)
- **Features:** Refillable, Adjustable Flame, Child Resistant
- **Recommended Fuel:** Ronson Butane Fuel
- **UPC:** 037900418420

Warranty and Support

The Ronson Comet Refillable Butane Lighter comes with a**1 Year Warranty**. For warranty claims, product support, or further assistance, please refer to the contact information provided on the product packaging or visit the official Ronson website.