

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Oster](#) /

› [Oster Gentle Paws Less Stress 2-Speed Dog and Cat Nail Grinder Instruction Manual \(Model 078129-600-001\)](#)

Oster 078129-600-001

Oster Gentle Paws Less Stress 2-Speed Dog and Cat Nail Grinder Instruction Manual

Model: 078129-600-001

INTRODUCTION

The Oster Gentle Paws Less Stress Dog and Cat Nail Grinder is designed to provide a quick and stress-free solution for maintaining your pet's nails. This cordless, battery-powered device offers precise control and operates quietly, making the nail filing process more comfortable for both you and your pet. It features a 2-speed design and an adjustable safety guard to prevent over-trimming and minimize mess from nail filings. Suitable for all breeds of cats and dogs, this grinder includes various accessories to ensure effective nail care.

PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the parts of your Oster Gentle Paws Nail Grinder:



Image: Oster Gentle Paws Nail Grinder showing its main components: Grinding Drum, Adjustable Safety Guard, Collet, Collet Lock Button, Easy to Hold Handle, On/Off Switch (2 speeds), and Battery Compartment.

- **Grinding Drum:** The rotating abrasive surface that files the pet's nails.
- **Adjustable Safety Guard:** A protective cover with different sized openings to guide the nail and collect filings.
- **Collet:** The part that holds the grinding drum in place.
- **Collet Lock Button:** Used to secure or release the grinding drum.
- **Easy to Hold Handle:** Ergonomically designed for comfortable grip and control.
- **On/Off Switch (2 speeds):** Controls the power and speed settings of the grinder.
- **Battery Compartment:** Houses the 4 AA batteries required for operation.

The package includes the main device, one coarse stone, one fine band, and two coarse bands for varied grooming needs.

SETUP

1. Battery Installation:

- Locate the battery compartment at the base of the grinder.
- Twist or slide open the compartment cover.
- Insert 4 AA batteries, ensuring correct polarity (+/-).
- Close the battery compartment cover securely.

2. Attaching Grinding Bands/Stones:

- Press and hold the Collet Lock Button.
- Unscrew the collet nut counter-clockwise to loosen it.
- Slide the desired grinding band or stone onto the spindle.
- Tighten the collet nut clockwise while holding the Collet Lock Button until the band/stone is secure. Release the button.

3. Adjusting Safety Guard:

- The adjustable safety guard has multiple openings for different nail sizes.
- Rotate the safety guard to select the appropriate opening for your pet's nail. This helps guide the nail and collects filings.

OPERATING INSTRUCTIONS

Preparing Your Pet

It is crucial to introduce the nail grinder to your pet gradually to ensure a positive experience. Allow your pet to sniff and investigate the grinder while it is off. Turn it on briefly to let them get used to the sound and vibration. Offer treats and praise throughout this process. For best results, begin with short, frequent sessions rather than long, infrequent ones.

Grinding Technique

1. Ensure your pet is calm and comfortable. Hold their paw gently but firmly.
2. Turn the grinder ON using the 2-speed switch. Start with the lower speed setting for initial use or nervous pets.
3. Gently place your pet's nail into the appropriate opening of the adjustable safety guard.
4. Apply the grinding drum to the tip of the nail for only 1-2 seconds at a time. This prevents the nail from overheating and causing discomfort.
5. Move the grinder around the tip of the nail to shape and smooth it. Avoid grinding too deeply to prevent hitting the quick (the sensitive part of the nail containing blood vessels and nerves).
6. Repeat the process for each nail, offering praise and treats as you go.
7. After grinding, check the nails for smoothness.



nail grinder uses the same technology used by professional groomers. Includes a whisper quiet rotary motor to quickly and effectively trim your pet's nails. Adjustable safety guard also ensures you don't trim your pet's nails too closely.

FEATURES

ROTATING HEAD - GENTLY FILES YOUR PET'S NAILS QUICKLY, EASILY AND WITH LESS STRESS.

SAFETY GUARD - HOLDS NAILS IN PLACE AND PREVENTS ACCIDENTAL HAIR WINDING.

TWO SPEEDS - ADJUSTABLE FOR ALL DOG BREEDS AND SIZES

CORDLESS OPERATION - PROVIDES AN EASY ONE-HANDED OPERATION AND PRECISE CONTROL.



INCLUDES

GRINDING DRUM
MEDIUM & FINE SANDING BANDS
GRINDING STONE

REQUIRES


4 "AA" BATTERIES (NOT INCLUDED)

©2014 Sunbeam Products, Inc. doing business as Jarden Consumer Solutions. All rights reserved. Distributed by Sunbeam Products, Inc. doing business as Jarden Consumer Solutions, Boca Raton, Florida 33431. Sunbeam Products, Inc. is a subsidiary of Jarden Corporation (NYSE: JAH). 1-800-830-3678. Made in China.

1 Year Warranty - see inside for details. Due to continuing product development, the product inside the package may look slightly different than the one in the package.

P.N. 166986 SKU 078129-501-001

CSA101314 - OPA36282



0 34264 3834 7

www.osterpets.com

Image: A person holding a dog's paw and using the Oster Gentle Paws Nail Grinder to trim the nails. The adjustable safety guard is visible, guiding the nail into the grinding drum.



Image: A close-up view of the Oster Gentle Paws Nail Grinder in action, showing the grinding drum gently filing a dog's nail. The dog appears calm during the process.



Image: The Oster Gentle Paws Nail Grinder being used on a dog's paw, illustrating how the pet's paw is held securely while the grinder works on the nail. The focus is on the gentle and controlled application.

Official Product Video

Your browser does not support the video tag.

Video: An official product video demonstrating the features and proper use of the Oster Gentle Paws Premium Nail Grinder for Dogs and Cats. It highlights the quiet operation and ease of use for pet grooming.

MAINTENANCE

- **Cleaning:** After each use, remove the adjustable safety guard and gently brush away any accumulated nail dust from the grinding drum and inside the guard. This ensures optimal performance and hygiene.
- **Replacing Grinding Bands/Stones:** When the grinding surface becomes worn or less effective, replace it with a new one. Follow the instructions in the "Setup" section for attaching new bands/stones.
- **Battery Replacement:** When the grinder's power diminishes, replace all 4 AA batteries with new ones. Refer to the "Setup" section for battery installation.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Grinder does not turn on.	Dead or incorrectly installed batteries.	Check battery polarity and replace with fresh AA batteries.
Grinder runs slowly or lacks power.	Low battery power.	Replace batteries with new ones.
Ineffective grinding.	Worn grinding band/stone; excessive nail dust buildup.	Replace the grinding band/stone. Clean the grinding drum and safety guard.
Pet shows discomfort or fear.	Not accustomed to the grinder; nails overheating.	Reintroduce the grinder gradually with positive reinforcement. Use shorter grinding intervals (1-2 seconds per nail) to prevent heat buildup.

SPECIFICATIONS

Feature	Detail
Brand	Oster
Model Number	078129-600-001
Power Source	Battery Powered (4 AA batteries required)
Voltage	6 Volts (DC)
Speed Settings	2-Speed Design
Special Features	Whisper-Quiet Operation, Adjustable Safety Guard
Included Components	Main device, coarse stone, fine band, 2 coarse bands
Item Weight	0.3 Pounds (4.8 ounces)
Item Dimensions (L x W x H)	2.25 x 5.5 x 9.5 inches
Material	Stone (for grinding attachments)
Target Audience	Dogs, House-cats (All Life Stages)
Manufacturer	Jarden Consumer Solutions
Country of Origin	China
Date First Available	July 15, 2009

WARRANTY AND SUPPORT

This Oster product is covered by the manufacturer's standard warranty. For specific warranty details, including duration and coverage, please refer to the warranty information provided in your product packaging or contact Jarden Consumer Solutions directly. Keep your proof of purchase for any warranty claims.

For customer support, replacement parts, or further assistance, please visit the official Oster website or contact their customer service department. Contact information can typically be found on the product packaging or the manufacturer's website.

