

Manuals.plus /

› Casio /

› Casio G-2900F-1 Genuine Replacement Watch Band Instruction Manual

Casio G-2900F-1

Casio G-2900F-1 Genuine Replacement Watch Band Instruction Manual

Model: G-2900F-1

1. INTRODUCTION

This instruction manual provides guidance for the proper installation, use, and maintenance of your Casio G-2900F-1 genuine replacement watch band. This band is designed to ensure a perfect and secure fit for your Casio G-Shock watch.

Compatibility: This replacement watch band is specifically designed for the following Casio G-Shock models:

- G-2900F-1VW
- G-2900-1AV
- G-2900BT-10VV
- G-2900BT-11VV
- G-2900BT-12VV
- G-20BT-1V VD
- G-2900BT-2VVD
- G-2900BT-3VVD
- G-2900BT-4VVD
- G-2900BT-5VVD

Please verify your watch's model number, typically found on the back casing, to ensure compatibility.

2. SETUP AND INSTALLATION

Installing your new Casio G-2900F-1 watch band requires careful handling of the spring-loaded hinge pins. The replacement band does **not** include new pins; you must reuse the original pins from your watch.

2.1 Tools Required

- Small, thin flat-head screwdriver or a spring bar tool.
- Soft cloth or surface to protect your watch.

2.2 Removing the Old Watch Band

1. Place your watch face down on a soft, clean surface to prevent scratches.
2. Locate the spring-loaded hinge pin connecting the watch band to the watch case. These pins are typically found at the lugs where the band meets the watch.
3. Using a thin flat-head screwdriver or spring bar tool, gently insert the tip between the watch band and the watch case, near one end of the hinge pin.
4. Apply slight pressure to compress the spring-loaded pin. You will feel it retract.
5. Once one end of the pin is compressed and free from its socket, carefully wiggle the band to release the other end of the pin from its socket.
6. Remove the old band section and set aside the hinge pin. Repeat for the other side of the watch band.
7. **Important:** Do not discard the old hinge pins, as they are required for installing the new band.



Image 1: The Casio G-2900F-1 genuine replacement watch band, displaying both sections of the strap and the metal buckle.

2.3 Installing the New Watch Band

1. Take one section of the new watch band and insert one of the saved hinge pins through the channel at its end. Ensure the pin is centered within the channel.
2. Position one end of the hinge pin into its corresponding socket on the watch case.
3. Using your screwdriver, spring bar tool, or even your thumbnail, compress the other end of the hinge pin.
4. While compressed, guide the pin into its socket on the watch case.
5. Once the pin is seated, gently tug on the band to ensure it is securely attached and the pins are fully engaged in their sockets.
6. Repeat this process for the second section of the watch band.



Image 2: Underside view of the Casio G-2900F-1 replacement watch band, highlighting the texture and pin channels.

3. OPERATING (WEARING AND ADJUSTMENT)

Once installed, the watch band operates like any standard buckle-closure watch strap.

- **Fastening:** Insert the free end of the band through the buckle and secure the pin into one of the adjustment holes.
- **Adjustment:** Select the hole that provides a comfortable yet secure fit on your wrist. The band should not be too tight to restrict circulation, nor too loose to allow the watch to slide freely.
- **Strap Keeper:** Use the movable strap keeper to secure any excess band length.

4. MAINTENANCE AND CARE

To ensure the longevity and appearance of your Casio G-2900F-1 watch band, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the band with a soft cloth dampened with mild soap and water. Rinse thoroughly with clean water and dry completely with a soft, dry cloth.
- **Avoid Chemicals:** Do not expose the band to harsh chemicals, solvents, or abrasive cleaners, as these can damage the resin material.
- **Storage:** When not in use, store your watch in a cool, dry place away from direct sunlight to prevent material degradation.
- **Inspection:** Periodically inspect the band for any signs of wear, cracks, or damage, especially around the pin areas.

5. TROUBLESHOOTING

If you encounter issues with your replacement watch band, consider the following:

- **Band Does Not Fit:** Double-check your watch's model number against the compatibility list in Section 1. Ensure you have the correct replacement band for your specific G-Shock model.
- **Pins Keep Falling Out During Installation:** Ensure the hinge pins are fully compressed and properly seated into both sockets on the watch case. A slight tug on the band after installation should confirm security. If pins are bent or damaged, they may need replacement (not included with this

band).

- **Discomfort or Irritation:** Ensure the band is not fastened too tightly. If irritation persists, clean the band thoroughly as per Section 4.

6. SPECIFICATIONS

| | |
|------------------------------|---------------------------------------|
| Model Number | G-2900F-1 |
| Material | Resin |
| Clasp Type | Buckle |
| Item Length | 7.68 inches (approx. 19.5 cm) |
| Product Dimensions | 7.68 x 1.97 x 0.59 inches (L x W x H) |
| Weight | 1.12 ounces (approx. 31.75 grams) |
| Lug Width (Ring size) | 16 millimeters |

7. WARRANTY AND SUPPORT

As a genuine Casio replacement part, this watch band is manufactured to Casio's high-quality standards. For specific warranty information regarding accessories, please refer to the official Casio website or contact Casio customer support directly.

If you require further assistance or have questions not covered in this manual, please contact Casio customer service. When contacting support, please have your watch model number (G-2900F-1) readily available for efficient service.

You can find official Casio support contact information on their global website: www.casio.com/support