

[Manuals.plus](#) /

> [Klip Xtreme](#) /

> Klip Xtreme KES-390 Stereo Speakers 2.0 User Manual

Klip Xtreme KES-390

Klip Xtreme KES-390 Stereo Speakers 2.0 User Manual

Model: KES-390

1. INTRODUCTION

Thank you for purchasing the Klip Xtreme KES-390 2.0 Stereo Speakers. These speakers are designed to provide a true stereo audio experience, offering flexibility in positioning each unit to optimize sound delivery. Please read this manual carefully to ensure proper setup, operation, and maintenance of your new speakers.



Image: Klip Xtreme KES-390 2.0 Stereo Speakers. The image shows two compact silver and black speakers positioned in front of a black laptop, highlighting their desktop use.

2. PACKAGE CONTENTS

Ensure all items are present in the package:

- Klip Xtreme KES-390 2.0 Stereo Speakers (2 units)
- USB Power Cable

- 3.5mm Audio Cable
- User Guide

3. PRODUCT FEATURES

- 2.0 Channel Stereo Speakers
- USB Powered for convenience
- High-quality stereophonic sound
- 3.5mm audio input for versatile connectivity
- Compact and portable design
- Audio playback via USB and SD

4. SETUP INSTRUCTIONS

1. **Positioning the Speakers:** Place the two speaker units on a stable, flat surface. For optimal stereo separation, position them equidistant from your listening position.
2. **Connecting Power:** Connect the USB power cable from one of the speakers to an available USB port on your computer, laptop, or a USB wall adapter (not included). The speakers will power on automatically.
3. **Connecting Audio Source:**
 - **Via 3.5mm Audio Cable:** Connect one end of the included 3.5mm audio cable to the audio input jack on the speaker (usually marked "Audio In" or with a headphone icon). Connect the other end to the audio output jack of your device (e.g., computer, smartphone, MP3 player).
 - **Via USB/SD Card:** Insert your USB flash drive or SD card into the designated slot on the speaker. The speaker should automatically detect and begin playing audio files. Refer to the operating instructions for specific playback controls.
4. **Adjusting Volume:** Adjust the volume using the volume control knob on the speaker or through your connected audio device.



Image: A close-up view of the two Klip Xtreme KES-390 speakers, showing their silver speaker cones and black casing, ready for connection.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

The speakers are powered on automatically when connected to a USB power source. Disconnect the USB cable to power them off.

5.2 Volume Control

Locate the volume control knob on one of the speaker units. Rotate it clockwise to increase the volume and counter-clockwise to decrease it. You can also control the volume from your connected audio device.

5.3 Audio Playback (3.5mm Input)

Once the 3.5mm audio cable is connected to your device, ensure your device's volume is turned up and playback is initiated. The sound will be output through the speakers.

5.4 USB/SD Card Playback

Insert the USB drive or SD card into the corresponding slot. The speakers should automatically detect and play compatible audio files. Use the integrated controls (if available) on the speaker to navigate tracks or adjust playback settings.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker surfaces. Do not use liquid cleaners or abrasive materials, as they may damage the finish.
- **Storage:** When not in use for extended periods, store the speakers in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the speakers or subjecting them to strong impacts.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound	USB power not connected. Audio cable not connected properly. Volume too low on speakers or audio device. Incorrect audio source selected on device.	Ensure USB power cable is securely connected to a working USB port. Check 3.5mm audio cable connections at both ends. Increase volume on both the speakers and your audio device. Verify the correct audio output is selected on your computer or device.
Distorted sound	Volume too high. Poor audio source quality. Loose cable connection.	Reduce volume on speakers and/or audio device. Try a different audio source or file. Check all cable connections.
Speakers not recognized (USB/SD playback)	Incompatible file format. Faulty USB drive/SD card.	Ensure audio files are in a compatible format (e.g., MP3). Try a different USB drive or SD card.

8. SPECIFICATIONS

Feature	Detail
Brand	Klip Xtreme

Feature	Detail
Model	KES-390
Speaker Type	2.0 Channel Stereo Speakers
Connectivity Technology	USB (for power), 3.5mm Audio Jack (for input), USB/SD Card (for playback)
Max Speaker Output Power	48 Watts
Power Source	USB Powered
Mounting Type	Desktop Mount
Material	Acrylic
Color	Silver
Item Weight	453 Grams
UPC	798304071054
ASIN	B002KXZD02

9. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or contact your retailer. For technical support or service inquiries, please visit the official Klip Xtreme website or contact their customer service department.