

Bose 318842-110R

# Bose CineMate Series II Digital Home Theater Speaker System User Manual

*Model: 318842-110R*

## 1. PRODUCT OVERVIEW

The Bose CineMate Series II Digital Home Theater Speaker System is designed to enhance your HDTV audio experience with dramatic sound. This 2.1-channel system features compact speakers and a hideaway Acoustimass module, utilizing proprietary TrueSpace technology for a spacious soundstage.



Figure 1: Overview of the Bose CineMate Series II system components.

### Key Features:

- 2.1-channel home theater speaker system with redesigned Articulated Array speakers.
- Improved digital acoustic performance for enhanced audio.
- Specifically designed for seamless integration with your television.
- Sleek, four-button remote control for convenient system operation.
- Simplified setup process requiring only a few connections.

## 2. WHAT'S IN THE BOX

Verify that all components are present before proceeding with setup:

- Acoustimass module
- 2 Articulated Array speakers
- Interface module
- Four-button remote control
- Power cord (8')
- Stereo cable (6')
- Speaker cable (15')
- Optical cable (6')

- Setup DVD
- Owner's manual

### 3. SETUP INSTRUCTIONS

---

The CineMate Series II system is designed for easy installation. Follow these steps to connect your system:

1. **Position the Acoustimass Module:** Place the Acoustimass module in a discreet location, such as behind a curtain or chair. Ensure it is near a power outlet.
2. **Connect the Speakers:** Connect the two Articulated Array speakers to the Acoustimass module using the provided speaker cables.
3. **Connect the Interface Module:** The interface module houses the audio input from your TV. Connect the interface module to your TV using either the optical cable or the stereo cable, depending on your TV's available outputs.



Figure 2: Rear connections of the Acoustimass module and the interface module.

4. **Power Connection:** Connect the power cord from the Acoustimass module to a wall outlet.
5. **Remote Control Setup:** Insert batteries into the four-button remote control.

For detailed visual guidance, refer to the included Setup DVD.



Figure 3: Example of the CineMate Series II system integrated into a living room.

## 4. OPERATING THE SYSTEM

---

The CineMate Series II system is operated using its simplified four-button remote control.



Figure 4: The simplified four-button remote control.

- **Power:** Press the power button to turn the system on or off.
- **Volume:** Use the volume up (+) and volume down (-) buttons to adjust the sound level.
- **Mute:** Press the mute button to temporarily silence the audio. Press again to restore sound.

The interface module will display on/off status for your speaker system.

## 5. MAINTENANCE

To ensure optimal performance and longevity of your Bose CineMate Series II system, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the speakers, Acoustimass module, and interface module. Avoid using liquid cleaners or solvents.
- **Ventilation:** Ensure that the Acoustimass module has adequate ventilation. Do not block any vents.
- **Cable Management:** Periodically check all cable connections to ensure they are secure.
- **Environmental Conditions:** Avoid exposing the system to extreme temperatures, humidity, or direct sunlight.

## 6. TROUBLESHOOTING

If you encounter issues with your CineMate Series II system, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
No sound	Power cord disconnected, incorrect audio input, system muted.	Check power connections. Verify audio cable connection to TV and interface module. Ensure system is not muted.
Poor sound quality	Loose speaker cables, incorrect speaker placement, audio source issue.	Secure speaker cables. Adjust speaker placement for optimal sound. Test with a different audio source.
Remote control not working	Dead batteries, obstructed signal, remote out of range.	Replace remote batteries. Ensure clear line of sight to interface module. Move closer to the system.

For further assistance, consult the full owner's manual or contact Bose customer support.

## 7. SPECIFICATIONS

- **Model Name:** CineMate Series II
- **Speaker Type:** Satellite
- **Surround Sound Channel Configuration:** 2.1
- **Color:** Black
- **Product Dimensions (CineMate II speaker arrays):** 3.3 x 7.8 x 5.1 inches
- **Product Dimensions (Acoustimass Module):** 14.5 x 8.8 x 19.1 inches
- **Product Dimensions (Interface module):** 2.38 x 5.5 x 2.63 inches
- **Item Weight:** 34.25 Pounds (total shipping weight)

- **Compatible Devices:** TVs: standard and high-definition
- **Control Method:** Remote
- **Power Source:** Corded Electric

## 8. WARRANTY AND SUPPORT

The Bose CineMate Series II Digital Home Theater Speaker System comes with a **Limited Warranty**. Please refer to the official owner's manual included in your package for complete warranty details, terms, and conditions.

For product support, technical assistance, or warranty claims, please visit the official Bose website or contact their customer service department. Keep your purchase receipt and product serial number handy for faster service.





## 9. PRODUCT VIDEO OVERVIEW



Watch this video for a brief overview of the Bose speaker system and its features.

Your browser does not support the video tag.

Video: A user review highlighting the features and sound quality of a Bose speaker system.

**Related Documents - 318842-110R**

 <p><b>CineMate® 15/10</b> Home Theater System</p> <p>Regelungsfunktion • Einstellungsanleitung • Sicherheitsanleitung Anleitung • Reparaturanleitung • Produktanwendung Benutzerhandbuch • Produktanwendung • Reparaturanleitung</p>	<p><a href="#">Bose CineMate 15/10 Home Theater System User Manual</a></p> <p>Comprehensive user manual for the Bose CineMate 15/10 home theater system, covering setup, connections, operation, troubleshooting, and maintenance. Includes safety instructions, regulatory information, and technical specifications.</p>
 <p><b>SURROUND SPEAKERS</b></p> <p>SETUP GUIDE</p>	<p><a href="#">Bose Surround Speakers Setup Guide with Bose Smart Soundbar</a></p> <p>Concise guide on setting up Bose Surround Speakers with Bose Smart Soundbar using the Bose Music app. Includes instructions for different Bose soundbar models and links to resources.</p>
 <p><b>SURROUND SPEAKERS</b></p>	<p><a href="#">Bose Surround Speakers User Manual &amp; Safety Information</a></p> <p>Comprehensive guide to setting up, using, and maintaining your Bose Surround Speakers, including important safety instructions, regulatory information, and troubleshooting tips.</p>
 <p><b>SURROUND SPEAKERS 700</b></p> <p>QUICK START GUIDE</p>	<p><a href="#">Bose Surround Speakers 700 Quick Start Guide</a></p> <p>Get started with your Bose Surround Speakers 700. This quick start guide explains how to set up your speakers, focusing on using the Bose Music app for compatible soundbars. Includes support information and model details.</p>

 BOSE BASS MODULE 700	<p><a href="#">Bose Bass Module 700 Installation Guide and Setup Instructions</a></p> <p>Get step-by-step installation instructions for the Bose Bass Module 700. This guide covers setup for compatible Bose soundbars including Soundbar 500, 700, Smart Soundbar 300, TV Speaker, and SoundTouch 300. Available in multiple languages.</p>
 BOSE BASS MODULE 700	<p><a href="#">Bose Bass Module 700: Quick Start Guide</a></p> <p>Learn how to set up your Bose Bass Module 700 with your Bose Smart Soundbar or Bose TV Speaker using the Bose Music app or a wired connection. Includes setup instructions and placement guidelines.</p>