

[Manuals.plus](#) /

› [PRS](#) /

› PRS SE One Electric Guitar User Manual

PRS SE1TS

PRS SE One Electric Guitar User Manual

Model: SE1TS

1. PRODUCT OVERVIEW

The PRS SE One Electric Guitar is designed for musicians seeking a straightforward, no-frills instrument. It features a single pickup, a single volume knob, and a classic single cutaway body shape, providing a direct and expressive playing experience.



Image 1.1: Full view of the PRS SE One Electric Guitar, showcasing its Tobacco Sunburst finish, single pickup, and single cutaway body.

2. KEY FEATURES

- **Single Pickup Configuration:** Simplifies tone shaping for a focused sound.
- **Single Volume Control:** Direct control over output level.

- **Single Cutaway Body:** Classic design offering comfortable upper fret access.
- **Mahogany Body:** Provides a warm, resonant tone with excellent sustain.
- **Wide Fat Neck Shape:** Offers a comfortable and substantial feel for various playing styles.
- **PRS Designed Stoptail Bridge:** Ensures stable tuning and enhanced sustain.

3. SETUP

3.1 Initial Inspection

Upon unboxing, carefully inspect the guitar for any visible damage that may have occurred during shipping. Check the finish, hardware, and neck for any irregularities.

3.2 Tuning

The guitar is equipped with standard tuning machines. Use a reliable electronic tuner to tune the guitar to standard EADGB_e (low to high). Turn the tuning pegs slowly to avoid over-tightening the strings.



Image 3.1: Close-up view of the PRS SE One headstock, showing the tuning machines and the "PRS SE ONE" logo.

3.3 String Installation (Optional)

If replacing strings, ensure you use nickel strings of appropriate gauge (e.g., .009-.042 or .010-.046). Thread the string through the stoptail bridge, pull it taut through the tuning post, and wind it neatly. Stretch new strings gently to help them settle and hold tune.

4. OPERATING INSTRUCTIONS

4.1 Connecting to an Amplifier

Insert a standard 1/4-inch instrument cable into the output jack located on the side of the guitar body. Connect the other end of the cable to the input of your guitar amplifier or audio interface.

4.2 Volume Control

The PRS SE One features a single volume knob. Rotate the knob clockwise to increase the output volume and counter-clockwise to decrease it. This control allows for dynamic adjustments during play.

4.3 Tone Shaping

While there is no dedicated tone knob, the guitar's single pickup and mahogany construction provide a rich, full-bodied tone. Experiment with your amplifier's tone controls and external effects pedals to achieve desired sounds.

5. MAINTENANCE

5.1 Cleaning

Regularly wipe down the guitar body, neck, and strings with a soft, lint-free cloth after each use to remove sweat and grime. For the finish, use a guitar-specific polish sparingly. Avoid abrasive cleaners.

5.2 Fretboard Care

The rosewood fretboard should be conditioned periodically (e.g., every 3-6 months) with a fretboard conditioner to prevent drying and cracking. Apply a small amount to a cloth and wipe onto the fretboard, then wipe off any excess.

5.3 String Replacement

Replace strings regularly, typically every 1-3 months depending on usage, to maintain optimal tone and playability. Refer to section 3.3 for string installation guidance.

5.4 Storage

Store the guitar in a stable environment, away from extreme temperature fluctuations and humidity. A guitar case or gig bag is recommended for protection.

6. TROUBLESHOOTING

- **No Sound:**
 - Check if the instrument cable is securely connected to both the guitar and the amplifier.
 - Ensure the amplifier is turned on and its volume is not at zero.
 - Verify the guitar's volume knob is turned up.
 - Test with a different cable or amplifier to rule out equipment issues.
- **Buzzing/Fretting Out:**
 - Check string action (height) at the bridge and nut.
 - Ensure the neck relief is correct. This may require professional adjustment.
 - Verify frets are level.
- **Poor Tuning Stability:**
 - Ensure strings are properly stretched and wound on tuning posts.
 - Check for worn or damaged strings and replace if necessary.
 - Lubricate the nut slots with graphite or a specialized lubricant.

7. SPECIFICATIONS

Feature	Detail
Model Number	SE1TS

Body Material	Mahogany
Top Material	Mahogany Wood
Back Material	Mahogany Wood
Neck Material Type	Mahogany
Fretboard Material	Rosewood
Number of Strings	6
Scale Length	25 inches
String Material	Nickel
Guitar Bridge System	Stop Tail (PRS designed stoptail)
Colour	Tobacco Sunburst
Product Dimensions	96.52 x 33.02 x 7.62 cm
Item Weight	3.18 kg (3 kg 180 g)

8. WARRANTY AND SUPPORT

For information regarding warranty coverage and terms for your PRS SE One Electric Guitar, please refer to the warranty card included with your purchase or visit the official PRS Guitars website. For technical support, service, or parts inquiries, please contact PRS Guitars customer service directly.

Manufacturer: PRS Guitars

Date First Available: 27 August 2012

Note: Keep your proof of purchase for warranty claims.

© 2024 PRS Guitars. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question