

Fujifilm INSTAX MINI 25

Fujifilm Instax MINI 25 Instant Film Camera User Manual

INTRODUCTION

The Fujifilm Instax MINI 25 is an instant film camera designed for capturing and printing credit card-sized images instantly. It features a high-quality Fujinon lens, a self-portrait mirror, and automatic exposure adjustment with a built-in intelligent flash. The camera is compact and easy to operate, making it suitable for various photographic moments.

SETUP

1. Battery Installation

The Instax MINI 25 requires two CR2 lithium batteries. Locate the battery compartment on the side of the camera. Open the compartment cover and insert the batteries, ensuring correct polarity as indicated inside the compartment. Close the cover securely.

2. Film Pack Loading

Open the film compartment door on the back of the camera. Align the yellow mark on the film pack with the yellow mark inside the camera's film compartment. Insert the film pack straight in, then close the compartment door. The camera will automatically eject the dark protective sheet. Do not open the film compartment door until all exposures in the pack are used.

3. Attaching the Close-up Lens

For close-up shots (up to 35cm), attach the included close-up lens to the camera's main lens. Ensure it is securely fastened. This accessory allows for enlarged subjects and detailed close-up photography.



Figure 1: Front view of the Fujifilm Instax MINI 25 camera with film partially ejected. This image shows the lens, flash, and power button.

OPERATING INSTRUCTIONS

1. Powering On/Off

Press the power button to turn the camera on. The lens will extend. To turn off the camera, press the power button again, and the lens will retract.

2. Taking a Picture

- **Framing:** Look through the viewfinder to compose your shot. For self-portraits, use the small mirror located next to the lens.
- **Exposure Adjustment:** The camera features simple exposure adjustment with an auto built-in intelligent flash. It automatically adjusts for low light conditions. Manual exposure compensation options may be available via specific buttons or modes.
- **Shutter Button:** Press the shutter button to take a picture. The camera has two shutter buttons, one for vertical and one for horizontal orientation, for ease of use.
- **Film Ejection:** After taking a picture, the film will automatically eject from the top slot. Allow the image to develop for a few minutes.



Figure 2: Close-up view of the Fujifilm Instax MINI 25 lens and surrounding controls, including the self-portrait mirror.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the camera body and lens. Do not use alcohol, thinner, or other solvents.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight and high temperatures.
- **Battery Care:** Remove batteries if the camera will not be used for an extended period to prevent leakage.

TROUBLESHOOTING

- **No Power:** Check if the batteries are inserted correctly and are not depleted. Replace with new CR2 batteries if necessary.
- **Film Not Ejecting:** Ensure a film pack is properly loaded and the camera is powered on. If the film counter shows 'S' or '0', the film pack might be empty or incorrectly inserted.
- **Dark or Overexposed Photos:** The camera has automatic exposure. Ensure the flash is not obstructed. For very bright or dark environments, the camera's automatic settings might have limitations.
- **Blurry Photos:** Hold the camera steady when taking a picture. Ensure the subject is within the recommended focus range (0.5m to infinity). When using the close-up lens, ensure the subject is within 35cm.

SPECIFICATIONS

Model Name	Instax Mini 25 Camera
Film Format Type	Instax Mini
Image Size	2.13" x 3.4" (credit card size)
Lens	Fujinon lens, 60mm
Focus Range	0.5m - infinity
Shutter Speed	Electronic Shutter 1/3 - 1/400 sec
Flash	Auto Flash in low light, auto adjust
Exposure Control	Automatic, with manual exposure compensation
Power Supply	2 x CR2 Lithium Metal batteries (included)
Dimensions (L x W x H)	4.41 x 1.99 x 4.76 inches
Item Weight	9.7 ounces (275 Grams)
Special Features	Auto Exposure, Built-in Flash, Self-portrait mirror, Close-up lens

WARRANTY AND SUPPORT

The Fujifilm Instax MINI 25 camera comes with a **1-year manufacturer's warranty**. For warranty claims, technical support, or service inquiries, please refer to the official Fujifilm support channels or contact your retailer. Keep your proof of purchase for warranty validation.

For additional information and resources, visit the official Fujifilm website: www.fujifilm.com