

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Acer](#) /
- > [Acer H223HQ 21.5-inch TFT Monitor User Manual](#)

Acer H223HQ

Acer H223HQ 21.5-inch TFT Monitor User Manual

Model: H223HQ

INTRODUCTION

This user manual provides comprehensive instructions for the Acer H223HQ 21.5-inch TFT Monitor. It covers essential information regarding product setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your display. Please read this manual thoroughly before using the monitor.



Figure 1: Front view of the Acer H223HQ monitor.

PACKAGE CONTENTS

Verify that all items listed below are present in your package. If any items are missing or damaged, please contact your retailer.

- Acer H223HQ 21.5-inch TFT Monitor
- Monitor Stand Base
- Power Cord
- VGA Cable
- DVI Cable
- User Manual (this document)

SETUP

1. Assembling the Monitor Stand

1. Carefully place the monitor face down on a soft, clean surface to prevent scratches.
2. Align the stand base with the stand neck.
3. Secure the base to the neck using the provided screw, typically located on the underside of the base. Tighten firmly.
4. Attach the assembled stand to the back of the monitor by aligning the tabs and pushing until it clicks into place or securing with screws if applicable.

2. Connecting Cables

Ensure your computer and monitor are powered off before making any connections.

- **Power Cable:** Connect one end of the power cord to the monitor's power input port and the other end to a grounded electrical outlet.
- **Video Cable (VGA or DVI):**
 - **VGA Connection:** Connect the VGA cable from your computer's VGA output port to the VGA input port on the monitor. Tighten the screws on the VGA connector.
 - **DVI Connection:** Connect the DVI cable from your computer's DVI output port to the DVI input port on the monitor. Tighten the screws on the DVI connector.



Figure 2: Rear view with connection ports.

3. Initial Power On

1. Power on your computer.
2. Press the power button on the monitor. The power indicator light should illuminate.
3. The monitor should automatically detect the input signal. If not, you may need to manually select the input source using the monitor's OSD menu.

OPERATING THE MONITOR

1. Monitor Controls

The control buttons are typically located on the bottom right bezel of the monitor. These buttons allow you to navigate the On-Screen Display (OSD) menu and adjust various settings.



Figure 3: Monitor with control buttons visible.

- **Power Button:** Turns the monitor on or off.
- **Menu Button:** Accesses the OSD menu.
- **Input Button:** Cycles through available input sources (VGA, DVI).
- **Auto Button:** Automatically adjusts image settings for optimal display (primarily for analog VGA input).
- **Navigation Buttons (Up/Down or Left/Right):** Used to navigate through OSD menu options and adjust values.

2. On-Screen Display (OSD) Menu

To access the OSD menu, press the **Menu** button. Use the navigation buttons to move between options and adjust settings. Press **Menu** again to exit or confirm selections.

Common OSD settings include:

- **Picture:** Brightness, Contrast, Sharpness, Aspect Ratio.
- **Color:** Color Temperature, sRGB, User Defined Color.
- **OSD:** OSD Language, OSD Timeout, OSD Position.
- **Management:** Input Select, DDC/CI, Auto Source.
- **Information:** Displays current resolution, refresh rate, and model name.

MAINTENANCE

1. Cleaning the Monitor

- Always unplug the monitor from the power outlet before cleaning.
- Use a soft, lint-free cloth lightly dampened with water or a specialized screen cleaner.
- Do not spray cleaner directly onto the screen. Apply it to the cloth first.
- Avoid using abrasive cleaners, waxes, or solvents as they can damage the screen or casing.
- Wipe the screen gently to remove dust and smudges. Clean the monitor casing with a dry, soft cloth.

2. Safety Precautions

- Do not block ventilation openings on the monitor.
- Do not place the monitor on an unstable cart, stand, or table.
- Do not expose the monitor to rain or moisture.
- Do not open the monitor casing. There are no user-serviceable parts inside. Refer all servicing to qualified service personnel.
- Unplug the monitor during lightning storms or when unused for long periods.

TROUBLESHOOTING

If you encounter issues with your monitor, refer to the following common troubleshooting steps before contacting support.

Problem	Possible Solution
No power	<ul style="list-style-type: none">• Ensure the power cord is securely connected to the monitor and a working electrical outlet.• Check if the power outlet is functioning by plugging in another device.• Press the monitor's power button.
No image on screen	<ul style="list-style-type: none">• Verify that the video cable (VGA or DVI) is securely connected to both the monitor and the computer.• Ensure the computer is powered on and not in sleep mode.• Press the "Input" button on the monitor to cycle through input sources (VGA, DVI) and select the correct one.• Try connecting the monitor to another computer or using a different video cable to rule out cable or computer issues.
Image is blurry or distorted	<ul style="list-style-type: none">• Ensure your computer's display resolution is set to the monitor's native resolution (1920 x 1080).• Adjust the "Auto" setting (for VGA) or "Clock" and "Phase" settings in the OSD menu.• Adjust Brightness, Contrast, and Sharpness settings in the OSD menu.
Colors are incorrect	<ul style="list-style-type: none">• Check the color settings in the OSD menu (e.g., Color Temperature, sRGB).• Ensure the video cable is not damaged or bent.

SPECIFICATIONS

The following are the technical specifications for the Acer H223HQ monitor:

Feature	Specification
Brand	Acer
Screen Size	21.5 Inches
Resolution	1920 x 1080
Aspect Ratio	16:9
Screen Surface Description	Glossy
Image Contrast Ratio	50000:1
Response Time	5 Milliseconds
Refresh Rate	200 Hz
Connectivity Technology	DVI, VGA

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or visit the official Acer support website. Keep your purchase receipt as proof of purchase for warranty claims.