

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Generic](#) /
- › [Vacuum Cleaner Attachment Kit User Manual](#)

Generic BCHBU16

Vacuum Cleaner Attachment Kit

USER MANUAL

1. Product Overview

This Vacuum Cleaner Attachment Kit provides a comprehensive set of tools designed to extend the versatility and reach of your vacuum cleaner. Featuring a 12-foot hose and various specialized attachments, this kit enables thorough cleaning in hard-to-reach areas, on different surfaces, and with improved efficiency.



Image 1.1: The complete Vacuum Cleaner Attachment Kit, showcasing the flexible 12-foot hose, two rigid extension wands, a narrow crevice tool for tight spaces, a soft dusting brush, an upholstery tool for fabrics, and a wider floor tool.

2. Package Contents

Please verify that all components are present in your package:

- 1 x 12-Foot Flexible Vacuum Hose with Angled Handle
- 2 x Extension Wands (rigid tubes)
- 1 x Crevice Tool
- 1 x Dusting Brush (round with bristles)
- 1 x Upholstery Tool
- 1 x Floor Tool

3. Compatibility

This attachment kit is designed for broad compatibility with various vacuum cleaner brands and models. It is confirmed to fit:

- **Panasonic:** MC5000 Series and MC6000 Series
- **Carpet Pro:** CPU-1QD, CPU1, CPU2, CPU2T, CPU-250, CPU-350, SCT-1.2, SCBP1, CPU-75, CPU-85T, CPU-1T, CPU75T, ZM-400 CP, SCC1, CPC-TT, CPCC1, CP500.2, CP-BWV, CPC-P, CPBU-1
- **Riccar and Simplicity Models**

The attachments are generally compatible with vacuum cleaners that accept standard 1.25-inch (32mm) diameter accessories. Please check your vacuum's hose or wand diameter for optimal fit.

4. Setup

To begin using your attachment kit:

1. **Connect the Hose:** Locate the main hose connection point on your vacuum cleaner. Insert the larger end of the 12-foot flexible hose firmly into this port until it is secure.
2. **Attach Wands (Optional):** For extended reach, connect one or both extension wands to the angled handle end of the flexible hose. Ensure they click or fit snugly into place.
3. **Attach Desired Tool:** Select the appropriate cleaning tool (crevice tool, dusting brush, upholstery tool, or floor tool) for your task. Attach it firmly to the end of the extension wand or directly to the angled handle of the flexible hose.
4. **Power On:** Turn on your vacuum cleaner according to its manufacturer's instructions.

5. Operating Instructions

Utilize the various attachments for specific cleaning needs:

- **12-Foot Flexible Hose:** Provides extended reach for cleaning high ceilings, drapes, under furniture, or inside vehicles without moving the main vacuum unit. The angled handle offers ergonomic use.
- **Extension Wands:** Use these to further extend the reach of the hose, ideal for cleaning ceiling corners, tall shelves, or reaching deep under appliances.
- **Crevice Tool:** This narrow, angled tool is perfect for cleaning tight spaces, such as between couch cushions, along baseboards, in car interiors, or around radiator fins.
- **Dusting Brush:** Features soft bristles for gentle cleaning of delicate surfaces like lampshades, blinds, electronics, picture frames, and intricate moldings. Use light pressure to avoid scratching.
- **Upholstery Tool:** Designed for cleaning fabric surfaces such as sofas, chairs, curtains, and car seats. Its wide, flat design helps to effectively remove dust and debris from textiles.
- **Floor Tool:** Suitable for cleaning hard floors or low-pile carpets. Glide the tool across the surface to pick up dirt and debris.

6. Maintenance and Care

Proper care will prolong the life of your attachment kit:

- **Cleaning Attachments:** After each use, wipe down the plastic attachments with a damp cloth to remove any accumulated dust or grime. For the dusting brush, gently remove any tangled hair or debris from the bristles.
- **Hose Care:** Avoid kinking or sharply bending the flexible hose, as this can cause damage. Store it in a coiled position.
- **Storage:** Store all components in a clean, dry place away from direct sunlight and extreme temperatures to prevent

material degradation.

- **Inspection:** Periodically inspect all parts for signs of wear, cracks, or blockages. Clear any obstructions in the hose or tools to maintain optimal suction.

7. Troubleshooting

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Loss of Suction	Hose or attachment blockage; loose connection; vacuum bag/canister full.	Check hose and attachments for obstructions and clear them. Ensure all connections are secure. Check and empty your vacuum's dust bag or canister.
Attachments do not fit securely	Incompatible vacuum hose/wand diameter; improper insertion.	Verify your vacuum's hose/wand diameter matches the kit's standard 1.25-inch (32mm) size. Ensure attachments are pushed firmly into place. Some connections may require a slight twist.
Hose is stiff/difficult to maneuver	New hose; cold environment.	New hoses may be stiff initially and will become more flexible with use. Allow the hose to warm up to room temperature if stored in a cold environment.

8. Specifications

- **Model Number:** BCHBU16
- **Product Dimensions:** 3 x 3 x 2 inches (packaging/collapsed)
- **Item Weight:** 3.52 ounces
- **Hose Length:** 12 feet
- **Manufacturer:** Generic
- **Batteries Required:** No

9. Warranty and Support

As a Generic product, specific warranty details may vary. Please refer to the retailer or seller from whom you purchased this product for information regarding warranty coverage, returns, or technical support. Keep your proof of purchase for any warranty claims.

For general inquiries or assistance with product usage, please contact the customer service department of the retailer.