

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [John Timberland](#) /

> John Timberland Organic Modern Zen Indoor Tabletop Water Fountain Instruction Manual

## John Timberland B002NTSGSO

# John Timberland Organic Modern Zen Indoor Tabletop Water Fountain

Model: B002NTSGSO

## INTRODUCTION

---

Thank you for purchasing the John Timberland Organic Modern Zen Indoor Tabletop Water Fountain. This fountain is designed to provide a soothing and calming ambiance to your home or office environment. Please read this manual carefully before assembly and operation to ensure safe and proper use of your product.




Image 1: The John Timberland Organic Modern Zen Indoor Tabletop Water Fountain displayed on a wooden surface, featuring its natural and organic design with water flowing down a textured column into a basin. An integrated LED light illuminates the water flow.

## SAFETY INFORMATION

---

- **Electrical Safety:** Always unplug the fountain from the electrical outlet before cleaning, maintenance, or when not in use. Ensure your power outlet matches the voltage requirements of the pump. Do not operate if the power cord or pump is damaged.
- **Water Safety:** Use only clean, distilled water to prevent mineral buildup. Do not allow the pump to run dry, as this can damage the motor. Keep the water level above the pump at all times during operation.
- **Placement:** Place the fountain on a flat, stable, and waterproof surface to prevent spills and damage. Keep away from electrical appliances and outlets.
- **Children and Pets:** Keep the fountain out of reach of children and pets to prevent accidents.
- **Indoor Use Only:** This fountain is designed for indoor use only. Do not expose to outdoor elements.

## PACKAGE CONTENTS

---

Please check to ensure all parts are included in your package:

- Fountain Base
- Fountain Top/Column
- Water Pump with Power Cord
- LED Light Assembly
- Decorative River Rocks
- Instruction Manual

## SETUP INSTRUCTIONS

---

1. **Unpack Components:** Carefully remove all components from the packaging and place them on a clean, flat surface.
2. **Position the Pump:** Place the water pump inside the fountain base. Ensure the pump's suction cups are firmly attached to the bottom of the basin.
3. **Connect Tubing:** Connect the plastic tubing from the fountain top/column to the outlet on the water pump. Ensure a snug fit to prevent leaks.
4. **Place Fountain Top:** Carefully place the fountain top/column onto the base, ensuring it is stable and the tubing is not kinked.
5. **Install LED Light:** Position the LED light assembly at the top of the fountain column, ensuring it is securely placed to illuminate the water flow. Connect the light's power cord to the designated connector, usually near the pump.



Image 2: A side view of the fountain, highlighting the placement of the adjustable LED light fixture at the top, designed to illuminate the cascading water.

6. **Add Water:** Fill the fountain base with clean, distilled water. The water level should be sufficient to completely submerge the pump, but not so high that it overflows when the fountain is running.
7. **Arrange Rocks:** Place the decorative river rocks into the basin around the fountain column.



Image 3: A close-up, top-down view of the fountain's basin, showing the decorative river rocks arranged around the base of the water column, enhancing the natural aesthetic.

8. **Connect to Power:** Plug the pump's power cord into a standard electrical outlet.

## OPERATING INSTRUCTIONS

---

### Starting the Fountain

Once plugged in, the pump will begin to circulate water, and the LED light will illuminate. It may take a few moments for the water to flow consistently through the column.



Image 4: A detailed view of the water cascading down the textured surface of the fountain's column, illuminated by the integrated LED light, creating a serene visual effect.

### **Adjusting Water Flow**

The pump typically has an adjustable flow rate switch. Locate this switch on the pump and slide it to increase or decrease the water flow to your desired level. Adjusting the flow can change the sound of the water.

### **Turning Off the Fountain**

To turn off the fountain, simply unplug the power cord from the electrical outlet.

Your browser does not support the video tag.

Video 1: An official product video demonstrating the John Timberland Organic Modern Zen Indoor Tabletop Water Fountain in operation, showcasing its water flow and illuminated effect. This video provides a visual guide to the fountain's aesthetic and function.

## **MAINTENANCE**

---

### **Water Level**

Check the water level daily. Due to evaporation, water levels will decrease. Always ensure the pump is fully

submerged to prevent damage. Refill with distilled water as needed.

## Cleaning the Fountain

To prevent mineral buildup and algae growth, clean the fountain regularly (at least once a month). Unplug the fountain, drain the water, and wipe down all surfaces with a soft cloth and mild soap. Rinse thoroughly with clean water. Do not use harsh chemicals or abrasive cleaners.

## Pump Care

Periodically clean the pump to ensure optimal performance. Disassemble the pump according to its instructions (usually involves removing the front cover and impeller). Clean any debris or mineral buildup from the impeller and its housing using a small brush. Reassemble the pump carefully.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Water not flowing or weak flow	Low water level, kinked tubing, dirty pump, airlock in pump.	Add water to cover the pump. Check tubing for kinks. Clean the pump. Unplug and replug the pump to reset.
Excessive splashing	Water flow too high, fountain not level.	Adjust pump flow rate to a lower setting. Ensure the fountain is on a level surface.
No light	Light bulb burnt out, loose connection, power issue.	Check light bulb and replace if necessary (ensure correct wattage). Verify all light connections are secure. Check power outlet.
Loud pump noise	Low water level, pump not properly submerged, debris in pump.	Ensure pump is fully submerged. Clean the pump of any debris.

## SPECIFICATIONS

- **Brand:** John Timberland
- **Model:** B002NTSGSO
- **Material:** Resin
- **Product Dimensions:** 8"L x 8"W x 10.25"H
- **Special Feature:** Lightweight, Integrated LED Light
- **Power:** Includes 4-watt light (specific bulb type may vary, refer to light assembly for details)
- **UPC:** 736101256298
- **Manufacturer:** Universal Lighting and Decor

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the manufacturer's website or contact their customer service department. Keep your purchase receipt for warranty claims.

**Manufacturer:** Universal Lighting and Decor

**Brand:** John Timberland

For further assistance, please visit the [John Timberland Store on Amazon](#).

