Vinturi V1071

Vinturi Deluxe Wine Aerator Instruction Manual

Model: V1071

Introduction

The Vinturi Deluxe Wine Aerator is designed to enhance the flavor and aroma of your wine instantly. By introducing the optimal amount of air, it allows the wine to breathe, softening tannins and releasing its full bouquet. This manual provides instructions for the proper setup, operation, and maintenance of your Vinturi aerator.

Product Components

Your Vinturi Deluxe Wine Aerator package includes the following items:

- Vinturi Aerator
- Presentation Tower (Stand)
- Drip-free Base
- Sediment Filter



Image: The Vinturi Deluxe Wine Aerator product box, illustrating the included components.

Setup

Follow these steps to assemble your Vinturi Deluxe Wine Aerator:

1. Place the presentation tower base on a stable, flat surface.
2. Insert the curved aerator stand into the designated slot on the base.
3. Place the Vinturi aerator securely into the top of the stand.
4. Insert the sediment filter into the top opening of the aerator.
5. Position the drip-free base beneath the aerator's spout on the main base to catch any drips.

Your browser does not support the video tag.

Video: Demonstrates the assembly and disassembly of the Vinturi Deluxe Wine Aerator and its components.



Image: Dimensions of the Vinturi Deluxe Wine Aerator assembled on its stand.

Operating Instructions

Using your Vinturi aerator is simple:

1. Ensure the aerator is clean and properly assembled on its stand.
2. Hold a wine glass directly beneath the aerator's spout.
3. Slowly pour wine from the bottle through the top opening of the Vinturi aerator.
4. Observe the wine as it flows through the aerator, mixing with air before entering your glass.
5. The aerator is designed to provide optimal aeration instantly, enhancing the wine's characteristics.

Your browser does not support the video tag.

Video: Shows the process of pouring wine through the Vinturi aerator into a glass.



Image: The Vinturi aerator in action, enhancing red wine as it is poured.

Cleaning and Maintenance

To ensure the longevity and performance of your Vinturi aerator, follow these cleaning guidelines:

- After each use, rinse the aerator thoroughly with warm water.
- For a deeper clean, disassemble the aerator and wash all components with mild soap and water.
- The material used is high-quality plastic that does not absorb odors or deteriorate over time.
- Allow all parts to air dry completely before reassembling or storing.
- Do not use abrasive cleaners or scrubbers, as these may scratch the surface.



Image: A detailed view of the Vinturi aerator, highlighting its design for easy cleaning.

Troubleshooting

If you encounter any issues with your Vinturi Deluxe Wine Aerator, consider the following:

- **Slow Pouring:** Ensure the aerator is clean and free of any sediment buildup. The sediment filter should also be clear.
- **No Aeration Sound:** A slight gurgling sound is normal during aeration. If absent, check for proper assembly and ensure wine is poured steadily.
- **Leaking:** Verify that all components are correctly assembled and seated firmly. The drip-free base is designed to catch minor drips.

For further assistance, please contact Vinturi customer support.

Specifications

Brand	Vinturi
Model Number	V1071
Material	Plastic
Special Feature	Instant wine aeration during pouring
Dimensions (H x W x D)	35 cm x 9.5 cm x 25 cm (13.78 in x 3.74 in x 9.84 in)
Weight	1.13 Pounds (approx. 0.51 kg)

Warranty and Support

For information regarding warranty coverage, product registration, or technical support, please refer to the official Vinturi website or contact their customer service department. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question