

[Manuals.plus](#) /

> [Nuvo](#) /

> Nuvo TP143 Monopoint Adapter for Low-Voltage Track Lighting Instruction Manual

Nuvo TP143

Nuvo TP143 Monopoint Adapter for Low-Voltage Track Lighting Instruction Manual

Model: TP143 | Brand: Nuvo

1. PRODUCT OVERVIEW

The Nuvo TP143 Monopoint Adapter is designed to individually mount a single track lighting head to a standard junction box. This adapter facilitates the integration of low-voltage track lighting fixtures into various indoor settings, providing a clean and direct power connection. It is suitable for dry locations only.



Image showing the black Nuvo TP143 Monopoint Adapter, a square-shaped component designed to connect a single track head to a junction box.

2. SAFETY INFORMATION

- **WARNING:** Always disconnect power at the circuit breaker before installation, servicing, or cleaning. Failure to do so may result in electric shock or serious injury.

- Consult a qualified electrician if you are unsure about wiring procedures or electrical codes.
- Ensure all electrical connections are secure and comply with local electrical codes and ordinances.
- This product is rated for **dry locations only**. Do not install in damp or wet environments.
- Do not exceed the maximum wattage or voltage ratings specified for the connected track head.

3. PACKAGE CONTENTS

- 1 x Nuvo TP143 Monopoint Adapter (Black)
- Mounting Hardware (screws, wire connectors)

4. SETUP AND INSTALLATION

Follow these steps to properly install your Nuvo TP143 Monopoint Adapter:

1. **Turn Off Power:** Locate the circuit breaker controlling the lighting circuit and turn off the power. Verify power is off using a voltage tester.
2. **Prepare Junction Box:** Remove the existing fixture or junction box cover. Ensure the junction box is securely mounted and accessible.
3. **Wire Connections:** Connect the adapter's wires to the corresponding household wires:
 - Connect the black wire from the adapter to the black (hot) wire from the junction box.
 - Connect the white wire from the adapter to the white (neutral) wire from the junction box.
 - Connect the green or bare copper ground wire from the adapter to the ground wire from the junction box.

Use the provided wire connectors and ensure all connections are tight and secure.

4. **Mount Adapter:** Carefully tuck the wires into the junction box. Align the adapter with the junction box screw holes and secure it using the provided mounting screws. Do not overtighten.
5. **Attach Track Head:** Refer to the specific instructions provided with your low-voltage track head for attaching it to the monopoint adapter. Ensure it is securely seated and properly connected.
6. **Restore Power:** Once installation is complete and all connections are checked, restore power at the circuit breaker.
7. **Test Lighting:** Turn on the light switch to test the functionality of your track lighting fixture.

5. OPERATING INSTRUCTIONS

The Nuvo TP143 Monopoint Adapter functions as a power conduit for your track lighting head. Once correctly installed, the operation of the connected light fixture is controlled by the wall switch or dimmer connected to the electrical circuit. There are no user-operable controls on the adapter itself.

6. MAINTENANCE

- **Cleaning:** Clean the adapter with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes, as these may damage the finish or electrical components.
- **Inspection:** Periodically inspect the adapter and its connections for any signs of wear, damage, or loose wiring. If any issues are found, turn off power immediately and consult a qualified electrician.

7. TROUBLESHOOTING

- **Light Not Turning On:**
 - Check if the power is on at the circuit breaker.
 - Verify that all wire connections are secure and correctly made.
 - Ensure the light bulb or track head itself is functioning correctly and is properly installed.
- **Flickering Light:**
 - Turn off power and check for any loose wire connections within the junction box or at the track head.

- Ensure the connected track head or bulb is compatible with the electrical system and not exceeding wattage limits.
- If the issue persists, consult a qualified electrician.

8. SPECIFICATIONS

Brand	Nuvo
Model Number	TP143
Color	Black
Material	Plastic
Style	120V Monopoint
Light Fixture Form	Track Light Head Adapter
Specific Uses	Track Lighting
Indoor/Outdoor Usage	Indoor (Dry Location Rated)
Power Source	Corded Electric
Voltage	120 Volts
Dimensions (L x W x H)	5" x 5" x 0.5"
Item Weight	0.01 Ounces
Warranty	1 Year Limited

9. WARRANTY INFORMATION

The Nuvo TP143 Monopoint Adapter is covered by a **1-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use and service. It does not cover damage resulting from improper installation, accident, misuse, abuse, or unauthorized modifications. For warranty claims or further details, please retain your proof of purchase and contact Nuvo customer support.

10. CUSTOMER SUPPORT

For technical assistance, troubleshooting, or inquiries regarding your Nuvo TP143 Monopoint Adapter, please visit the official Nuvo Lighting website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official website.

Nuvo Lighting Website: [Visit the Nuvo Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question