

- [Manuals.plus](#) /
- › [Nuvo](#) /
 - › Nuvo TH203 R30 Straight Cylinder Track Head Instruction Manual

Nuvo TH203

Nuvo TH203 R30 Straight Cylinder Track Head Instruction Manual

1. INTRODUCTION

This manual provides instructions for the safe installation, operation, and maintenance of your Nuvo TH203 R30 Straight Cylinder Track Head. Please read thoroughly before use to ensure proper functionality and safety.



Figure 1: Nuvo TH203 R30 Straight Cylinder Track Head in Black.

2. SAFETY INFORMATION

Always follow basic safety precautions when installing or working with electrical fixtures. Failure to do so may result in serious injury or property damage.

- **WARNING:** This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.
- Ensure power is turned off at the circuit breaker before installation or servicing.
- Consult a qualified electrician if you are unsure about any part of the installation process.
- Do not exceed the maximum wattage rating of 75 watts.

- Use only bulbs with an E26 base.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- One (1) Nuvo TH203 R30 Straight Cylinder Track Head

4. SPECIFICATIONS

Brand	Nuvo
Model Number	TH203
Style	PAR30LN Straight
Color	Black
Material	Glass, Metal
Product Dimensions	4.5"L x 9.5"W x 7"H
Wattage	75 watts (Max)
Voltage	120 Volts
Bulb Base	E26
Light Source Type	Incandescent (compatible with LED)
Certification	UL Listed

5. INSTALLATION

Important: Ensure power is OFF at the circuit breaker before proceeding with installation.

5.1 Mounting the Track Head

1. Align the conductor prongs on the track head's base with the slot in the track.
2. Pull down on the black plastic base cover (the cubic area that connects to the track) so it slides back.
3. While holding the sliding part back, insert the end of the track head into the track slot.
4. Rotate the track head 90 degrees to engage the conductors.
5. Release the black plastic base cover. The track head should now be securely attached to the track.

5.2 Bulb Installation

This track head is designed for E26 base bulbs, up to 75 watts. It is compatible with PAR30LN incandescent bulbs and many MR16 GU10 LED bulbs.

1. Gently pull the socket out of the track head housing.
2. Carefully screw the E26 base bulb into the socket. Do not overtighten.
3. Reinsert the socket/bulb assembly into the housing.
4. Secure the bulb in place using the provided ring clip. Note: If using certain LED bulbs, the flat glass lens may not be necessary or may interfere with fit. Omitting the glass lens can also aid in heat dissipation for LED bulbs.



Figure 2: Side view of the Nuvo TH203 Track Head, illustrating its cylindrical design.

6. OPERATION

Once installed and powered, the track head can be adjusted to direct light as needed.

- **Adjusting Angle:** Gently pivot the track head on its joint to achieve the desired lighting angle. Avoid excessive force to prevent damage.
- **Power Control:** The track head is controlled by the track lighting system's power switch, typically a wall switch.

7. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your track head.

- **Cleaning:** Ensure power is off. Wipe the exterior of the track head with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** Ensure power is off. Follow the bulb installation steps (Section 5.2) in reverse to remove the old bulb, then install a new one.

8. TROUBLESHOOTING

If you encounter issues with your track head, refer to the following common problems and solutions:

- **Light does not turn on:**
 - Check if the circuit breaker is on.
 - Verify the bulb is correctly installed and not burnt out.
 - Ensure the track head is properly seated and rotated 90 degrees in the track to make electrical contact.
- **Difficulty installing bulb:**
 - Ensure the socket is fully pulled out of the housing before attempting to screw in the bulb.

- Some bulbs, especially certain LED types, may have a tight fit. Ensure proper alignment and gentle pressure.
- **Track head feels loose or falls from track:**
 - Re-seat the track head by following the installation steps in Section 5.1, ensuring the 90-degree rotation and release of the plastic base cover.
 - Inspect the plastic base for any visible damage or fractures. If damaged, replacement may be necessary.

9. WARRANTY

This Nuvo TH203 R30 Straight Cylinder Track Head comes with a **1-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper installation, accident, misuse, abuse, or unauthorized modification. For warranty claims, please retain your proof of purchase and contact Nuvo customer support.

10. SUPPORT

For further assistance, technical support, or to inquire about replacement parts, please visit the official Nuvo Lighting website or contact their customer service department. Contact information can typically be found on the product packaging or the manufacturer's website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B002OMFVGU>

More documents and user manuals: <https://manuals.plus/>