

[Manuals.plus](#) /

› [Invicta](#) /

› [Invicta Men's 6621 Invicta II Chronograph Watch User Manual](#)

## Invicta 6621

# Invicta Men's 6621 Invicta II Chronograph Watch User Manual

Model: 6621

## 1. INTRODUCTION AND OVERVIEW

---

This manual provides essential information for the proper setup, operation, and maintenance of your Invicta Men's 6621 Invicta II Chronograph Watch. Please read these instructions carefully to ensure optimal performance and longevity of your timepiece.



The Invicta Men's 6621 Invicta II Chronograph Watch, showcasing its blue dial and two-tone stainless steel design on a wrist.

The Invicta 6621 is a robust chronograph watch featuring a stainless steel case, a blue dial with luminous hands, and a durable Flame Fusion crystal. It is powered by a Japanese quartz movement (VD53 Caliber) and offers 100 meters of water resistance, making it suitable for various water sports activities, excluding diving.

Your browser does not support the video tag.

Official product video showcasing the Invicta Men's 6621 II Collection Chronograph Watch, highlighting its design and features.

## 2. SETUP

---


### 2.1 Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch) to the second click position.
2. **Set the time:** Turn the crown to move the hour and minute hands to the desired time. Ensure you account for AM/PM if setting the date.
3. **Set the date:** Push the crown in one click to the first click position. Turn the crown to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this can damage the movement.
4. **Push in the crown:** Once the time and date are set, push the crown back into its normal position to start

the watch and ensure water resistance.

## 2.2 Adjusting the Stainless Steel Band

The stainless steel band is adjustable by adding or removing links. For precise adjustment, it is recommended to visit a professional watchmaker or jeweler. Improper adjustment can damage the band or clasp.



Detailed diagram illustrating the watch's dimensions, including dial diameter (45mm), band width (22mm), strap length (195mm), dial thickness (12.5mm), and overall weight (195 grams).

## 3. OPERATING INSTRUCTIONS

### 3.1 Chronograph Functions

Your Invicta 6621 watch features a chronograph for measuring elapsed time. The functional subdials include a 60-minute counter, a 60-second counter, and a 24-hour indicator.

# The Invicta Specialty Men 6621



Visual guide to the chronograph functions, including start/pause, adjust time/calendar, reset, chronograph hours, minutes, seconds, and calendar window.

- **Start/Pause:** Press the top pusher (button) to start the chronograph. Press it again to pause.
- **Reset:** While the chronograph is stopped (paused), press the bottom pusher to reset all chronograph hands to zero.

## 3.2 Water Resistance

The watch is water resistant to 100 meters (330 feet). This makes it suitable for recreational surfing, swimming, snorkeling, sailing, and water sports. **It is not suitable for diving.**

- Ensure the crown is fully pushed in before any contact with water.
- Do not operate the crown or pushers while the watch is wet or submerged.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.

## 4. MAINTENANCE

### 4.1 Cleaning

To maintain the appearance of your watch, wipe the case and band regularly with a soft, dry cloth. For stainless steel, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.

## 4.2 Battery Replacement

The watch uses an SR920SW battery. When the battery needs replacement, it is highly recommended to have it replaced by a qualified watch technician. This ensures proper sealing for water resistance and prevents damage to the movement.

## 4.3 Crystal Care

The Flame Fusion crystal is designed for durability. While resistant to scratches, it is not scratch-proof. Avoid direct impact and contact with sharp objects to preserve its clarity.

# 5. TROUBLESHOOTING

---

## 5.1 Watch Not Running

- Check if the crown is fully pushed in. If it's pulled out, the watch will not run.
- The battery may be depleted. Refer to section 4.2 for battery replacement.

## 5.2 Incorrect Time or Date

- Refer to section 2.1 for instructions on setting the time and date.
- Ensure the crown is securely pushed in after setting to prevent accidental changes.

## 5.3 Condensation Inside the Crystal

If you notice condensation inside the watch crystal, it indicates a potential breach in water resistance. Immediately take the watch to a professional watchmaker for inspection and repair to prevent further damage to the movement.

# 6. SPECIFICATIONS

---

Feature	Detail
Model Number	6621
Case Material	Stainless Steel
Case Diameter	45 mm
Case Thickness	12.5 mm (approx. 13 mm)
Band Material	Stainless Steel
Band Width	22 mm
Band Length	195 mm (approx. 10 inches)
Dial Color	Blue
Crystal Type	Flame Fusion

Feature	Detail
Movement Type	Japanese Quartz (VD53 Caliber)
Battery Type	SR920SW (included)
Water Resistance	100 meters (330 feet)
Watch Weight	195 grams (approx. 6.88 ounces)
Clasp Type	Fold-over clasp with double push-button safety
Additional Features	Chronograph (60min, 60sec, 24hr subdials), Luminous hands, Uni-directional stainless steel bezel

## 7. WARRANTY AND SUPPORT

---

### 7.1 Manufacturer's Warranty

Your Invicta watch is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration. Keep your proof of purchase for warranty claims.

### 7.2 Customer Support

For any questions, service, or support regarding your Invicta watch, please visit the official Invicta website or contact their customer service department. Contact information can typically be found on the warranty card or the brand's official website.

# Gift Ready Watch Box

Watch box may come in a **different color & style**



  
**INVICTA**

The Invicta watch presented in its gift-ready box, which may vary in color and style.