Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Balsam Hill 5021445

Balsam Hill 7.5 ft Unlit Classic Blue Spruce Artificial Christmas Tree Instruction Manual

Model: 5021445

1. Introduction

This manual provides detailed instructions for the assembly, care, and maintenance of your Balsam Hill 7.5 ft Unlit Classic Blue Spruce Artificial Christmas Tree. Designed for durability and a realistic appearance, this tree features over 2,960 tips and a sturdy metal stand. Please read all instructions carefully before beginning assembly.



Figure 1: The Balsam Hill 7.5 ft Unlit Classic Blue Spruce Artificial Christmas Tree.

2. What's in the Box

Your Balsam Hill artificial Christmas tree package includes the following components:

- Tree sections (typically 3-4 sections, labeled A, B, C, etc.)
- Premium metal tree stand with scratch-proof rubber feet
- Protective gloves for shaping branches
- Durable storage bag for off-season storage
- Instruction manual



Figure 2: Included accessories: tree stand, storage bag, and protective gloves.

3. Setup and Assembly

Follow these steps to assemble your artificial Christmas tree:

1. **Unfold the Tree Stand:** Place the metal tree stand on a flat, stable surface. Unfold the legs into an 'X' shape and

tighten the eye bolt to secure it.

2. **Insert Bottom Section:** Locate the bottom tree section (usually labeled 'A'). Carefully insert it into the tree stand. Ensure it is firmly seated.
3. **Fluff Bottom Section:** Wearing the provided protective gloves, begin to gently pull and spread out the branches of the bottom section. Work from the trunk outwards, shaping each branch to fill any gaps and create a full, natural appearance.
4. **Add Middle Sections:** Insert the next tree section (labeled 'B') into the top of the previous section. Repeat the fluffing process for this section. Continue with any remaining middle sections, working your way up the tree.
5. **Attach Top Section:** Finally, insert the top tree section into the last middle section. Fluff the branches of the top section, paying attention to the tree's peak.
6. **Final Shaping:** Step back and observe the tree from different angles. Adjust any branches as needed to achieve your desired fullness and shape. The first time shaping a 7.5 ft tree may take over an hour for optimal results.



Figure 3: Visual guide for assembly and initial shaping of the tree.



Figure 4: Hinged branches simplify the setup process.

Assembly Video

Your browser does not support the video tag.

Video 1: A detailed guide on assembling and fluffing a Balsam Hill artificial Christmas tree.

Product Overview and Fluffing Tips

Your browser does not support the video tag.

Video 2: An overview of the 7.5 ft unlit Blue Spruce, including tips for achieving a full look.

4. Operating (Fluffing and Shaping)

As an unlit tree, the primary 'operation' involves proper fluffing and shaping to achieve its intended full and realistic appearance. This process is crucial for maximizing the aesthetic appeal of your tree.

- **Branch by Branch:** Work on one branch at a time, starting from the bottom of the tree and moving upwards.
- **Spread Tips:** Separate and spread individual branch tips to fill any gaps. Aim for an outward-facing, natural look, similar to a peacock's tail.
- **Gentle Bending:** Gently bend the branch tips upwards to create the lush fullness of a real tree.
- **Layering:** Ensure branches are layered to create depth and avoid a flat appearance.



Figure 5: Close-up of the Classic Needles (PVC foliage) for a traditional look.

5. Maintenance

To ensure the longevity and beauty of your artificial Christmas tree, follow these maintenance guidelines:

- **Cleaning:** Dust the tree periodically with a soft cloth or duster. For deeper cleaning, use a damp cloth with mild soap and water, then allow to air dry completely.
- **Inspection:** Before and after each season, inspect the tree for any loose branches or damaged parts.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the foliage to fade. Store the tree in a cool, dry place away from direct sunlight.

6. Storage

Proper storage is essential for preserving your tree for many seasons:

- **Remove Ornaments:** Ensure all ornaments and decorations are removed from the tree.
- **Compress Branches:** Gently compress the branches upwards towards the trunk. If your tree came with ribbons for compression, use them. The less you compress the tree, the less work you will have next year.
- **Disassemble:** Carefully dismantle the tree sections from top to bottom.
- **Use Storage Bag:** Place each section into the provided durable storage bag. This protects the foliage from dust and damage.
- **Store in a Cool, Dry Place:** Store the bag in a cool, dry location, away from extreme temperatures and humidity.

7. Troubleshooting

Here are some common issues and their solutions for artificial Christmas trees:

- **Tree Not Looking Full:** This is almost always due to insufficient fluffing. Dedicate ample time to shaping each branch and tip. Refer to the 'Operating' section for detailed fluffing instructions.
- **Wobbly Tree:** Ensure the tree stand is fully unfolded and the eye bolt is securely tightened. Make sure the bottom tree section is fully inserted into the stand.

- **Branches Not Staying in Place:** The branches are designed to be flexible. If a branch is not holding its position, gently bend the wire within the branch to reshape it.

8. Specifications

Feature	Detail
Brand	Balsam Hill
Model Number	5021445
Product Dimensions	60"D x 60"W x 90"H (7.5 ft tall)
Color	Unlit (Green/Blue Spruce)
Material	Metal, Polyvinyl Chloride, Rubber
Item Weight	47 Pounds
Tip Count	2960+
Base Type	Stand
Built-in Light	No

9. Warranty and Support

For specific warranty information and customer support, please refer to the documentation included with your product or visit the official Balsam Hill website. Balsam Hill is committed to providing high-quality artificial Christmas trees and offers support for their products.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B002PF3P5U

More documents and user manuals: **https://manuals.plus/**