



[Manuals.plus](#) /

› [Comfort Zone](#) /

› Comfort Zone CZHTV9 Oscillating Halogen Radiant Space Heater Instruction Manual

## Comfort Zone CZHTV9

# Comfort Zone CZHTV9 Oscillating Halogen Radiant Space Heater

INSTRUCTION MANUAL

## Introduction

This manual provides essential information for the safe and efficient operation of your Comfort Zone CZHTV9 Oscillating Halogen Radiant Space Heater. Please read all instructions carefully before use and retain this manual for future reference. This heater is designed to deliver instant, focused warmth to small to medium-sized indoor spaces such as offices, bedrooms, and living rooms, utilizing radiant heating technology.



Image: The Comfort Zone CZHTV9 heater in operation, showing the radiant heat emitted from its halogen tubes.

## Important Safety Instructions

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. These include:

- Read all instructions before using this heater.

- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This heater includes an **Overheat Protection System** that automatically shuts off the unit if it reaches an unsafe temperature.
- A **Tip-Over Safety Switch** automatically turns the heater off if it is accidentally knocked over.
- The **Stay-Cool Molded Handle** and housing allow for safe transportation.
- Ensure the heater is placed on a stable, level surface.

## Intelligent Safety Features



OVERHEAT  
SENSOR



TIP-OVER  
AUTO OFF SWITCH



ETL  
APPROVED



STAY COOL  
MOLDED HANDLE



Image: Visual representation of the intelligent safety features integrated into the CZHTV9 heater.

### Product Overview

The Comfort Zone CZHTV9 heater features a slim, flat panel design with a top-mounted control knob for easy access. It

utilizes halogen quartz bulbs for radiant heat and includes an oscillating base for wider heat distribution.





Image: Front view of the CZHTV9 heater, highlighting its flat panel design and heating elements.

### Parts Identification:

- **Control Knob:** Located on top, used to select power modes and oscillation.
- **Halogen Heating Elements:** Visible behind the front grille, emit radiant heat.
- **Protective Grille:** Covers the heating elements.
- **Oscillating Base:** Allows the heater to rotate for wider heat distribution.
- **Molded Handle:** Integrated into the top for easy carrying.

## Onboard Controls with Oscillate



Power Mode  
Select



Oscillate



Image: Detailed view of the control knob, indicating power and oscillation settings.

### Setup

The Comfort Zone CZHTV9 heater requires no assembly and is ready for use directly out of the box.

1. **Unpack:** Carefully remove the heater from its packaging.
2. **Placement:** Place the heater on a firm, level surface. Ensure there is at least 3 feet (0.9 meters) of clear space from any walls, furniture, curtains, or other combustible materials. This heater is suitable for indoor use in small to medium rooms such as bedrooms, offices, or living rooms.
3. **Power Connection:** Plug the power cord directly into a 120V AC, 60Hz electrical outlet. Do not use extension cords or power strips.

# Ideal for Small to Medium Rooms

Quiet operation



LIVING  
ROOM



BEDROOM



OFFICE



KITCHEN



Image: The CZHTV9 heater positioned in a bedroom, demonstrating ideal placement in a small to medium room.

## Operating Instructions

The heater is controlled by a single rotary knob located on the top of the unit.

1. **Power On:** Rotate the control knob from the 'OFF' position to your desired setting.
2. **Heat Settings:**
  - **LOW (400W):** Activates the heater at a lower heat output.
  - **HIGH (800W):** Activates the heater at a higher heat output.
3. **Oscillation Function:**
  - **OSC LOW:** Activates the heater at 400W with a 70-degree oscillation.
  - **OSC HIGH:** Activates the heater at 800W with a 70-degree oscillation.
4. **Power Off:** To turn off the heater, rotate the control knob to the 'OFF' position.

# Instant & Powerful Heat

Choose between two convenient outputs: 400W / 800W



Image: The CZHTV9 heater demonstrating its instant heat and 70-degree oscillation capability.

## Maintenance

Regular maintenance ensures optimal performance and longevity of your heater.

1. **Cleaning:** Always unplug the heater from the power outlet and allow it to cool completely before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents. Ensure no water enters the

interior of the heater.

2. **Storage:** When not in use, store the heater in a cool, dry location. It is recommended to store it in its original packaging to protect it from dust and damage.

## Troubleshooting

If your heater is not operating correctly, please refer to the following common issues and solutions:

- **Heater does not turn on:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Check if the control knob is set to 'OFF'. Rotate it to 'LOW', 'HIGH', 'OSC LOW', or 'OSC HIGH'.
  - Verify that the tip-over switch has not been activated. If the heater was moved or tipped, place it upright on a stable surface.
  - The overheat protection system may have been activated. Unplug the heater, wait 10 minutes for it to cool down, then plug it back in.
- **Heater is on but not producing sufficient heat:**
  - Ensure the heater is set to 'HIGH' or 'OSC HIGH' for maximum heat output.
  - Radiant heaters provide direct, focused heat. Ensure you are within close proximity to the heater for optimal warmth.
  - Confirm the room size is appropriate for the heater's capacity (up to 150 sq. ft.).

If these steps do not resolve the issue, please contact customer support.

## Specifications

<b>Brand</b>	Comfort Zone
<b>Model Number</b>	CZHTV9
<b>Power Output</b>	400W / 800W
<b>Voltage</b>	120V
<b>Amperage</b>	6.66 Amps (at 800W)
<b>Heating Type</b>	Halogen Radiant
<b>Oscillation</b>	70 degrees
<b>Heating Coverage</b>	Up to 150 sq. ft.
<b>Product Dimensions (D x W x H)</b>	7.5" x 11" x 21.75"
<b>Item Weight</b>	3.87 pounds
<b>Safety Features</b>	Overheat Protection, Tip-Over Switch, Stay-Cool Housing





**Ready to use - no assembly required.**

Image: Dimensional view of the CZHTV9 heater, indicating its compact size.

**Warranty and Support**

---

This Comfort Zone CZHTV9 heater comes with a **1-year warranty against manufacturer defects** from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact Comfort Zone customer support. Contact information can typically be found on the product packaging or the official Comfort Zone website.

