

RCA DRC69705

RCA DRC69705 7-Inch Dual Screen Mobile DVD System User Manual

Model: DRC69705 | Brand: RCA

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your RCA DRC69705 7-Inch Dual Screen Mobile DVD System. Designed for portable entertainment, this system features a main DVD player unit and an additional screen, allowing multiple viewers to enjoy movies on the go. The system includes electronic skip protection for smooth playback, built-in stereo speakers, headphone jacks, and AV input/output jacks for versatile connectivity. Please read this manual thoroughly to ensure proper use and longevity of your device.

SETUP

Package Contents

- Main 7-inch DVD Player Unit
- Additional 7-inch Screen
- Remote Control
- Car Power Adapter
- AV Power Cable
- 2 Headrest Mounting Kits

Mounting the Screens

The system includes two headrest mounting kits for secure installation in a vehicle. Attach each screen to a headrest using the provided straps, ensuring they are firmly secured and positioned for optimal viewing by passengers. The straps are designed to fit around most standard car headrests.



Figure 1: The RCA DRC69705 Dual Screen Mobile DVD System, ready for in-car use.

Connecting the System

1. **Connect the Screens:** Use the supplied AV power cable to connect the main DVD player unit to the additional screen. This cable transmits both video and audio signals between the two displays.
2. **Power Connection:** Plug the car power adapter into the main DVD player unit's power input. Then, insert the car power adapter into your vehicle's 12V cigarette lighter socket. The system is designed to draw power from the vehicle's electrical system.
3. **External Device Connection (Optional):** The main unit features AV input and output jacks. These can be used to connect external video game systems, camcorders, or other AV products for display on the screens.

OPERATING YOUR DVD SYSTEM

Inserting a DVD

1. Gently press the OPEN button on the main DVD player unit to open the disc tray.
2. Carefully place a DVD disc onto the spindle with the label side facing up.
3. Close the disc tray firmly until it clicks into place. The system will automatically begin reading the disc.

Basic Controls

The main DVD player unit features integrated control buttons for essential functions:

- **Play/Pause:** Initiates or temporarily stops playback.

- **Stop:** Halts playback and returns to the disc's main menu or beginning.
- **Fast Forward/Rewind:** Skips through content quickly.
- **Skip (Next/Previous):** Jumps to the next or previous chapter/track.

A remote control is also included for convenient operation from a distance. Ensure a clear line of sight between the remote and the main unit's infrared receiver.

Using Headphones

Both the main DVD player unit and the additional screen are equipped with headphone jacks. This allows individual viewers to listen to audio privately without disturbing others. Simply plug standard 3.5mm headphones into the designated jack on either screen.

Adjusting Volume

Volume can be adjusted directly on the main DVD player unit using the dedicated volume controls. The remote control also provides volume adjustment functionality.

MAINTENANCE AND CARE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the units. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying. Do not use abrasive cleaners or solvents.
- **Disc Handling:** Always handle DVDs by their edges to avoid fingerprints and scratches. Store discs in their cases when not in use.
- **Storage:** When not in use, store the DVD system in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cables:** Ensure all cables are not kinked or pinched, which can lead to damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No Power	Car power adapter not properly connected or vehicle's 12V socket is not active.	Ensure the car power adapter is securely plugged into both the DVD unit and the vehicle's 12V socket. Check vehicle's ignition or fuse for the 12V socket.
No Picture/Sound	AV cable between units is loose or damaged; disc is dirty or damaged.	Check all cable connections. Clean the DVD disc with a soft cloth or try a different disc. Ensure volume is not muted or too low.
Disc Skipping	Disc is scratched or dirty; excessive vehicle vibration.	Clean the disc. While the system has electronic skip protection, extreme bumps may still cause skipping. Ensure the units are securely mounted.
Remote Control Not Working	Batteries are dead or incorrectly inserted; no clear line of sight.	Replace remote control batteries. Ensure batteries are inserted with correct polarity. Point the remote directly at the main unit's IR sensor.

PRODUCT SPECIFICATIONS




Feature	Specification
---------	---------------


Feature	Specification
Brand Name	RCA
Model Number	DRC69705
Screen Size	7 Inches (each screen)
Display Type	LCD
Media Type	DVD
Color	Black
Item Weight	0.01 ounces (Note: This weight seems unusually low and may refer to packaging or a component, not the full system.)
Product Dimensions	11.75 x 5.75 x 8 inches
Special Features	Dual screens, Built-in stereo speakers, Headphone jacks, AV input/output jacks, Electronic skip protection

WARRANTY AND SUPPORT

For information regarding warranty coverage, technical support, or service for your RCA DRC69705 Dual Screen Mobile DVD System, please refer to the warranty card included with your purchase or visit the official RCA support website. Keep your proof of purchase for any warranty claims.

Related Documents - DRC69705

	RingConn Gen 2 Smart Ring User Manual and Product Information Comprehensive guide to the RingConn Gen 2 Smart Ring, including safety instructions, package contents, product specifications, usage, maintenance, warranty information, and FCC compliance.
	RCA RTD205 Home Theater User's Guide Comprehensive user's guide for the RCA RTD205 Home Theater system, covering setup, operation, playback, player menus, troubleshooting, and specifications.
	LONPOO LP-099 DVD Player User Manual and Setup Guide Explore the LONPOO LP-099 DVD Player user manual for comprehensive instructions on setup, operation, troubleshooting, and maintenance. Learn about its Full-HD 1080p up-conversion, USB 2.0 input, multi-format playback (DVD, CD, VCD, MP3, JPEG), and remote control functions. This guide covers system connections, player settings, safety warnings, and specifications for optimal performance.



[The RCA Radiotron Manual - Technical Series R-10](#)

A technical manual from RCA Radiotron detailing the characteristics, application, and manufacturing of various radio tubes, including diodes, triodes, tetrodes, and pentodes. Features an index of tube types and technical specifications.



User manual
MODEL NO. LD42Y4A
Support@yehua.cn



[YEHUA LD42Y4A User Manual: Screen Mirroring for iOS and Android Devices](#)

Comprehensive user manual for the YEHUA LD42Y4A device, detailing setup, connection diagrams, iOS and Android screen mirroring instructions, app settings, and troubleshooting notes. Learn how to connect your smartphone or tablet to car displays and TVs.

Quick User Guide

Congratulations on your purchase of the DVD Player. Before using our player, it is recommended that you first discuss it carefully with the Product, Features, and Applications described in this manual. Due to slight variations in production, the illustrations, features, and descriptions in this manual might be slightly different from your product. Design and specifications are subject to change without notice.

Q&A

1. Does screen display and video appear after connected TV without any settings?
The DVD player supports both PAL and NTSC, and the player has a universal remote control. When the DVD player is connected to the TV, the screen will show a black screen. Please check the DVD player's remote control and the TV's remote control to see if they are working properly. If the screen is still black, please check the DVD player's remote control and the TV's remote control to see if they are working properly.
2. How to set up the DVD player?
Please refer to the Quick User Guide for more information.
3. Why the DVD player can't read the disc?
Please check the disc and the DVD player's remote control to see if they are working properly. If the screen is still black, please check the DVD player's remote control and the TV's remote control to see if they are working properly.
4. How to use the DVD player?
Please refer to the Quick User Guide for more information.
5. How to use the DVD player's remote control?
Please refer to the Quick User Guide for more information.
6. How to use the DVD player's remote control?
Please refer to the Quick User Guide for more information.
7. How to use the DVD player's remote control?
Please refer to the Quick User Guide for more information.
8. How to use the DVD player's remote control?
Please refer to the Quick User Guide for more information.
9. How to use the DVD player's remote control?
Please refer to the Quick User Guide for more information.
10. How to use the DVD player's remote control?
Please refer to the Quick User Guide for more information.

Need help? Email support@yehua.cn

Phone: +86 10 1234 5678

[Tojock DVD Player Quick User Guide and Warranty Information](#)

A comprehensive quick user guide for the Tojock DVD Player, offering setup advice, troubleshooting tips for common issues like screen display and disc reading, and detailed warranty activation and coverage information. Includes contact details for support.