

JOYOUNG CTS1068

Joyoung CTS1068 Automatic Hot Soy Milk Maker User Manual

Model: CTS1068

INTRODUCTION

Thank you for choosing the Joyoung CTS1068 Automatic Hot Soy Milk Maker. This appliance is designed to simplify the process of making fresh soy milk, as well as milk from other ingredients like rice, mung beans, and almonds. This manual provides essential information for safe operation, proper setup, usage, and maintenance to ensure optimal performance and longevity of your device. Please read these instructions thoroughly before first use and retain them for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. These include:

- Read all instructions before operating the appliance.
- Do not immerse the motor head in water or other liquids. Only the jug and filter components are washable.
- Ensure the voltage rating on the appliance matches your local power supply before connecting.
- Always unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Avoid contact with moving parts.
- Do not use attachments not recommended or sold by the manufacturer.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Extreme caution must be used when moving an appliance containing hot liquids.
- This appliance is for household use only.
- Keep hands and utensils out of the jug during operation to prevent injury and damage to the appliance.

PRODUCT COMPONENTS

The Joyoung CTS1068 Soy Milk Maker consists of several key parts designed for efficient operation and easy cleaning.



Figure 1: Assembled Joyoung CTS1068 Soy Milk Maker. This image shows the complete unit with the motor head securely latched onto the stainless steel jug.



Figure 2: Disassembled Joyoung CTS1068 Soy Milk Maker. The motor head, containing the grinding and heating elements, is separated from the stainless steel jug. This view highlights the internal components of the motor head and the jug's interior.



Figure 3: Joyoung CTS1068 Soy Milk Maker with accessories. The main unit is shown alongside the included strainer and a collection cup, which are used for filtering the finished soy milk.

The main components include:

- **Motor Head:** Contains the micro-computer control panel, grinding blades, and heating element.
- **Stainless Steel Jug:** The main container for ingredients and milk production, with a capacity of up to 1.5 liters.
- **Filter Cup:** Used to strain the soy milk after processing.
- **Power Cord:** Detachable power supply cord.

SETUP

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for storage or future transport.
2. **Initial Cleaning:** Before first use, wash the stainless steel jug, filter cup, and any other parts that come into contact with food using warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the motor head with a damp cloth; do not immerse it in water.
3. **Placement:** Place the soy milk maker on a stable, flat, and dry surface, away from heat sources and direct sunlight.
4. **Assembly:** Ensure the motor head is properly seated and latched onto the stainless steel jug. The appliance will not operate if not correctly assembled.

OPERATION

Follow these steps to make fresh soy milk:

1. **Prepare Ingredients:** For soy milk, soak 1/2 US cup of soybeans overnight (approximately 8-12 hours). Drain and rinse the soaked beans.
2. **Add Ingredients:** Place the prepared soybeans (or other ingredients like rice, mung beans, almonds) into the stainless steel jug.

- 3. **Add Water:** Fill the jug with water between the minimum and maximum fill lines indicated inside the jug. Do not overfill or underfill. The maximum capacity is 1.5 liters.
- 4. **Secure Motor Head:** Place the motor head onto the jug and ensure it is securely latched.
- 5. **Connect Power:** Plug the power cord into a grounded electrical outlet. The appliance will typically beep once, and indicator lights may illuminate.
- 6. **Select Program:** Press the desired function button on the control panel (e.g., 'Soy Milk' for soaked beans). The micro-computer control will automatically manage the grinding and heating cycles.
- 7. **Start Process:** The machine will begin operation. It will heat, grind, and cook the ingredients. The process is fully automatic.
- 8. **Completion:** Once the process is complete, the machine will typically beep multiple times and enter a standby mode. Unplug the appliance.
- 9. **Filter and Serve:** Carefully remove the motor head. Pour the contents of the jug through the provided filter cup into another container to separate the milk from the pulp (okara). Serve the fresh soy milk warm or chill for later consumption.

CLEANING AND MAINTENANCE

Regular cleaning ensures hygiene and extends the life of your appliance. It is recommended to clean the unit immediately after each use.

- 1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
- 2. **Separate Components:** Detach the motor head from the stainless steel jug.
- 3. **Clean Jug and Filter:** Wash the stainless steel jug and filter cup with warm, soapy water. Use a soft brush or sponge to remove any residue. The stainless steel interior is designed for easy cleaning. Rinse thoroughly and dry completely.
- 4. **Clean Motor Head:** Wipe the exterior of the motor head with a damp cloth. For the grinding and heating elements located underneath the motor head, use a damp cloth or a small brush to carefully remove any food particles. Do not immerse the motor head in water or rinse it under running water.
- 5. **Stubborn Residue:** If residue is sticky or difficult to remove, soak the jug and filter in warm water for a few minutes before scrubbing.
- 6. **Storage:** Ensure all parts are completely dry before reassembling or storing the appliance. Store in a dry, cool place.

TROUBLESHOOTING

If you encounter issues with your Joyoung CTS1068, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not start or power on.	Not plugged in; improper assembly; power outage.	Ensure power cord is securely plugged into a working outlet. Verify the motor head is correctly latched onto the jug. Check household circuit breaker.
Machine beeps continuously or unexpectedly.	Sensor error; jug not properly filled; motor head not secured.	Unplug and re-plug the unit. Ensure water level is between MIN and MAX lines. Re-seat the motor head firmly. If problem persists, contact support.

Problem	Possible Cause	Solution
Soy milk tastes 'raw' or is not fully cooked.	Insufficient cooking time; incorrect program selected; too many ingredients.	Ensure the correct program for soaked beans is selected. Do not exceed recommended ingredient quantities. Ensure beans are properly soaked.
Residue is difficult to clean.	Residue dried onto surfaces.	Clean the jug and filter immediately after use. If residue has dried, soak in warm water before scrubbing.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS


- **Model:** CTS1068
- **Brand:** JOYOUNG
- **Capacity:** Up to 1.5 Liters
- **Control:** Micro-computer controlled, fully automatic operation
- **Jug Material:** Stainless Steel
- **Item Weight:** Approximately 4 pounds (1.8 kg)
- **Package Dimensions:** 13.3 x 10.5 x 8.3 inches (33.8 x 26.7 x 21.1 cm)
- **ASIN:** B002RD0REM
- **First Available Date:** October 2, 2009




WARRANTY AND SUPPORT

For specific warranty information, please refer to the warranty card included with your purchase or contact the retailer where the product was acquired. Warranty terms typically cover manufacturing defects for a specified period from the date of purchase.

If you require technical assistance, have questions about operation, or need to report a defect, please contact Joyoung customer support through their official website or the contact information provided in your product documentation. Please have your model number (CTS1068) and purchase details ready when contacting support.

Related Documents - CTS1068

	<p>Joyoung DJ13E-ME Full-automatic Domestic Soy Milk Machine Operation Manual</p> <p>Comprehensive operation manual for the Joyoung DJ13E-ME Full-automatic Domestic Soy Milk Machine, covering safety precautions, parts identification, usage instructions, maintenance, and troubleshooting.</p>
---	---

	<p>Joyoung DJ12U-A903SG Fully Automatic Soy Milk Maker User Manual</p> <p>User manual for the Joyoung DJ12U-A903SG fully automatic soy milk maker. Provides detailed instructions on operation, safety, maintenance, troubleshooting, and recipes for various beverages and dishes. Features include automatic heating, no-filtering technology, and multiple functions.</p>
	<p>Joyoung DJ13E-D79 Full-Automatic Domestic Soy Milk Machine Operation Manual</p> <p>Comprehensive operation instructions and safety precautions for the Joyoung DJ13E-D79 Full-Automatic Domestic Soy Milk Machine. Learn about parts, usage, maintenance, and troubleshooting.</p>
	<p>Joyoung Hands-free Washing Blender L12-Y521-US01 Operation Manual</p> <p>Operation instruction manual for the Joyoung Hands-free Washing Blender (Model L12-Y521-US01), covering safety precautions, components, functions, usage instructions, cleaning, maintenance, and troubleshooting.</p>
	<p>Joyoung Soybean Milk Maker DJ12B-A11: Operation Instruction and User Guide</p> <p>Comprehensive operation instruction and user guide for the Joyoung Soybean Milk Maker DJ12B-A11, covering setup, usage, recipes, maintenance, and troubleshooting.</p>
	<p>Joyoung Unmanned Blender Soybean Milk Machine User Manual</p> <p>Comprehensive user manual for the Joyoung unmanned blender Soybean milk machine, covering product introduction, operation, recipes, cleaning, troubleshooting, safety guidelines, and specifications.</p>