



[Manuals.plus](#) /

> [Sauder](#) /

> Sauder Multimedia 7-Tier Storage Tower, Cinnamon Cherry Finish (Model 409110) Instruction Manual

## Sauder 409110

# Sauder Multimedia 7-Tier Storage Tower Instruction Manual

Model: 409110 | Brand: Sauder

## INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, and maintenance of your Sauder Multimedia 7-Tier Storage Tower. This unit is designed for organizing and storing various media such as DVDs, Blu-rays, and CDs, offering adjustable shelving for versatile use.

## SAFETY INFORMATION

---

- Refer to the instructions manual for important safety guidelines.
- Ensure all parts are securely fastened during assembly to prevent instability.
- Do not overload shelves beyond their stated weight capacity (7 lbs per adjustable shelf, 10 lbs for bottom, 5 lbs for top). Overloading can cause sagging or structural failure.
- For added stability, especially on uneven surfaces or in homes with children or pets, consider securing the unit to a wall using appropriate hardware (not included).
- This product is made of engineered wood. Avoid exposure to excessive humidity or moisture, which can affect material integrity.

## PACKAGE CONTENTS

---

Before beginning assembly, verify that all components are present and undamaged.

- Engineered wood panels (sides, top, bottom, shelves, back panel)
- Hardware kit (screws, cam locks, dowels, shelf pins, nails)
- Assembly instructions sheet

**Tools Required:** Hammer, Phillips head screwdriver.

## SETUP AND ASSEMBLY

---

Follow these steps carefully for proper assembly. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

### **Step 1: Unpack and Identify Parts**

Carefully remove all components from the packaging. Lay them out and identify each piece according to the included parts list.

### **Step 2: Assemble the Main Frame**

Connect the side panels to the top and bottom panels using cam locks and dowels. Ensure all connections are tight.

Your browser does not support the video tag.

Video: Official Sauder video demonstrating the proper technique for installing cam locks and dowels during furniture assembly, ensuring a secure connection between panels.




Image: The fully assembled Sauder Multimedia Storage Tower, showcasing its seven tiers and Cinnamon Cherry finish. The tower is shown in a living room setting, holding various media items.

### Step 3: Attach the Back Panel

Position the back panel onto the assembled frame. Secure it using the provided nails, ensuring it is flush with the edges.

Your browser does not support the video tag.

Video: Official Sauder video demonstrating the process of attaching the back panel to the storage tower using nails. This step ensures structural integrity and provides a finished look.

#### **Step 4: Install Adjustable Shelves**

Insert the shelf pins into the desired holes on the side panels. Place the adjustable shelves onto these pins. The unit features multiple pre-drilled holes for flexible shelf placement.



Image: A detailed view of the adjustable shelves within the storage tower, illustrating how media items like CDs and DVDs can be organized. The shelf pins are visible, allowing for customization of shelf height.



Image: A close-up of the top section of the storage tower, highlighting the cam lock covers and the smooth, curved edge of the top panel. This shows the finished appearance of the unit.

## OPERATING INSTRUCTIONS

---

### Adjusting Shelf Height

To adjust a shelf, remove all items from it. Carefully lift the shelf off its pins, remove the pins, and reinsert them into the desired holes. Then, place the shelf back onto the pins. Ensure pins are fully seated for stability.

### Capacity

The unit can hold approximately 280 DVDs or 426 CDs. The number of items per shelf will vary based on their size and the chosen shelf spacing.



Image: The storage tower filled with a variety of media, demonstrating its capacity for DVDs and CDs. The image shows how different media types can be arranged on the adjustable shelves.

## MAINTENANCE

---

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth to prevent buildup.
- **Humidity Control:** Maintain a stable room temperature and humidity level to preserve the engineered wood.
- **Inspection:** Periodically check all hardware connections to ensure they remain tight. Tighten screws as needed.

## TROUBLESHOOTING

---

### Shelves are sagging

- **Cause:** Overloading or prolonged exposure to humidity.
- **Solution:** Reduce the weight on the shelf. If sagging persists, remove items, flip the shelf over, and redistribute weight more evenly. Ensure the unit is not in a high-humidity environment.

## Unit feels unstable

- **Cause:** Loose connections or uneven flooring.
- **Solution:** Re-tighten all cam locks and screws. Ensure the unit is placed on a level surface. Consider using shims if the floor is uneven. For maximum stability, use wall anchor kits (sold separately).

## Back panel is loose

- **Cause:** Nails have come loose.
- **Solution:** Re-secure the back panel with additional nails if necessary. Ensure items are not pushing against the back panel from inside the unit.

## SPECIFICATIONS

| Feature                | Detail   |
|------------------------|--|
| Model Number           | 409110   |
| Brand                  | Sauder   |
| Dimensions (L x W x H) | 32.44" x 9.41" x 45.35" (82.4 cm x 23.9 cm x 115.2 cm) |
| Material               | Engineered Wood  |
| Finish                 | Cinnamon Cherry  |
| Number of Shelves      | 7 (6 adjustable)                                       |
| Media Capacity         | Approx. 280 DVDs or 426 CDs                            |
| Mounting Type          | Freestanding   |
| Assembly Required      | Yes  |



Image: A technical diagram illustrating the precise dimensions of the storage tower, including width, height, and depth, along with shelf depth measurements.

## WARRANTY INFORMATION

---

This product is covered by a **5-year parts warranty** from the manufacturer, Sauder. Please retain your proof of purchase for warranty claims.

## SUPPORT

---

For further assistance, missing parts, or warranty inquiries, please contact Sauder customer service. Refer to the contact information provided in your product packaging or visit the official Sauder website.

**Online Resources:** You may find additional assembly tips and product information on the Sauder website or by searching for "Sauder Multimedia Storage Tower 409110 assembly" online.