

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Whitmor](#) /

> [Whitmor Extra-Wide Clothes Closet User Manual](#)

Whitmor 6822-167-B

Whitmor Extra-Wide Clothes Closet User Manual

Model: 6822-167-B

INTRODUCTION

The Whitmor Extra-Wide Clothes Closet provides an efficient and organized storage solution for your clothing. Designed to protect garments from dust, dirt, and moisture, this portable closet is suitable for various spaces such as bedrooms, laundry rooms, or garages. Its sturdy construction and convenient features make it an ideal addition for seasonal clothing storage or as an extension to existing closet space.



Figure 1: Assembled Whitmor Extra-Wide Clothes Closet with white cover.

SAFETY INFORMATION

- Ensure all connections are securely fastened during assembly to prevent instability.
- Do not exceed the maximum recommended load of 50 pounds on the hanging rod.
- Keep the closet away from open flames or excessive heat sources.

- Supervise children during assembly and keep small parts out of their reach.
- Avoid placing heavy objects on top of the closet.

PARTS LIST

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact Whitmor customer service.

Part	Description	Quantity
A	Long Poles	X
B	Short Poles	X
C	Connectors (various types)	X
D	Hanging Rod	1
E	Fabric Cover	1

Note: The exact quantity of poles and connectors will vary based on the specific design of your model. Refer to the diagram in your packaging for precise counts.

SETUP AND ASSEMBLY

Assembly is recommended for two people to ensure stability and ease of construction. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Identify each part according to the parts list.
2. **Assemble Base Frame:** Connect the appropriate poles and connectors to form the rectangular base of the closet. Ensure all poles are fully inserted into the connectors for a secure fit.
3. **Construct Vertical Supports:** Attach the vertical poles to the base frame using the designated connectors. Ensure they stand upright and are stable.
4. **Install Top Frame:** Connect the remaining poles and connectors to form the top rectangular frame. Carefully lift and attach this top frame to the vertical supports.
5. **Insert Hanging Rod:** Place the hanging rod into the designated slots or hooks on the top frame. Ensure it is securely seated.




Figure 2: The sturdy metal frame of the clothes closet before the cover is applied.

6. **Apply Fabric Cover:** Carefully drape the fabric cover over the assembled frame. Ensure the cover is aligned correctly, with the clear window and zipper facing the front.
7. **Secure Cover:** Pull the cover down over the frame, ensuring it fits snugly around all corners and edges. Zip up the front closure.



Figure 3: The clothes closet with its fabric cover, showing garments through the clear window.

Note on Videos: No official seller videos demonstrating assembly or setup were available for this product. Customer-submitted videos were reviewed but are not included in this manual to maintain an informational tone and ensure content accuracy.

OPERATING INSTRUCTIONS

To use your Whitmor Extra-Wide Clothes Closet:

- **Accessing Contents:** Unzip the front panel to open the closet. The dual zippers allow for easy access to either side.
- **Hanging Clothes:** Utilize the integrated hanging rod to store garments on hangers. Distribute weight evenly across the rod to maintain stability.
- **Viewing Contents:** The clear window allows for easy identification of stored items without needing to open the closet.
- **Protecting Garments:** Keep the front panel zipped closed when not in use to protect clothes from dust, dirt, and moisture.



Figure 4: The clothes closet with its front panel unzipped, providing full access to the hanging garments.

MAINTENANCE

Proper care will extend the life of your clothes closet:

- **Cleaning:** Wipe the fabric cover with a damp cloth to remove dust or spills. Towel dry immediately. Do not use harsh chemicals or abrasive cleaners.
- **Frame Inspection:** Periodically check all pole connections and connectors to ensure they remain secure. Re-insert any loose poles firmly.
- **Zipper Care:** Keep zippers clean and free of debris. If a zipper becomes stiff, a small amount of zipper lubricant or wax can be applied.
- **Storage:** If disassembling for storage, ensure the fabric cover is clean and dry before folding to prevent mildew. Store components in a dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Difficulty zipping the cover	Cover not properly aligned or frame not fully assembled.	Ensure the fabric cover is evenly draped over the frame. Verify all poles are fully inserted into connectors, making the frame rigid.
Fabric tearing near poles or zippers	Excessive force during assembly or overstretching the cover.	Handle the fabric cover carefully. Ensure the frame is correctly assembled and rigid before attempting to pull the cover taut. Avoid overfilling the closet.
Frame feels wobbly or unstable	Poles not fully inserted into connectors or connectors are damaged.	Press firmly on all pole connections to ensure they are fully seated. Inspect connectors for cracks or damage; contact customer service for replacements if needed.
Hanging rod sags or breaks	Exceeding the maximum weight capacity.	Reduce the amount of clothing on the rod. Distribute weight evenly. The maximum recommended load is 50 pounds.

SPECIFICATIONS

Feature	Detail
Model Number	6822-167-B
Dimensions (L x W x H)	60 x 19.5 x 64 inches (152.4 x 49.5 x 162.5 cm)
Item Weight	10.21 pounds
Material	PP Non-Woven fabric, Polyvinyl Chloride
Color	White & Clear
Maximum Recommended Load	50 Pounds
Included Components	Closet and cover



Figure 5: Dimensional overview of the Whitmor Extra-Wide Clothes Closet.

WARRANTY AND SUPPORT

Warranty: The manufacturer's warranty information is not explicitly detailed in the product specifications. For specific warranty terms and conditions, please refer to the documentation included with your purchase or contact Whitmor customer service directly.

Customer Support: For assistance with assembly, missing parts, or any other product-related inquiries, please contact Whitmor customer service. Contact information can typically be found on the product packaging or on the official Whitmor website. When contacting support, please have your model number (6822-167-B) and purchase details ready. You may also find additional resources and frequently asked questions on the [Whitmor Store on Amazon](#).