Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Schick P-20

Schick Proline Blade P-20 Instruction Manual

Model: P-20

Introduction

Thank you for choosing the Schick Proline Blade P-20. These high-quality replacement blades are designed for commercial use, providing a precise and efficient shaving experience. This manual provides essential information for the safe and effective use, maintenance, and storage of your blades.

Each pack contains 20 individual blades, ensuring a long-lasting supply for professional or personal use.

Product Overview



Image: Packaging for Schick Proline Blade P-20, containing 20 replacement blades.

The Schick Proline Blade P-20 comes in a compact, protective package designed for easy storage and access. Each blade is crafted for durability and sharpness, suitable for various shaving needs.

Setup and Installation

These blades are designed for use with compatible professional or personal razors. Always handle blades with extreme care to prevent injury.

1. **Preparation:** Ensure your hands are clean and dry before handling the blade.
2. **Unpackaging:** Carefully remove one blade from its protective wrapping. Avoid touching the sharp edges.
3. **Insertion:** Following the instructions specific to your razor handle, carefully insert the new blade into the blade holder. Ensure it is securely seated and aligned.
4. **Disposal of Old Blade:** Immediately and safely dispose of the used blade in a designated blade disposal container.

Operating Instructions

For optimal performance and safety, follow these guidelines when using the Schick Proline Blade P-20:

- **Skin Preparation:** Always prepare the skin by washing it with warm water and applying a suitable shaving cream or gel. This softens the hair and lubricates the skin.

- **Shaving Technique:** Hold the razor at a comfortable angle. Shave with light, short strokes in the direction of hair growth. Avoid applying excessive pressure, as the blade is designed to cut efficiently with minimal force.
- **Rinsing:** Rinse the blade frequently under running water during shaving to remove accumulated hair and shaving cream.
- **Post-Shave Care:** After shaving, rinse the skin with cool water and apply an aftershave balm or moisturizer to soothe and hydrate the skin.
- **Blade Replacement:** Replace the blade as soon as you notice any dullness, pulling, or discomfort during shaving. A fresh blade ensures a smooth and safe shave.

Care and Maintenance

Proper care extends the life of your blades and ensures hygienic use:

- **Cleaning:** After each use, rinse the blade thoroughly under running water to remove all hair and shaving residue. Do not wipe the blade, as this can dull it and pose a risk of injury.
- **Drying:** Allow the blade to air dry completely before storing.
- **Storage:** Store unused blades in their original packaging in a dry, safe place, away from children and pets. Store the razor with the blade in a dry, well-ventilated area.

Troubleshooting

Problem	Possible Cause	Solution
Blade feels dull or pulls hair.	Blade is worn out or clogged.	Replace the blade with a new one. Ensure proper rinsing during use.
Skin irritation or nicks after shaving.	Dull blade, improper technique, or insufficient skin preparation.	Ensure blade is sharp. Use light strokes. Prepare skin with warm water and shaving cream. Shave in the direction of hair growth.
Blade not fitting securely in razor.	Incorrect blade type or improper insertion.	Verify that the blade is compatible with your razor handle. Re-insert the blade carefully, ensuring it clicks into place if applicable.

Product Specifications

Brand: Schick

Model: P-20

Blade Type: Proline Blade

Quantity per Pack: 20 sheets

Package Dimensions: 7.8 x 2.9 x 2.2 cm

Item Weight: 30 Grams

Recommended Age Range: Adult

Suitable Skin Type: All Skin

Warranty and Support

Schick products are manufactured to high-quality standards. For specific warranty information or support inquiries regarding your Schick Proline Blade P-20, please refer to the official Schick website or contact their customer service directly.

You can also visit the official Schick Store on Amazon for more product information and support resources.

© 2025 Schick. All rights reserved.
This manual is for informational purposes only. Always exercise caution when handling sharp blades.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B002UNACQM

More documents and user manuals: **https://manuals.plus/**