

[Manuals.plus](#) /

› [Smart Design](#) /

› Smart Design Deluxe Mesh Over The Door Pop Up Hamper (Model 3519114) Instruction Manual

Smart Design 3519114

Smart Design Deluxe Mesh Over The Door Pop Up Hamper

Model: 3519114 | Brand: Smart Design

1. INTRODUCTION AND OVERVIEW

The Smart Design Deluxe Mesh Over The Door Pop Up Hamper is a versatile and space-saving solution for organizing laundry and other household items. Constructed from breathable VentilAir mesh material, it features an adjustable strap and a convenient bottom zipper for easy unloading. Its collapsible design allows for compact storage when not in use, making it ideal for small spaces such as dorm rooms, apartments, or laundry rooms.





Image 1.1: Front view of the Smart Design Deluxe Mesh Over The Door Pop Up Hamper. This image shows the hamper in its expanded, ready-to-use state, highlighting its mesh construction and overall shape.

2. PRODUCT FEATURES

- **VentilAir Mesh Material:** The hamper is made from a breathable mesh fabric that promotes air circulation, helping to reduce odors from dirty laundry.
- **Over-the-Door Design:** Equipped with an adjustable strap and a sturdy hook, the hamper can be easily hung over most standard doors, maximizing floor space.



Image 2.1: The mesh hamper shown hanging over a white door, partially filled with white laundry, demonstrating its primary use and space-saving capability.

- **Adjustable Strap:** The integrated strap allows for height adjustment, ensuring the hamper hangs at an optimal level for various door heights and user preferences.



Image 2.2: A detailed view of the adjustable strap and the over-the-door hook, illustrating how the hamper is secured and its height can be modified.

- **Easy Unloading Zipper:** A zipper located at the bottom of the hamper allows for quick and effortless emptying of contents directly into a laundry basket or machine.

Easy unloading
zipper



Adjustable Strap
& hook for hanging

Image 2.3: This image focuses on the bottom zipper of the hamper, showing it partially open with clothes being released, demonstrating the easy unloading feature.

- **Collapsible Design:** The hamper can be folded flat for convenient storage when not in use, saving valuable space.
- **Multi-purpose Use:** While ideal for laundry, its open mesh design also makes it suitable for storing toys, sports equipment, or other bulky items.

Great for storage



Image 2.4: The hamper is shown filled with sports balls, illustrating its versatility beyond just laundry storage.

3. SETUP INSTRUCTIONS

1. **Unpack the Hamper:** Carefully remove the hamper from its packaging. It may be folded flat.
2. **Allow to Pop Up:** The hamper is designed to pop open automatically. Gently twist and release the frame if it remains folded.
3. **Attach the Hook:** Slide the provided over-the-door hook onto the top edge of your desired door.
4. **Hang the Hamper:** Attach the adjustable strap of the hamper to the hook.
5. **Adjust Height:** Use the buckle on the strap to adjust the hamper's height to your preferred level, ensuring it clears the floor and allows the door to close properly.

Video 3.1: Official product video demonstrating the setup and features of the Smart Design Deluxe Mesh Over The Door Pop Up Hamper, including its pop-up action and hanging mechanism.

4. OPERATING INSTRUCTIONS

1. **Loading Laundry:** Place dirty clothes or other items into the large opening at the top of the hamper. Ensure not to exceed the maximum capacity of 3 loads to prevent strain on the hanging mechanism.
2. **Unloading Contents:** When ready to empty, simply unzip the bottom zipper. The contents will fall out directly, making transfer to a laundry basket or washing machine easy.

5. MAINTENANCE

- **Cleaning:** Wipe the mesh material with a damp cloth and mild soap. Allow to air dry completely before folding or reusing. Do not machine wash.
- **Storage:** When not in use, the hamper can be collapsed flat for compact storage.

6. TROUBLESHOOTING

- **Hamper Not Staying Open:** Ensure the internal frame is fully expanded. Gently twist the frame to help it retain its shape.
- **Door Not Closing Properly:** Adjust the height of the hamper using the adjustable strap to ensure it does not interfere with the door frame or floor.
- **Hamper Sagging:** Avoid overfilling the hamper beyond its recommended capacity (approximately 3 loads) to prevent sagging and potential damage to the material or hook.

7. SPECIFICATIONS

Product Dimensions	16"L x 16"W x 32"H
Material	Polyester (VentilAir Mesh)
Color	White
Capacity	Up to 3 loads of laundry
Mounting Type	Over the Door (Wall Mount also possible with appropriate hardware, not included)
Item Weight	7 ounces





Image 7.1: A visual representation of the hamper's dimensions, indicating its height and width for easy reference.

8. WARRANTY & SUPPORT

This Smart Design Deluxe Mesh Over The Door Pop Up Hamper comes with a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. For warranty claims, product questions, or concerns, please contact Smart Design customer support through their official website or the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question