

Hasbro 94349

Hasbro FurReal Newborn Parrot Model 94349 Instruction Manual

Model: 94349 (C-022G)

INTRODUCTION

Thank you for choosing the Hasbro FurReal Newborn Parrot. This electronic pet is designed to provide interactive companionship through touch and sound. This manual provides essential information for the safe and proper use, setup, operation, and maintenance of your new pet.

SAFETY INFORMATION

- **Age Recommendation:** This product is suitable for children aged 4 to 12 years (48-144 months).
- **Battery Safety:**
 - Always use fresh batteries of the recommended type and size.
 - Do not mix old and new batteries, or different types of batteries.
 - Insert batteries with correct polarity (+ and -).
 - Remove exhausted batteries promptly.
 - Remove batteries if the product is not used for an extended period.
 - Do not dispose of batteries in fire; they may leak or explode.
 - Keep batteries out of reach of small children.
- **Choking Hazard:** Small parts may be generated. Not for children under 3 years.
- **Cleaning:** Refer to the Maintenance section for proper cleaning instructions.

PACKAGE CONTENTS

Please ensure all items are present in the package:

- 1 x FurReal Newborn Parrot (Green/Orange)
- 1 x Feeding Bottle (may be attached to packaging)

- 1 x Instruction Manual
- 3 x AAA Batteries (pre-installed or included separately)

SETUP

Battery Installation

Your FurReal Newborn Parrot requires 3 AAA batteries. These are typically included with the product. Follow these steps to install or replace batteries:

1. Locate the battery compartment on the underside of the parrot.
2. Using a Phillips head screwdriver (not included), loosen the screw on the battery compartment cover.
3. Remove the cover.
4. Insert 3 new AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
5. Replace the battery compartment cover and tighten the screw securely.



Image: The FurReal Newborn Parrot. The battery compartment is located on the underside of the toy.

OPERATING INSTRUCTIONS

Your FurReal Newborn Parrot is designed to respond to your touch and interaction. Here's how to engage with your pet:

- **Activation:** Once batteries are installed, locate the ON/OFF switch (usually near the battery compartment) and slide it to the 'ON' position.
- **Petting:** Gently pet the parrot's head or back. It may respond with chirps, movements, or other sounds.
- **Feeding:** Use the included feeding bottle. Bring the bottle to the parrot's beak, and it may make feeding sounds or movements.

- **Interaction:** Continue to interact with your parrot to discover all its unique responses and sounds.

MAINTENANCE

Cleaning

To keep your FurReal Newborn Parrot clean:

- Wipe the surface with a slightly damp cloth.
- Do not immerse the toy in water or use harsh cleaning agents.
- Allow the toy to air dry completely before storage or further use.

Storage

When not in use for extended periods:

- Turn the parrot OFF.
- Remove the batteries to prevent leakage and damage.
- Store the toy in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

If your FurReal Newborn Parrot is not functioning as expected, please refer to the following common issues and solutions:

Problem	Solution
Parrot does not respond or makes no sound.	Ensure the ON/OFF switch is in the 'ON' position. Check battery installation for correct polarity. Replace with fresh AAA batteries.
Parrot makes unusual or distorted sounds.	Batteries may be low. Replace with fresh AAA batteries.

SPECIFICATIONS

- **Brand:** Hasbro
- **Model Name:** Parrot
- **Model Number:** 94349 (Manufacturer Part Number: C-022G)
- **Dimensions:** Approximately 5 x 6.73 x 7.52 inches
- **Power Source:** 3 x AAA batteries (included)
- **Age Range:** 4 to 12 years (48-144 months)
- **Color:** Green, Orange
- **Theme:** Animal
- **Operation Mode:** Manual (interactive touch)

WARRANTY INFORMATION

This product is covered by a limited manufacturer's warranty. Please refer to the warranty information provided on the product packaging or visit the official Hasbro website for detailed terms and conditions. Keep your purchase receipt as proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For further assistance, questions, or to report any issues with your FurReal Newborn Parrot, please contact Hasbro customer service:

- **Website:** Visit the official [Hasbro Consumer Care](#) page for support resources and contact options.
- **Phone:** Refer to the contact information provided on the product packaging for regional support numbers.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question