

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Duravit](#) /

› [Duravit 005052 Sink Drain S Chrome Instruction Manual](#)

Duravit 005052

Duravit 005052 Sink Drain S Chrome Instruction Manual

Model: 005052 | Brand: Duravit

INTRODUCTION

The Duravit 005052 Push-Button Drain Assembly in Chrome is designed to provide efficient and reliable drainage for your sink. This manual will guide you through the installation, operation, and maintenance of your new drain, ensuring its longevity and optimal performance.

Key features of the Duravit 005052 Sink Drain include:

- High-quality chrome finish for durability and aesthetic appeal.
- Convenient push-button mechanism for easy opening and closing.
- Specifically designed to complement Duravit sinks, ensuring proper fit and function, especially for sinks with overflow.

SETUP AND INSTALLATION

Proper installation is crucial for the correct function and leak-free operation of your Duravit sink drain. While the process is straightforward, attention to detail is required. This drain is designed for sinks with an overflow.

Tools Required:

- 4mm Allen wrench
- Plumber's putty or silicone sealant
- Adjustable wrench or basin wrench
- Soft cloth

Installation Steps:

1. **Unpack and Inspect:** Carefully remove all components from the packaging. Inspect all parts for any signs of damage. Ensure all necessary components are present, including the drain body, push-button stopper, and extension pipe.
2. **Prepare the Sink Opening:** Clean the sink's drain opening thoroughly, removing any old sealant or debris.
3. **Apply Sealant:** Apply a thin bead of plumber's putty or silicone sealant around the underside of the drain flange (the

top part that sits inside the sink).

4. **Insert Drain Body:** Insert the drain body from the top of the sink opening. Ensure the sealant creates a tight seal with the sink surface.
5. **Secure from Below:** From underneath the sink, thread the large nut onto the drain body. Hand-tighten first, then use an adjustable wrench to gently tighten, being careful not to overtighten and crack the sink.
6. **Connect Extension Pipe:** Attach the provided 1-1/4" extension pipe to the bottom of the drain assembly. This pipe is where the P-trap will connect.
7. **Install Push-Button Stopper:** The push-button stopper typically screws into the drain body. Ensure it operates smoothly.
8. **Connect P-Trap:** Connect your existing P-trap assembly to the extension pipe. Ensure all connections are secure and hand-tighten any slip nuts.
9. **Test for Leaks:** Turn on the water and fill the sink. Observe all connections for any signs of leaks. If leaks are present, tighten the connections slightly until they stop.





Image: The complete Duravit 005052 Sink Drain assembly, showing the push-button stopper, drain body, and extension pipe.

OPERATING INSTRUCTIONS

The Duravit 005052 Sink Drain features a simple and intuitive push-button operation:

- **To Close the Drain:** Gently press down on the chrome cap of the drain stopper. You will feel a click as it locks into the closed position, allowing water to fill the sink.
- **To Open the Drain:** Press down on the chrome cap again. The stopper will release and pop up, allowing water to drain freely from the sink.

Ensure the stopper is fully open when draining to prevent slow drainage due to partial obstruction.

MAINTENANCE AND CARE

To maintain the pristine appearance and functionality of your Duravit 005052 Sink Drain, follow these care guidelines:

- **Regular Cleaning:** Clean the chrome finish regularly with a soft, damp cloth and a mild, non-abrasive soap or cleaner. Wipe dry immediately after cleaning to prevent water spots.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, scouring pads, ammonia-based products, or cleaners containing bleach, acids, or harsh chemicals. These can damage the chrome finish and internal components.
- **Clear Debris:** Periodically remove the push-button stopper and clear any hair, soap scum, or other debris that may accumulate in the drain body. This helps prevent clogs and ensures efficient drainage.
- **Check for Leaks:** Occasionally inspect the connections underneath the sink for any signs of leaks. Address any leaks promptly to prevent water damage.

TROUBLESHOOTING

If you encounter issues with your Duravit 005052 Sink Drain, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Slow Drainage	Partial clog in the drain or P-trap. Stopper not fully open.	Remove the stopper and clear any debris. If necessary, clean the P-trap. Ensure the push-button stopper is fully depressed to the open position.
Drain Leaks	Loose connections. Improperly applied sealant. Damaged gaskets or washers.	Check and tighten all connections (drain nut, P-trap connections). If sealant was not applied correctly, disassemble, reapply sealant, and reassemble. Inspect gaskets and washers for wear or damage and replace if necessary.
Stopper Not Operating	Debris obstructing the mechanism. Mechanism misalignment or damage.	Remove the stopper and clean any debris from the internal mechanism. If the mechanism is damaged, contact Duravit customer support for replacement parts or service.
Drain does not fit sink	Sink design incompatible with this specific drain.	This drain is specifically designed for Duravit sinks, particularly those with an overflow. Ensure your sink is compatible.

SPECIFICATIONS

Attribute	Value
Brand	Duravit
Product Model Number	005052
Product Dimensions	27.94 x 10.16 x 12.7 cm (approx. 11 x 4 x 5 inches)
Color	Chrome
Material	Metal
Included Components	Hardware only
Batteries Required	No
Item Weight	363 g (approx. 0.8 lbs)
ASIN	B002W2AS42
Average Customer Rating	4.8 out of 5 stars (based on 15 ratings)
First Available Date	August 7, 2012

WARRANTY INFORMATION

This Duravit product is covered by the manufacturer's standard warranty. For detailed information regarding warranty terms, conditions, and duration, please refer to the official Duravit website or contact their customer service department. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For technical assistance, questions about installation, spare parts, or any other inquiries regarding your Duravit 005052 Sink Drain, please contact Duravit customer support. You can find up-to-date contact information, including phone numbers and email addresses, on the official Duravit website (www.duravit.com).

© 2023 Duravit AG. All rights reserved. | Model 005052

Related Documents - 005052

 	<p>Duravit Single-Lever Basin Mixer: Installation and Operating Instructions</p> <p>Comprehensive guide for installing and operating your Duravit single-lever basin mixer. Includes safety warnings, technical specifications, and step-by-step mounting instructions.</p>
 	<p>Duravit D-Code Wall-Mounted Toilet Installation Guide Article 56978/15.02.1</p> <p>Comprehensive installation guide for the Duravit D-Code wall-mounted toilet (Wand-WC). Includes step-by-step instructions, diagrams explained, and product details. Article number 56978/15.02.1.</p>

