



[Manuals.plus](#) /

> [Compaq](#) /

> Compaq HP LE1711 LCD Monitor User Manual

Compaq LE1711

Compaq HP LE1711 LCD Monitor User Manual

Model: LE1711

1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your Compaq HP LE1711 LCD Monitor. Please read these instructions carefully before using your monitor to ensure proper functionality and safety.



Figure 1: Compaq HP LE1711 LCD Monitor (Angled View)

2. SAFETY INFORMATION

Observe the following safety precautions to prevent damage to the monitor and ensure user safety:

- Do not expose the monitor to rain or moisture.
- Do not open the monitor casing. Refer all servicing to qualified personnel.
- Place the monitor on a stable, flat surface.
- Ensure proper ventilation around the monitor. Do not block ventilation openings.
- Use only the power cord and adapter supplied with the monitor.

3. PACKAGE CONTENTS

Verify that your package contains the following items:

- Compaq HP LE1711 LCD Monitor
- Monitor Stand (Base and Neck)

- Power Cord
- VGA Cable
- User Manual (this document)

4. SETUP

4.1. Attaching the Monitor Stand

1. Carefully place the monitor face down on a soft, clean cloth to prevent scratching the screen.
2. Align the stand neck with the mounting slot on the back of the monitor.
3. Secure the stand neck to the monitor using the provided screws (if applicable) or by snapping it into place until it clicks.
4. Attach the stand base to the bottom of the stand neck, securing it with the thumb screw or latch.



Figure 2: Rear View of Monitor, showing stand attachment area.

4.2. Connecting Cables

Connect the necessary cables to the monitor and your computer:

1. **Power Cable:** Connect one end of the power cord to the monitor's power input and the other end to a grounded electrical outlet.
2. **VGA Cable:** Connect the VGA cable from the monitor's VGA port to the VGA port on your computer's graphics card. Tighten the screws on the VGA connector to ensure a secure connection.



Figure 3: Monitor Ports (Power and VGA)

4.3. Powering On

1. Ensure all cables are securely connected.
2. Press the power button on the front panel of the monitor. The power indicator light should illuminate.
3. Turn on your computer. The monitor should automatically detect the signal and display the image.

5. OPERATION

5.1. Front Panel Controls

The front panel of your monitor features several buttons for adjusting display settings. Refer to Figure 4 for button locations.



Figure 4: Front View of Monitor with Control Buttons

- **Power Button:** Turns the monitor on or off.
- **Menu Button:** Opens the On-Screen Display (OSD) menu.
- **Navigation Buttons (<, >):** Used to navigate through OSD menu options and adjust values.
- **Select/OK Button:** Confirms selections within the OSD menu.

5.2. On-Screen Display (OSD) Menu

The OSD menu allows you to customize various display settings. To access and navigate the OSD:

1. Press the **Menu** button to open the OSD.
2. Use the **Navigation** buttons to scroll through the menu options.
3. Press the **Select/OK** button to enter a sub-menu or confirm a selection.
4. Use the **Navigation** buttons to adjust values or select further options.
5. Press the **Menu** button again to exit the OSD.

5.3. Adjusting Display Settings

Common adjustments available through the OSD menu include:

- **Brightness:** Adjusts the overall luminance of the screen.
- **Contrast:** Adjusts the difference between light and dark areas.
- **Image Control:** Fine-tunes settings like clock, phase, and position for optimal image clarity, especially with analog (VGA) connections.
- **Color Control:** Adjusts color temperature or individual RGB levels.
- **OSD Control:** Adjusts OSD language, position, and timeout.

6. MAINTENANCE

6.1. Cleaning the Monitor

To clean your monitor, follow these guidelines:

- Always turn off the monitor and unplug the power cord before cleaning.
- Use a soft, lint-free cloth lightly dampened with water or a non-abrasive screen cleaner.
- Wipe the screen gently. Do not press hard or use harsh chemicals (e.g., alcohol, ammonia, acetone).
- For the casing, use a soft, dry cloth.

6.2. General Care

- Avoid placing heavy objects on the monitor or its cables.
- Keep the monitor away from direct sunlight, heat sources, and excessive dust.
- Do not block the ventilation slots on the monitor.

7. TROUBLESHOOTING

If you encounter issues with your monitor, refer to the following common problems and solutions:

Problem	Possible Solution
No image on screen	Ensure the power cable is securely connected and the monitor is turned on. Verify the video cable (VGA) is properly connected to both the monitor and the computer. Check if the computer is powered on and not in sleep mode.
Image is blurry or distorted	Adjust the 'Clock' and 'Phase' settings in the OSD menu. Ensure the display resolution on your computer is set to the monitor's native resolution (SXGA).
Colors are incorrect	Adjust 'Color Control' settings in the OSD menu. Check the video cable for bent pins or damage.
Monitor turns off randomly	Check power cable connections. Ensure proper ventilation to prevent overheating. Disable any power-saving features on your computer that might be turning off the display.

8. SPECIFICATIONS

Technical specifications for the Compaq HP LE1711 LCD Monitor:

Feature	Specification
Brand	Compaq
Model	LE1711

Feature	Specification
Screen Size	17 Inches
Resolution	SXGA
Aspect Ratio	16:10
Screen Surface	Glossy
Input Ports	VGA (D-Sub)

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact Compaq/HP customer service directly. Support contact details can typically be found on the manufacturer's official website.