UNGER UNGTF900

Unger TelePlus Modular Telescopic Extension Pole System

MODEL: UNGTF900

1. Introduction

The Unger TelePlus Modular Telescopic Extension Pole System (Model UNGTF900) is designed to provide safe and efficient access to hard-to-reach and high-access areas without the need for ladders. Its modular design allows for adjustable lengths from 6 feet to 30 feet, making it versatile for various cleaning and maintenance tasks. The system features robust locking mechanisms and an ErgoTec locking cone to securely attach compatible tools.

2. Safety Information

Always read and understand all instructions before using this product. Failure to follow safety guidelines may result in injury or damage.

- Inspect the pole and all attachments for damage before each use. Do not use if any part is damaged.
- Ensure all locking mechanisms are fully engaged before applying pressure or extending the pole.
- Maintain a stable and balanced stance when operating the pole. Avoid overreaching.
- Be aware of overhead power lines and other electrical hazards. Keep the pole clear of all electrical sources.
- Do not use the pole in high winds or adverse weather conditions.
- Only use attachments designed for or compatible with the ErgoTec locking cone.
- Keep hands and fingers clear of telescoping sections when extending or retracting to prevent pinching.

3. Components

The Unger TelePlus Modular Telescopic Extension Pole System consists of several interlocking sections that allow for variable length adjustment. Key components include:

- **Telescopic Pole Sections:** Multiple sections that slide within each other to extend or retract the pole.
- **Locking Mechanisms:** Securely hold the pole sections at the desired length.
- **ErgoTec Locking Cone:** The universal tip designed to securely attach a variety of Unger tools and accessories.



Figure 1: The Unger TelePlus Modular Telescopic Extension Pole in its extended form, showcasing its full length and modular sections.



Figure 2: A detailed view of the top section of the Unger TelePlus pole, highlighting the ErgoTec locking cone for tool attachment.

4. Setup

The Unger TelePlus pole comes pre-assembled. Setup primarily involves extending the pole to your desired working length and attaching the appropriate tool.

1. **Unpacking:** Carefully remove the pole from its packaging.
2. **Extending the Pole:**
    - Hold the base section of the pole firmly.
    - Twist the locking collar of the outermost section counter-clockwise to loosen it.
    - Gently pull the section outwards to extend it to the desired length.
    - Twist the locking collar clockwise to tighten and secure the section.
    - Repeat this process for each subsequent section until the pole reaches the required length. Ensure all sections are fully locked before use.

3. **Retracting the Pole:**
    - Starting from the outermost section, twist the locking collar counter-clockwise to loosen it.
    - Gently push the section inwards until it is fully retracted.
    - Twist the locking collar clockwise to secure the retracted section.
    - Repeat for all sections until the pole is fully retracted.

5. Operating Instructions

Using the Unger TelePlus pole effectively requires proper technique and tool attachment.

1. **Attaching Tools:**
    - Ensure the tool you wish to attach is compatible with the Unger ErgoTec locking cone.
    - Align the tool's handle with the ErgoTec cone at the tip of the pole.
    - Push the tool firmly onto the cone until it clicks into place, indicating a secure connection.
    - To remove, press the release button or lever on the tool (if applicable) or firmly pull the tool straight off the cone.
2. **Usage:**
    - Always maintain a firm grip on the pole.
    - Use smooth, controlled movements when cleaning or performing tasks. Avoid sudden jerks.
    - For tasks requiring significant force, ensure the pole is extended only as far as necessary to maintain stability and leverage.
    - When working at extreme heights, consider the weight of the attached tool and the potential for fatigue. Take breaks as needed.

6. Maintenance

Regular maintenance will prolong the life and performance of your Unger TelePlus pole.

- **Cleaning:** Wipe down the pole sections with a damp cloth after each use, especially if exposed to dirt, dust, or cleaning solutions. Dry thoroughly.
- **Inspection:** Periodically inspect the locking mechanisms for wear or damage. Ensure they engage and disengage smoothly.
- **Storage:** Store the pole in a clean, dry place, preferably fully retracted, to protect the internal mechanisms and prevent warping or damage.

7. Troubleshooting

- **Pole sections not extending/retracting smoothly:**
    - Check for dirt or debris inside the pole sections. Clean thoroughly.
    - Ensure locking collars are fully loosened before attempting to extend or retract.
- **Tool not securing to ErgoTec cone:**
    - Verify that the tool is compatible with the ErgoTec locking cone.
    - Check for any obstructions or damage on the cone or the tool's attachment point.

8. Specifications

Feature	Detail
Brand	UNGER
Model Number	UNGTF900
Material	Plastic
Color	Silver
Special Feature	Telescopic
Minimum Length	6 Feet
Maximum Height	30 Feet
Item Weight	6.86 Pounds
Product Dimensions (L x W x H)	0.08 x 4.99 x 0.08 inches
UPC	761475604482
ASIN	B002X9K59M
Manufacturer	UNGER
Date First Available	November 13, 2009

9. Warranty and Support

For detailed warranty information, product support, or to purchase compatible accessories, please visit the official UNGER website or contact UNGER customer service directly. Keep your purchase receipt for warranty claims.
You can find more information about UNGER products at their Amazon store:UNGER Amazon Store

© 2023 UNGER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question