Logitech 910-000928

Logitech M305 Wireless Mouse User Manual

Model: 910-000928

1. Product Overview

The Logitech Wireless Mouse M305 is designed to provide exceptional comfort and cordless convenience. It features an ergonomically designed soft rubber grip and a Plug-and-Forget Nano-receiver for reliable wireless connectivity.
Key features include:

- Wireless optical technology for precise tracking.
- Comfortable, ergonomic design with soft side grips.
- Three buttons and a scroll wheel for versatile control.
- Compact and contoured design for comfortable use.
- Long battery life, up to two years on a single AA battery.
- Includes a Logitech Nano Transceiver that can be stored inside the mouse.



Figure 1.1: Top view of the Logitech M305 Wireless Mouse with its accompanying Nano Receiver. The mouse is silver and black, featuring a scroll wheel and left/right click buttons.

2. Package Contents

Verify that all items are present in the package:

- Logitech Wireless Mouse M305
- Logitech Nano Transceiver
- User documentation (this manual)

Note: One AA battery is required for operation and is not included in the package.



Figure 2.1: Rear view of the Logitech M305 packaging, highlighting key features such as the Plug-and-Forget Nano-receiver, ergonomic design, and long battery life.

3. Setup Guide

3.1. Battery Installation

1. Locate the battery compartment cover on the underside of the mouse.
2. Slide the cover open.
3. Insert one AA battery, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.

4. Close the battery compartment cover securely.

3.2. Connecting the Nano Receiver

1. Remove the Nano Receiver from its storage slot within the mouse's battery compartment (if stored there).
2. Plug the Nano Receiver into an available USB port on your computer.
3. Allow a few seconds for your operating system to automatically detect and install the necessary drivers. No manual driver installation is typically required.



Figure 3.1: Angled view of the Logitech M305 Wireless Mouse alongside its compact Nano Receiver, illustrating their relative sizes and design.

3.3. Powering On the Mouse

Locate the On/Off switch on the underside of the mouse. Slide the switch to the "On" position. The mouse is now ready for use.




Figure 3.2: The Logitech Nano Receiver shown next to a US nickel, demonstrating its extremely small and low-profile design when plugged into a USB port.

4. Operating Instructions

4.1. Basic Functions

- **Left Click:** Press the left mouse button to select items, open links, or activate functions.
- **Right Click:** Press the right mouse button to open context menus or access additional options.
- **Scroll Wheel:** Roll the scroll wheel up or down to navigate through documents and web pages. The scroll wheel can also be pressed down for middle-click functionality, often used for opening links in new tabs.

4.2. Ergonomics and Comfort

The M305 mouse features a contoured design with soft rubber side grips, providing a comfortable and secure hold for extended periods of use. Its shape is designed to fit naturally in your hand, reducing strain.



Figure 4.1: Side view of the Logitech M305 Wireless Mouse, highlighting its contoured shape and soft rubber grips designed for ergonomic comfort.

4.3. Power Management

The mouse is equipped with intelligent power management features to conserve battery life. It includes an On/Off switch on the bottom. Additionally, the mouse will automatically enter a sleep mode when not in use, further extending battery life. To wake the mouse, simply move it or click a button.

5. Maintenance

5.1. Battery Replacement

When the mouse performance degrades or the battery indicator light (if present) signals low power, it's time to replace the AA battery. Follow the steps in Section 3.1 for battery installation.

5.2. Cleaning

To clean your mouse, use a soft, lint-free cloth lightly dampened with water. Avoid using harsh chemicals or abrasive cleaners. Ensure no liquid enters the mouse's internal components.

6. Troubleshooting

6.1. Mouse Not Responding

- **Check Battery:** Ensure the AA battery is correctly installed and has sufficient charge. Replace if necessary.
- **Power Switch:** Verify that the On/Off switch on the underside of the mouse is in the "On" position.
- **Receiver Connection:** Ensure the Nano Receiver is securely plugged into a working USB port on your computer. Try a different USB port.
- **Proximity:** Make sure the mouse is within range of the Nano Receiver (typically within a few meters).
- **Interference:** Move the mouse and receiver away from other wireless devices or large metal objects that might cause interference.

6.2. Erratic Cursor Movement

- **Surface:** Ensure you are using the mouse on a suitable surface. Highly reflective, transparent, or uneven surfaces can affect tracking. A mouse pad is recommended.
- **Sensor Cleanliness:** Check the optical sensor on the underside of the mouse for any dust or debris and clean gently with a soft cloth if needed.

7. Specifications

Feature	Detail
Brand	Logitech
Model Number	910-000928
Connectivity Technology	Wireless (2.4 GHz)
Movement Detection Technology	Laser, Optical
Color	Silver
Power Source	1 x AA Battery (not included)
Estimated Battery Life	Up to 2 years
Product Dimensions	8.25 x 6 x 3.5 inches (approximate packaging dimensions)
Item Weight	4 ounces
First Available Date	November 21, 2009

8. Warranty and Support

8.1. Legal Disclaimer

Please note that returns may not be accepted for open packages. Refer to your point of purchase for specific return policies.

8.2. Customer Support

For further assistance, technical support, or warranty information, please visit the official Logitech support website or contact their customer service. You can often find support resources, FAQs, and driver downloads at www.logitech.com/support.
For product information and other details, you may also visit theLogitech Store on Amazon.

© 2024 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question