Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

H.Koenig KB20

H.Koenig KB20 Ice Maker User Manual

Model: KB20

1. Important Safety Instructions

Please read all instructions carefully before using the H.Koenig KB20 Ice Maker. Retain this manual for future reference.

- **Electrical Safety:** Ensure the appliance is connected to a properly grounded electrical outlet with the correct voltage (20V AC). Do not operate with a damaged cord or plug. Do not immerse the cord, plug, or appliance in water or other liquids.
- **Placement:** Place the ice maker on a stable, level surface. Keep it away from direct sunlight, heat sources (stoves, heaters), and corrosive gases. Ensure adequate ventilation around the unit (at least 10 cm clearance on all sides).
- **Water Quality:** Use only potable (drinkable) water in the appliance.
- **Children and Pets:** Keep the appliance out of reach of children and pets. Do not allow them to operate or play with the ice maker.
- **Maintenance:** Unplug the appliance before cleaning or performing any maintenance. Do not attempt to repair the appliance yourself; contact qualified service personnel.
- **Usage:** This appliance is for household use only. Do not use it for commercial or industrial purposes.

2. Product Overview

The H.Koenig KB20 is a compact and efficient ice maker designed for home use, capable of producing up to 12 kg of ice per day.

2.1 Components

Familiarize yourself with the parts of your ice maker:

- **Main Unit:** Stainless steel housing.
- **Transparent Lid:** Allows you to view the ice-making process.
- **Control Panel:** Features an LCD display, indicator lights (ADD WATER, ICE FULL), and buttons (SELECT, POWER).
- **Ice Basket:** Removable basket for collecting produced ice.
- **Ice Scoop:** For hygienic handling of ice cubes.

- **Water Reservoir:** Internal tank for water supply.
- **Ice Making Pins:** Metal rods where ice cubes form.
- **Drain Plug:** Located at the bottom or back for draining water.



Image 2.1: Front view of the H.Koenig KB20 Ice Maker, showcasing its stainless steel finish and compact design.



Image 2.2: The H.Koenig KB20 Ice Maker with its transparent lid closed, ready for operation.

2.2 Key Features

- **Efficient Production:** Produces up to 12 kg of ice per day.
- **Fast Cycle:** Ice ready in 6 to 8 minutes per cycle.
- **Water Capacity:** 2.1-liter water reservoir.
- **Ice Size Options:** Two selectable ice cube sizes (Small and Large).
- **User-Friendly Display:** Integrated LCD display for easy control.
- **Self-Cleaning Function:** Simplifies maintenance.
- **Monitoring:** Transparent lid and water level indicator for easy observation.
- **Durable Construction:** Made with stainless steel for longevity.
- **Power:** 120 Watts.

3. Setup

Follow these steps to set up your H.Koenig KB20 Ice Maker for the first time.

3.1 Unpacking

1. Carefully remove the ice maker from its packaging.
2. Remove all packaging materials, tape, and protective films from the unit.
3. Check for any damage during transit. If the unit is damaged, do not use it and contact your retailer.

3.2 Placement

- Place the ice maker on a firm, level, and stable surface.
- Ensure there is at least 10 cm (4 inches) of clear space around the unit for proper air circulation. Do not block any ventilation openings.
- Avoid placing the unit near heat sources (e.g., ovens, radiators) or in direct sunlight, as this can affect ice production efficiency.

3.3 Initial Cleaning

Before the first use, it is essential to clean the interior of the ice maker:

1. Open the transparent lid and remove the ice basket.
2. Clean the interior of the water reservoir and ice basket with a soft cloth dampened with warm water and a mild detergent.
3. Rinse thoroughly with clean water. Ensure no detergent residue remains.
4. Drain any remaining water through the drain plug.
5. Wipe all surfaces dry with a clean cloth.

3.4 First Use Preparation

After unpacking or moving the appliance, it is crucial to allow the refrigerant system to stabilize:

- Let the ice maker stand upright for at least**3 hours** before plugging it into an electrical outlet. This allows the refrigerant fluid to settle, preventing potential damage to the compressor.

4. Operating Instructions

Follow these steps to operate your H.Koenig KB20 Ice Maker.

4.1 Adding Water

1. Open the transparent lid.
2. Remove the ice basket.
3. Fill the water reservoir with potable water up to the

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B002YIBU3M

More documents and user manuals: **https://manuals.plus/**