

[manuals.plus](#) /

› [X Rocker](#) /

› [X Rocker Chimera RGB 2.0 Stereo Audio Gaming Chair User Manual](#)

X Rocker 5140301

X Rocker Chimera RGB 2.0 Stereo Audio Gaming Chair User Manual

Model: 5140301

1. INTRODUCTION

Welcome to your new X Rocker Chimera RGB 2.0 Stereo Audio Gaming Chair. This manual provides essential information for setup, operation, and maintenance to ensure optimal performance and longevity of your product.

The X Rocker Chimera RGB is a compact and foldable gaming floor rocker designed to enhance your gaming experience with integrated audio and vibrant LED lighting.



Image: The X Rocker Chimera RGB 2.0 Stereo Audio Gaming Chair, showcasing its sleek design and integrated LED lighting.

2. PACKAGE CONTENTS

Please verify that all the following components are included in your package:

- X Rocker Chimera RGB Gaming Chair
- Audio Cable Set
- Power Supply / Power Adapter

3. SETUP INSTRUCTIONS

3.1. Unpacking

- Carefully remove all components from the packaging.
- Ensure all listed package contents are present and undamaged.

3.2. Power Connection

- Locate the 12V 1A power input port on the chair's control panel.
- Connect the provided power adapter to this port, then plug the adapter into a standard wall outlet.

3.3. Audio Connection

- The chair features a stereo audio system. Connect the audio cable set from the chair's audio output (typically a green port) to your gaming device or TV's headphone or RCA audio output.
- An additional X Rocker Legacy adapter may be required if your device does not have direct headphone or RCA audio outputs.



Image: Detailed view of the chair's control panel, showing the volume knob, power switch, audio input/output ports, and power adapter input.

4. OPERATING INSTRUCTIONS

4.1. Powering On/Off

- Once connected to power, use the power switch located on the control panel to turn the chair on or off.

4.2. Audio Control

- Adjust the audio volume using the 'VOL' knob on the control panel.
- Ensure your connected audio source (e.g., TV, game console) also has its volume set to an appropriate level.

4.3. LED Lighting (Neo Motion RGB)

- The chair features Neo Motion LED Lighting with up to 30 different color and pattern options.
- Locate the dedicated button(s) on the control panel to cycle through the various lighting modes and colors.



Image: The X Rocker Chimera 2.0 Gaming Chair illuminated with its vibrant LED lights in a typical gaming setup.

5. MAINTENANCE

5.1. Cleaning

- Always unplug the chair from the power source before cleaning.
- Wipe the chair's surface clean with a damp cloth.
- Do not use abrasive cleaners, harsh chemicals, or solvents, as these can damage the material and finish.

5.2. Storage

- The X Rocker Chimera RGB chair is designed to be foldable for compact storage.
- Carefully fold the chair when not in use to save space and protect it from damage.

6. TROUBLESHOOTING

6.1. No Power

- Check if the power adapter is securely connected to both the chair's power input and a functional wall outlet.
- Ensure the power switch on the chair's control panel is in the 'On' position.

6.2. No Audio

- Confirm that all audio cables are correctly and securely connected between the chair and your audio source.
- Verify the volume levels on both the chair's control panel and the connected audio source.
- Ensure the audio source itself is producing sound.
- If using an X Rocker Legacy adapter, ensure it is correctly installed and functioning.

6.3. LED Lights Not Working

- Ensure the chair is powered on.
- Locate and press the LED control button(s) on the control panel to cycle through lighting modes or activate the lights.

7. SPECIFICATIONS

Brand	X Rocker
Model Number	5140301
Product Dimensions (D x W x H)	29.13" x 16.54" x 26.77"
Item Weight	16.53 pounds
Special Features	Arm Rest, Ergonomic, Foldable, Neo Motion LED Lighting, Stereo Audio System
Material	Faux Leather (Furniture Finish), Foam (Fill Material)
Recommended Uses	Gaming, Reading
UPC	094338220230, 094338514032
Product Care Instructions	Wipe Clean

OVERALL
WIDTH - 42CM
DEPTH - 74CM
HEIGHT - 62CM

SEAT
WIDTH - 42CM
DEPTH - 45CM
HEIGHT - 18CM

MAX WEIGHT CAPACITY - 80KG




Image: Technical diagram illustrating the overall and seat dimensions of the X Rocker Chimera RGB Gaming Chair.


8. WARRANTY AND SUPPORT

For detailed warranty information, technical assistance, or customer support, please refer to the official X Rocker website or contact their customer service directly. It is recommended to retain your proof of purchase for any warranty claims.

You can also visit the official X Rocker Store on Amazon for more product information and support resources:

[Visit the X Rocker Store on Amazon](#)

Related Documents - 5140301

 <p>Assembly Instructions X-Rocker 2.1 Bluetooth Sound Rocker WEBSITE: www.acerb.com SUPPORT: www.acerb.com/pages/support</p>	<p>X-Rocker 2.1 Bluetooth Sound Rocker Assembly Instructions</p> <p>Step-by-step guide for assembling the X-Rocker 2.1 Bluetooth Sound Rocker gaming chair, including a detailed parts list, safety warnings, and assembly procedures.</p>
 <p>X-Rocker 2.0 Stereo Wired with LED</p> <p>For Support, please visit www.acerb.com/pages/support IMPORTANT! You must keep your original retail receipt as proof of purchase!</p>	<p>X-Rocker 2.0 Stereo Wired with LED User Manual</p> <p>This manual provides instructions for setting up and using the X-Rocker 2.0 Stereo Wired with LED gaming chair, including connection guides, troubleshooting tips, and safety information.</p>
 <p>X-Rocker 2.1 Wireless & Bluetooth with vibration</p> <p>User Manual www.acerb.com/pages/support IMPORTANT! You must keep your original retail receipt as proof of purchase!</p>	<p>X-Rocker 2.1 Wireless & Bluetooth Gaming Chair: Setup and User Guide</p> <p>This user manual provides comprehensive setup and connection guides for the X-Rocker 2.1 Wireless & Bluetooth gaming chair. Learn how to connect to PS4, Xbox One, and TVs, troubleshoot common issues, and ensure safe usage for an immersive audio experience.</p>
 <p>X-Rocker Gaming Chair User Manual and Setup Guide</p> <p>Welcome to the world of interactive audio. With your new X-Rocker you can now not only hear your favorite music, but also feel it. Whether you are listening to music, watching a movie, or playing a game, you can now experience sound as you never have!</p> <p>Do not return this product to the store. Email: service@acerb.com or call 888-949-2463/911-359-2003 for trouble shooting advice.</p> <p>IMPORTANT: You must keep your original retail receipt as proof of purchase. HAVE THIS NUMBER READY WHEN CONTACTING CUSTOMER SERVICE/STAFF.</p> <p>Have Help? Email: service@acerb.com Phone: 888-949-2463 www.acerb.com IMPORTANT! You must keep your original retail receipt as proof of purchase.</p>	<p>X-Rocker Gaming Chair User Manual and Setup Guide</p> <p>Comprehensive guide for the X-Rocker gaming chair by Ace Bayou, covering features, setup, wired and Bluetooth connections, troubleshooting, and warranty information.</p>
 <p>X-Rocker 2.1 Stereo Wireless</p> <p>Need Help? Email: service@acerb.com Phone: 888-949-2463 www.acerb.com IMPORTANT! You must keep your original retail receipt as proof of purchase.</p>	<p>X-Rocker 2.1 Stereo Wireless User Manual and Connection Guide</p> <p>Comprehensive guide for the X-Rocker 2.1 Stereo Wireless audio system, detailing setup, wireless and wired connections for TVs and PS4 controllers, troubleshooting tips, and important health and safety information.</p>
 <p>X-Rocker 2.0 WIRED</p> <p>For Support, please visit www.acerb.com/pages/support IMPORTANT! You must keep your original retail receipt as proof of purchase!</p>	<p>X-Rocker 2.0 Wired Gaming Chair Connection and Safety Guide</p> <p>Comprehensive guide to connecting and safely using the X-Rocker 2.0 Wired gaming chair, including console and TV setup, troubleshooting, and important safety information.</p>

