

[manuals.plus](#) /

› [Zeppelin](#) /

› [Zeppelin Men's Analogue Automatic Watch 76565 User Manual](#)

Zeppelin 76565

Zeppelin Men's Analogue Automatic Watch with Leather Strap

Model: 76565

INTRODUCTION

This manual provides essential information for the proper use and care of your Zeppelin Men's Analogue Automatic Watch, model 76565. This timepiece features a classic dial with clear Arabic numerals, combining German engineering with Swiss precision. It is designed for reliability and elegance.

Key features of your watch include:

- Automatic Movement
- Protective Hardened Mineral Crystal Lens
- Round Stainless Steel Case
- Water Resistance up to 50 meters (5 ATM)



Image: Front view of the Zeppelin Men's Analogue Automatic Watch 76565, showcasing its beige dial, Arabic numerals, and brown leather strap.

SETUP

Initial Winding

Your Zeppelin automatic watch is powered by the motion of your wrist. Before wearing it for the first time, or if it has stopped due to inactivity, it requires an initial manual winding. To do this:

1. Gently pull the crown (the knob on the side of the watch) out to position 1 (if it has a date function, this is the first click). If there is no date function, proceed to step 2.
2. Rotate the crown clockwise approximately 20-30 times. This will build up a sufficient power reserve to start the watch.
3. Push the crown back into its original position (position 0).

The watch should now begin to run. Regular wear will keep the watch wound.

Setting the Time

To set the correct time:

1. Pull the crown out to position 2 (the outermost position). The second hand will stop.
2. Rotate the crown in either direction to move the hour and minute hands until the desired time is displayed.
3. Once the time is set, push the crown back into position 0. The second hand will resume movement.

Adjusting the Leather Strap

The watch comes with a two-piece leather strap and a buckle clasp. To adjust the fit:

1. Place the watch on your wrist.
2. Thread the end of the strap through the buckle and select a hole that provides a comfortable, secure fit without being too tight or too loose.
3. Fasten the buckle pin through the chosen hole.
4. Tuck the excess strap into the two strap loops to secure it.

OPERATING YOUR AUTOMATIC WATCH

Automatic Movement

Your Zeppelin 76565 watch is equipped with an automatic mechanical movement. This means it does not require a battery. Instead, it is powered by the natural motion of your arm. An oscillating weight inside the watch rotates with your movements, winding the mainspring and storing energy. When fully wound, the watch typically has a power reserve of approximately 40-42 hours, meaning it can continue to run for this period even when not being worn.

Water Resistance (50 Meters / 5 ATM)

The watch is water-resistant to 50 meters (5 ATM). This rating means it is suitable for everyday use, including showering, swimming in shallow water, and brief immersion. It is **not** suitable for diving, snorkeling, or high-impact water sports. Always ensure the crown is fully pushed in (position 0) before any contact with water. Do not operate the crown while the watch is wet or submerged.

MAINTENANCE

Cleaning

To maintain the appearance of your watch:

- Wipe the stainless steel case and mineral crystal with a soft, dry, lint-free cloth.
- For the leather strap, avoid prolonged exposure to water, direct sunlight, and harsh chemicals.

Clean with a slightly damp cloth and allow it to air dry naturally.

Storage

When not wearing your watch for extended periods, store it in a cool, dry place away from direct sunlight and extreme temperatures. If the watch will not be worn for several days, it may stop. Simply re-wind it manually as described in the 'Setup' section before wearing it again.

Avoiding Magnetic Fields

Automatic watches can be affected by strong magnetic fields, which may cause them to run inaccurately or stop. Keep your watch away from strong magnets found in speakers, refrigerators, certain electronic devices, and magnetic clasps.

TROUBLESHOOTING

- **Watch Not Running:** If the watch has stopped, it likely needs to be wound. Manually wind the watch by rotating the crown clockwise 20-30 times. If it still does not start, ensure the crown is fully pushed in.
- **Inaccurate Time:** Automatic watches are mechanical and may not be as precise as quartz watches. A deviation of +/- 15-30 seconds per day is generally considered acceptable. If the deviation is significantly larger, ensure the watch is fully wound and has not been exposed to strong magnetic fields.
- **Condensation Under Crystal:** If you notice condensation under the crystal, this indicates moisture has entered the watch. Immediately take the watch to a qualified watchmaker for inspection and repair to prevent further damage.
- **Strap Damage:** If the leather strap shows signs of significant wear or damage, it is recommended to replace it to prevent accidental loss of the watch.

SPECIFICATIONS

Model Number	76565
Brand	Zeppelin
Movement Type	Automatic
Case Material	Stainless Steel
Case Diameter	40 mm
Case Thickness	12 mm
Crystal	Mineral
Band Material	Leather
Band Width	20 mm
Water Resistance	50 Meters (5 ATM)
Display Type	Analog

Clasp Type	Buckle
-------------------	--------

WARRANTY INFORMATION

Your Zeppelin 76565 watch comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage. The warranty typically covers manufacturing defects under normal use. Keep your proof of purchase for any warranty claims.

SUPPORT

For further assistance, service, or inquiries regarding your Zeppelin watch, please contact the authorized Zeppelin dealer or service center where you purchased the product. You may also visit the official Zeppelin website for support resources and contact information.