

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [N-A](#) /
- › User Manual for N-A Pears Soap I'd Forgotten My Pears Steel Fridge Magnet

N-A B002YV76HS

User Manual: N-A Pears Soap I'd Forgotten My Pears Steel Fridge Magnet

Brand: N-A | Model: B002YV76HS


INTRODUCTION

This manual provides essential information for the proper use and care of your N-A Pears Soap I'd Forgotten My Pears steel fridge magnet. This high-quality magnet is designed for decorative and functional use on magnetic surfaces.

SETUP

The N-A Pears Soap steel fridge magnet is ready for immediate use upon unboxing. No assembly or special tools are required.

1. **Unpacking:** Carefully remove the magnet from its packaging.
2. **Surface Selection:** Identify a clean, dry, and flat magnetic surface, such as a refrigerator door, magnetic whiteboard, or metal cabinet.
3. **Placement:** Gently place the magnet onto the chosen magnetic surface. The magnetic backing will adhere to the surface.



This image displays the front of the N-A Pears Soap steel fridge magnet. It features a classic Pears Soap advertisement, showing a young child in a bathtub, with the phrase 'I'd forgotten my Pears' prominently displayed. The magnet has a rectangular shape and a multi-color

design, reflecting the vintage aesthetic.

OPERATING

The primary function of this magnet is to adhere to magnetic surfaces and hold lightweight items such as notes, photos, or small papers. Its strong magnetic backing ensures a secure hold.

- **Attaching Items:** Place the item you wish to display between the magnet and the magnetic surface. Ensure the magnet fully covers the item to secure it.
- **Repositioning:** To move the magnet, gently lift it from the surface and re-place it in the desired location. Avoid sliding the magnet forcefully across surfaces to prevent scratches.

MAINTENANCE

Proper care will ensure the longevity and appearance of your magnet.

- **Cleaning:** To clean the magnet, wipe it gently with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these may damage the surface or the printed design.
- **Storage:** When not in use, store the magnet on a flat magnetic surface or in a dry place away from extreme temperatures and direct sunlight.

TROUBLESHOOTING

If you encounter any issues with your magnet, consider the following:

Problem	Possible Cause	Solution
Magnet does not stick firmly.	Surface is not magnetic, or is uneven/dirty.	Ensure the surface is made of a ferromagnetic material (e.g., steel, iron). Clean the surface and ensure it is flat.
Magnet appears dull or dirty.	Accumulation of dust or grime.	Wipe with a soft, damp cloth as described in the Maintenance section.

SPECIFICATIONS

- **Dimensions:** 80mm x 60mm (approximately 3 inches x 2.5 inches)
- **Material:** Steel (front), Magnetic backing
- **Shape:** Rectangular
- **Color:** Multi Color
- **Quantity:** 1 magnet per unit
- **Licensing:** Officially Licensed Product

WARRANTY AND SUPPORT

Due to the nature of this product, a specific manufacturer's warranty may not be applicable. For any concerns regarding product quality or defects upon receipt, please contact the seller directly through the platform where the purchase was made. Please refer to the seller's return and refund policy for further details.

For general inquiries or support, please refer to the contact information provided by your retailer or the product listing page.

© 2024 N-A. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.