Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DEWALT D26950

DEWALT Heat Gun (D26950) User Manual

Model: D26950 | Brand: DEWALT

1. Product Overview

The DEWALT D26950 Heat Gun is a versatile tool designed for various applications requiring concentrated heat. It features an innovative kickstand for enhanced stability and allows for precise temperature control. Its lightweight, compact, and durable design makes it suitable for professional use and convenient storage.



Image 1.1: The DEWALT D26950 Heat Gun, showcasing its ergonomic design and prominent yellow and black casing.

Key Features:

- **Variable Temperature Control:** Allows for precise adjustment of heat settings to suit different tasks.
- **Built-in Overload Protection:** Automatically shuts down the heating element to prevent burn-up and ensure tool longevity.
- **Integrated Hang Ring:** Provides a convenient option for storage when not in use.
- **Innovative Kickstand Support:** Offers greater stability and prevents the tool from tipping over during cool-down or when placed on a surface.
- **Cord Protector:** Designed to prevent the power cord from tearing away from the housing, enhancing durability.
- **Ergonomic Comfort Grip:** Ensures comfortable handling during extended periods of use, reducing user fatigue.
- **Separate Internal Components:** Facilitates easier maintenance of both the motor and the heating element.
- **Lightweight and Compact Design:** Weighs approximately 2.1 lbs.

2. Safety Information

Always read and understand all safety warnings and instructions before operating the DEWALT D26950 Heat Gun. Failure to follow these warnings and instructions may result in electric shock, fire, and/or serious injury.

General Safety Guidelines:

- Wear appropriate personal protective equipment (PPE), including safety glasses and gloves.
- Ensure the work area is well-ventilated to prevent the accumulation of fumes.
- Do not direct the heat gun at people or animals.
- Avoid touching the hot nozzle or accessories during and immediately after use.
- Do not use the heat gun near flammable materials or gases.
- Always unplug the tool when not in use or before performing maintenance.
- Use the integrated kickstand for stable placement when cooling down.

Proposition 65 Warning: This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

3. Setup

Before first use, inspect the heat gun for any damage. Ensure the power cord is intact and the plug is compatible with your power outlet (120 Volts).

Initial Setup:

1. Unpack the heat gun and any included accessories (e.g., nozzles).
2. Attach the desired nozzle firmly to the heat gun's outlet.
3. Ensure the power switch is in the "OFF" position before plugging the tool into a power source.
4. Place the heat gun on a stable, heat-resistant surface using its integrated kickstand if not holding it.

4. Operating Instructions

The DEWALT D26950 Heat Gun offers variable temperature control and a two-speed fan setting for optimal performance across various tasks.

Basic Operation:

1. **Power On:** Plug the heat gun into a 120V power outlet. Move the power switch to the desired fan speed setting (Low or High).
2. **Adjusting Temperature:** Use the variable temperature control dial located at the rear of the tool to set the desired heat output. Start with a lower setting and gradually increase if more heat is required for your application.
3. **Application:** Direct the hot air stream towards the workpiece. Maintain a safe distance to avoid scorching or damaging the material.
4. **Power Off:** When finished, switch the tool to the "OFF" position. Allow the heat gun to cool down completely before storing. Utilize the kickstand to keep the hot nozzle elevated during cool-down.

Common Applications:

- Stripping paint and varnish.
- Thawing frozen pipes.
- Bending plastic pipes.

- Shrinking heat-shrink tubing.
- Loosening rusted nuts and bolts.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your DEWALT Heat Gun. Always unplug the tool before any maintenance procedures.

Cleaning and Storage:

- **Cleaning:** Periodically clean the air intake vents to prevent overheating. Use a dry cloth to wipe down the exterior of the tool. Do not use harsh chemicals or abrasive cleaners.
- **Cool-down:** Always allow the heat gun to cool down completely before storing. The integrated kickstand helps in safe cool-down.
- **Cord Care:** Inspect the power cord regularly for cuts, abrasions, or damage. The cord protector helps prevent tearing.
- **Internal Components:** The design allows for separate maintenance of the motor and heating element by authorized service personnel. Do not attempt to open the tool unless you are a qualified technician.
- **Storage:** Store the heat gun in a dry, secure location out of reach of children. Use the built-in hang ring for convenient storage.

6. Troubleshooting

If you encounter issues with your DEWALT D26950 Heat Gun, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Heat gun does not turn on.	No power, faulty switch, or internal issue.	Check power outlet and circuit breaker. Ensure switch is fully engaged. If problem persists, seek professional service.
No heat or insufficient heat.	Overload protection activated, blocked air vents, or heating element issue.	Allow tool to cool down. Clear any obstructions from air vents. If problem persists, professional service is required.
Excessive smoke or burning smell.	Overheating, foreign material inside, or internal damage.	Immediately unplug the tool. Allow it to cool. Do not use until inspected by a qualified technician.

For issues not listed here or if solutions do not resolve the problem, contact DEWALT customer support or an authorized service center.

7. Specifications

Attribute	Detail
Manufacturer	DEWALT
Part Number	D26950
Item Model Number	D26950

Attribute	Detail
Item Weight	0.32 ounces (Note: This seems unusually low, but reflects provided data)
Product Dimensions	11 x 7.95 x 3.44 inches
Country of Origin	China
Color	Yellow
Style	Classic
Material	Blend
Power Source	Corded Electric
Voltage	120 Volts
Item Package Quantity	1
Included Components	HEAVY DUTY HEAT GUN
Batteries Included?	No
Batteries Required?	No
Date First Available	December 8, 2009

8. Official Product Videos

No official seller videos are available for this product at this time. Please refer to the text and images for product information.

9. Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the official DEWALT website or contact DEWALT customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

You can visit the official DEWALT Store for more information:DEWALT Store

© 2025 DEWALT. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00307B4P0

More documents and user manuals: **https://manuals.plus/**