

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

OSRAM 2721LL.BP2

SYLVANIA 2721 Long Life Miniature Bulb User Manual

Model: 2721LL.BP2 | Brand: OSRAM

PRODUCT OVERVIEW

The SYLVANIA Long Life Mini Bulb is engineered for various automotive lighting applications, offering increased bulb life. These lamps are designed to withstand road shock and vibration, featuring a robust filament and proprietary gas mixture for extended durability and reduced maintenance. They are legal for on-road use and are manufactured by an Original Equipment (OE) Manufacturer.



Image: Packaging for the SYLVANIA 2721 Long Life Miniature Bulb, containing two bulbs.

SPECIFICATIONS

Feature	Detail
Brand	OSRAM

Item Package Quantity	1 (Contains 2 Bulbs)
Color	Clear
Auto Part Position	Inside
Manufacturer	Osram Sylvania
UPC	046135392498
Item Weight	0.634 ounces
Product Dimensions	4 x 2.94 x 0.58 inches
Item Model Number	2721LL.BP2
Voltage	12 Volts



Image: A detailed view of the SYLVANIA 2721 miniature bulb, highlighting its compact size and filament.

INSTALLATION GUIDE

This guide provides general steps for replacing a miniature automotive bulb. Specific vehicle models may have variations in access and procedure. Always consult your vehicle's service manual for precise instructions.

Safety Precautions:

- Ensure the vehicle is turned off and the ignition key is removed.
- Allow any hot components (e.g., engine, existing bulbs) to cool down before handling.
- Wear appropriate safety gear, such as gloves and eye protection.
- Avoid touching the glass of the new bulb directly with bare hands, as oils can reduce bulb life. Use a clean cloth or gloves.

General Installation Steps:

1. **Locate the Bulb:** Identify the specific light assembly (e.g., dashboard, interior light, shifter indicator) where the bulb needs replacement. Access may require removing trim panels or other components.
2. **Access the Bulb Socket:** Carefully remove any covers, panels, or screws that obstruct access to the bulb socket. The socket typically holds the miniature bulb.
3. **Remove the Old Bulb:** Gently twist the bulb socket counter-clockwise (if applicable) or pull it straight out to remove it from the housing. The miniature bulb itself is often a press-fit or twist-lock into the socket. Carefully pull or twist the old bulb out.
4. **Insert the New Bulb:** Align the base of the new SYLVANIA 2721 bulb with the socket. Gently push or twist the bulb into place until it is secure. Ensure it is fully seated.
5. **Test the Bulb:** Before reassembling, turn on your vehicle's ignition and activate the light circuit to confirm the new bulb illuminates correctly.
6. **Reassemble:** Once confirmed, reinsert the bulb socket into its housing (if removed) and secure any panels or covers that were detached.

Note: A customer-created video demonstrating the replacement of a similar bulb in a Jeep JK automatic shifter light is available online. While not an official guide, it may offer visual reference for similar installation processes. Always prioritize your vehicle's specific service manual.

OPERATING INSTRUCTIONS

Once installed, the SYLVANIA 2721 Long Life Miniature Bulb operates automatically with your vehicle's electrical system. Simply activate the corresponding light function (e.g., turn on headlights, open door for interior lights, shift gear for indicator lights) for the bulb to illuminate.

MAINTENANCE

SYLVANIA Long Life bulbs are designed for extended durability and minimal maintenance. However, it is recommended to:

- **Replace in Pairs:** For optimal performance and consistent light output, it is often recommended to replace bulbs in pairs, especially for critical lighting functions.
- **Regular Inspection:** Periodically check all vehicle lights to ensure they are functioning correctly. Bulbs dim over time and require replacement.
- **Cleanliness:** Keep light housings and lenses clean to maximize light output.

TROUBLESHOOTING

If your newly installed SYLVANIA 2721 bulb does not illuminate, consider the following troubleshooting steps:

- **Check Connections:** Ensure the bulb is fully and correctly seated in its socket. Verify that the socket is properly connected to the vehicle's wiring harness.

- **Inspect the Bulb:** Carefully remove the bulb and inspect the filament. A broken or discolored filament indicates a burnt-out bulb.
- **Verify Power:** Use a multimeter or circuit tester to check for power at the bulb socket. If no power is present, the issue may be with the vehicle's wiring, fuse, or switch.
- **Check Fuse:** Consult your vehicle's owner's manual to locate the fuse box and identify the fuse for the affected lighting circuit. Replace any blown fuses with a new fuse of the correct amperage.
- **Professional Assistance:** If the issue persists after basic troubleshooting, it is advisable to seek assistance from a qualified automotive technician.

WARRANTY AND SUPPORT

For warranty information and customer support regarding your SYLVANIA 2721 Long Life Miniature Bulb, please refer to the packaging or visit the official OSRAM/SYLVANIA website. Keep your proof of purchase for any warranty claims. You can also visit the [OSRAM Store on Amazon](#) for more product information and support resources.

© 2024 OSRAM. All rights reserved.