



[Manuals.plus](#) /

> [PenPower](#) /

> Penpower Handwriter Lohas Chinese Handwriting Tablet User Manual (Model PHWT641TC)

PenPower PHWT641TC

Penpower Handwriter Lohas Chinese Handwriting Tablet User Manual

Model: PHWT641TC

1. INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your Penpower Handwriter Lohas Chinese Handwriting Tablet, Model PHWT641TC. This device is designed to offer a natural handwriting experience for various languages, including traditional and simplified Chinese, English, Japanese, and Korean.



Figure 1: Penpower Handwriter Lohas Chinese Handwriting Tablet and Cordless Pressure-Sensitive Pen.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your product package:

- Handwriting Tablet
- Cordless Pressure-Sensitive Pen
- USB Cable
- Quick Start Guide



Figure 2: Illustration of the package contents, including the tablet, pen, and USB cable.

3. SETUP

Follow these steps to set up your Penpower Handwriter Lohas tablet:

1. **System Requirements:** Ensure your computer runs a compatible Windows operating system.
2. **Connect the Tablet:**
Connect the USB cable to the tablet's port and then to an available USB port on your computer (Laptop or Desktop).



Figure 3: USB cable connection to the handwriting tablet.

3. Driver Installation:

Insert the installation CD (if provided) or download the latest drivers from the official PenPower website. Follow the on-screen instructions to complete the driver installation.

4. **Restart Computer:** After installation, it is recommended to restart your computer to ensure all drivers are properly loaded.

4. OPERATING INSTRUCTIONS

The Penpower Handwriter Lohas offers several features for an enhanced handwriting experience:

4.1. Character Recognition

The tablet is capable of recognizing a wide range of characters:

- Over 23,000 traditional and simplified Chinese characters.
- 4941 special Hong Kong characters.
- English letters, symbols, and numbers.
- Japanese Kanji, Katakana, and Hiragana.
- Korean characters.

No specific stroke order is required for recognition. The system is designed to accurately recognize extremely cursive handwriting and adapts to your unique writing style.

4.2. Input Interfaces

The Full-screen interface provides multiple input options:

- **Full-screen continual writing interface:** Allows continuous writing across the entire screen.
- **Writing Pad interface:** Provides a dedicated area for handwriting input.

- **Infinity-mode Writing interface:** Offers an expanded writing canvas.

4.3. Balloon UI Toolbar

The Balloon UI Toolbar simplifies access to various functions:

- **Mouse/Handwriting Switch:** Toggle between mouse and handwriting input modes.
- **Real-time Translator:** Translate handwritten text in real-time.
- **Signature Function:** Create and insert digital signatures.
- **Punctuation Symbol Input:** Easily access and insert punctuation.
- **Related Phrase and Setup:** Access related phrases and configuration settings.



Figure 4: Example of the Balloon UI Toolbar with various function icons.

4.4. Proofreading and Correction

The system includes a built-in vocabulary and phrases database. This feature automatically corrects recognition results, enhancing accuracy and efficiency.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Penpower Handwriter Lohas tablet, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the tablet surface. Avoid abrasive cleaners or solvents.
- **Storage:** Store the tablet in a cool, dry place away from direct sunlight and extreme temperatures.
- **Pen Care:** Keep the cordless pen away from magnetic fields and avoid dropping it. Replace pen tips as needed.
- **Cable Management:** Avoid bending or crimping the USB cable excessively to prevent damage.

6. TROUBLESHOOTING

If you encounter issues with your tablet, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Tablet not recognized by computer.	Ensure the USB cable is securely connected to both the tablet and the computer. Try a different USB port. Verify that the drivers are correctly installed. Reinstall if necessary. Restart your computer.
Pen is not responding.	Check if the pen tip is worn out and replace it if needed. Ensure the tablet is powered on and connected. Verify that the pen is within the active area of the tablet.
Inaccurate character recognition.	Ensure your handwriting is clear and within the designated writing area. Adjust recognition settings in the software if available. Practice writing to allow the system to adapt to your style.

If the problem persists, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	PenPower
Model Name	Lohas
Model Number	PHWT641TC
Connectivity Technology	USB
Pressure Sensitivity	1024 Levels
Operating System	Windows
Active Surface Area	24 square inches (6 Inches diagonal screen size)
Item Weight	2 Pounds
Compatible Devices	Laptop, Desktop
Character Recognition	Over 23,000 Chinese characters (Traditional/Simplified), 4941 Hong Kong characters, English, Japanese (Kanji, Katakana, Hiragana), Korean.
Special Features	Full-screen Interface, Balloon UI Toolbar, Built-in Vocabulary for Proofreading.

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the Quick Start Guide included in your package or visit the official PenPower website. Keep your purchase receipt as proof of purchase for warranty claims.

Manufacturer: VICTORY MULTIMEDIA

Contact: Refer to the official PenPower website for the latest support contact information.