

manuals.plus /

> [Energizer](#) /

> [Energizer Recharge Universal Rechargeable AA Batteries \(2 Pack\) Instruction Manual](#)

Energizer NH15BP-2

Energizer Recharge Universal Rechargeable AA Batteries (2 Pack) Instruction Manual

Model: NH15BP-2 | Brand: Energizer

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Energizer Recharge Universal Rechargeable AA Batteries. Please read these instructions thoroughly before first use and retain them for future reference.

PRODUCT OVERVIEW

The Energizer Recharge Universal Rechargeable AA Batteries are designed for repeated use, offering a sustainable power solution for various electronic devices. This pack includes two AA-sized Nickel Metal Hydride (NiMH) rechargeable batteries.




Image: Packaging for Energizer Recharge Universal AA Batteries, showing two batteries and the Energizer bunny mascot.

Key Features:

- **Rechargeable:** Can be charged hundreds of times, reducing waste and saving costs.
- **NiMH Technology:** Provides reliable power for various devices.
- **Pre-charged:** Ready to use right out of the package.
- **Long-lasting:** Holds charge for up to 1 year when not in use, with up to a 12-year battery life when not in use.
- **Eco-friendly:** Made with 22% recycled materials.
- **Leak Protection:** Designed to prevent damaging leaks.



BATTERIES MADE WITH
**22% RECYCLED
MATERIALS**

Image: Graphic highlighting that Energizer Recharge batteries are made with 22% recycled materials.

DESIGNED TO PREVENT DAMAGING LEAKS



Image: Graphic showing an Energizer Recharge battery with an arrow indicating its design to prevent damaging leaks.

SETUP AND FIRST USE

Your Energizer Recharge batteries come pre-charged and are ready for immediate use. However, for optimal performance and longevity, it is recommended to fully charge them before the first extensive use.

COMES
CHARGED
& READY TO GO



Image: Graphic showing an Energizer Recharge battery with text indicating it comes charged and ready to use.

Charging with an Energizer Recharge Charger:

1. **Insert Batteries:** Place the AA batteries into an Energizer Recharge charger (sold separately), ensuring correct polarity (+ and -) alignment.
2. **Connect Charger:** Plug the charger into a standard AC outlet.
3. **Monitor Charging:** The charger's indicator light will typically show red during charging and turn green when charging is complete. Refer to your specific charger's manual for detailed indicator information.
4. **Remove Batteries:** Once fully charged, unplug the charger from the outlet and remove the batteries.

CHARGES
100s
OF TIMES



Image: Graphic illustrating that Energizer Recharge batteries can be charged hundreds of times.

OPERATING INSTRUCTIONS

These batteries are suitable for a wide range of devices that require AA batteries. Always ensure correct battery orientation when inserting them into your device.

Recommended Uses:

- Cameras
- Wireless gaming components
- Toys
- Flashlights
- Remote controls
- Other household devices requiring AA batteries



REUSABLE POWER

FOR THE DEVICES YOU LOVE

Image: Various electronic devices such as a camera, game controller, and remote-controlled toy, illustrating the versatility of Energizer Recharge batteries.

Battery Life and Storage:

Energizer Recharge batteries are designed to hold power for up to 1 year when not in use. For best results, store fully charged batteries in a cool, dry place away from direct sunlight and extreme temperatures.

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and performance of your rechargeable batteries.

- **Regular Charging:** Recharge batteries when they are depleted to maintain their capacity.
- **Avoid Over-Discharging:** Do not completely drain batteries if possible, as this can reduce their overall lifespan.
- **Clean Contacts:** Periodically clean the battery contacts on both the batteries and your devices with a clean, dry cloth to ensure optimal connection.
- **Storage:** Store batteries in their original packaging or a dedicated battery case to prevent short circuits.

TROUBLESHOOTING

If you encounter issues with your Energizer Recharge batteries, consider the following:

- **Batteries Not Providing Power:**
 - Ensure batteries are fully charged.
 - Verify correct polarity (+ and -) when inserted into the device.
 - Check if the device itself is functioning correctly with other known good batteries.
- **Short Device Run Time:**
 - Ensure batteries are fully charged before use.
 - The device may be high-drain, consuming power quickly.
 - Batteries may be nearing the end of their lifespan and may need replacement.
- **Battery Leakage:**
 - While designed to prevent leaks, extreme conditions (e.g., high heat, physical damage) can cause issues. Discontinue use if leakage occurs and dispose of batteries properly according to local regulations.

SPECIFICATIONS

Feature	Detail
Model Number	NH15BP-2
Battery Type	Nickel Metal Hydride (NiMH) Rechargeable
Size	AA
Capacity	2300 Milliamp Hours (mAh)
Voltage	1.2V (typical for NiMH AA)
Recycled Material Content	22%
Shelf Life (when not in use)	Up to 1 year
Overall Battery Life (when not in use)	Up to 12 years
Product Dimensions	0.59 x 3.69 x 4.51 inches
Item Weight	2.08 ounces

SAFETY INFORMATION

Please observe the following safety precautions to prevent injury and property damage:

- Use only Nickel Metal Hydride (NiMH) rechargeable batteries. Do not attempt to charge other battery types (e.g., Alkaline, Carbon Zinc, Lithium) as this may cause them to leak, rupture, or explode.
- Do not open, dispose of in fire, put in backwards, mix with used or other battery types, or short circuit. This may ignite, explode, leak, or get hot causing injury.

- Keep batteries away from rain, snow, or excessive moisture.
- Do not operate batteries if damaged.
- Do not disassemble or modify any part of the battery.
- Dispose of depleted or damaged batteries properly according to local regulations.

Proposition 65 Warning: This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the official Energizer website or contact Energizer customer service. Keep your purchase receipt as proof of purchase.

Manufacturer: Energizer

Date First Available: June 27, 2007