

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Sealey](#) /
- › [Sealey IHS1 Stand for IWMH1809R/IFSH1809R Heaters - 1700mm Height Instruction Manual](#)

## Sealey IHS1

# Sealey IHS1 Stand for IWMH1809R/IFSH1809R Heaters - Instruction Manual

*Model: IHS1*

## 1. INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your Sealey IHS1 stand. This stand is designed to convert the Sealey IWMH1809R wall-mounted infrared heater into a freestanding IFSH1809R unit. Please read these instructions thoroughly before use and retain them for future reference.





Figure 1: The Sealey IHS1 stand with a compatible infrared heater installed, showcasing its freestanding design.

## 2. SAFETY INSTRUCTIONS

---

Always observe the following safety precautions to prevent personal injury or damage to the product.

- Ensure the stand is assembled on a flat, stable, and level surface.
- Do not exceed the maximum weight capacity of the stand. This stand is specifically designed for Sealey IWMH1809R/IFSH1809R heaters.
- Regularly inspect all fasteners and connections to ensure they are secure.
- Keep children and pets away from the stand and attached heater during operation.
- Do not attempt to modify the stand in any way.
- When moving the stand with the heater attached, ensure the heater is switched off and cooled, and move with care to prevent tipping.

## 3. PACKAGE CONTENTS

---

Verify that all components are present before beginning assembly:

- 1 x Sealey IHS1 Stand Assembly (includes base, pole sections, and mounting bracket)
- Required Fasteners and Tools (if applicable, refer to heater manual for heater-specific fasteners)

## 4. SETUP AND ASSEMBLY

---

Follow these steps to assemble the IHS1 stand and attach your compatible heater.

1. **Assemble the Base:** Place the stand base on a flat, stable surface. Ensure the base is fully seated and stable.



Figure 2: The robust circular base of the Sealey IHS1 stand, designed for stability.

2. **Attach Pole Sections:** Securely connect the pole sections to the base and to each other, following the instructions provided with the stand's packaging. Ensure all connections are tightened.
3. **Mount the Heater:** Attach your Sealey IWMH1809R heater to the top mounting bracket of the IHS1 stand. Refer to your heater's instruction manual for specific mounting hardware and procedures. Ensure the heater is securely fastened and balanced on the stand.
4. **Cable Management:** Route the heater's power cable along the stand pole using the provided cable clips to prevent tripping hazards and maintain a tidy appearance.



Figure 3: A close-up view of the cable management clip on the stand's pole, used to secure the power cord.

## 5. OPERATING INSTRUCTIONS

---

The IHS1 stand provides a stable platform for your heater. Its primary operational feature is height adjustment.

1. **Adjusting Height:** To adjust the height of the heater, loosen the height adjustment collar on the stand pole. Carefully raise or lower the upper pole section to the desired height (between 1340mm and 1700mm). Once the desired height is achieved, securely tighten the adjustment collar to lock the pole in place.



Figure 4: The height adjustment collar on the stand's pole, allowing for variable height settings.

2. **Positioning:** Place the stand with the attached heater in a location where it can provide optimal heating without obstruction. Ensure there is adequate clearance around the heater as specified in the heater's manual.





Figure 5: The Sealey IHS1 stand with an infrared heater positioned outdoors, demonstrating its freestanding utility.

*Note: For specific operating instructions regarding the heater's power, heat settings, and sensor functions, please refer to the instruction manual provided with your Sealey IWMH1809R/IFSH1809R heater. An example of a heater control panel is shown below for reference.*





Figure 6: Example of a control panel found on compatible Sealey heaters, featuring ON, OFF, and SENSOR buttons.

## 6. MAINTENANCE

To ensure the longevity and safe operation of your IHS1 stand:

- **Cleaning:** Wipe the stand with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Inspection:** Periodically check all bolts, screws, and connections for tightness. Retighten if necessary.
- **Storage:** If storing the stand for an extended period, disassemble it if desired and store in a dry, protected area.

## 7. TROUBLESHOOTING

If you encounter issues with your IHS1 stand, consider the following:

- **Stand Instability:**
  - Ensure the stand is on a completely flat and level surface.
  - Verify all pole sections and the base are securely tightened.
  - Confirm the heater is properly centered and balanced on the mounting bracket.

- **Difficulty Adjusting Height:**

- Ensure the height adjustment collar is fully loosened before attempting to adjust.
- Check for any obstructions or debris within the pole sections.

For issues related to the heater's functionality, refer to the heater's specific instruction manual.

## 8. SPECIFICATIONS

Feature	Detail
Model Number	IHS1
Compatible Heaters	Sealey IWMH1809R, IFSH1809R
Minimum Height	1340mm
Maximum Height	1700mm
Product Dimensions (packed)	Approximately 0.62 x 3.23 x 0.62 inches
Item Weight	22.2 pounds (approx. 10.07 kg)
Color	Black

## 9. WARRANTY AND SUPPORT

This Sealey IHS1 stand comes with a **1 Year Guarantee**. For full terms and conditions, please refer to the official Sealey website or contact Sealey customer support.









Figure 7: Sealey's 1 Year Guarantee emblem, indicating product assurance.

For technical assistance, spare parts, or warranty claims, please contact your authorized Sealey dealer or visit the official Sealey website for support information.

*Please note: "Terms and conditions apply" as indicated by the manufacturer.*



	<p><a href="#">Sealey IR55.V2 45.5kW Infrared Paraffin/Kerosene/Diesel Heater User Manual</a></p> <p>Comprehensive user manual for the Sealey IR55.V2 45.5kW infrared heater. Covers safety, specifications, operation, maintenance, and troubleshooting for paraffin, kerosene, and diesel fuels.</p>
	<p><a href="#">Sealey LP14 Infrared Gas Heater: User Manual and Safety Instructions</a></p> <p>Comprehensive user manual and safety instructions for the Sealey LP14 propane-fired infrared gas heater. Includes assembly, operation, safety warnings, and specifications for commercial applications.</p>
	<p><a href="#">Sealey IWMH2003 Infrared Quartz Heater - Installation and Operation Manual</a></p> <p>Comprehensive instructions for the Sealey IWMH2003 Infrared Quartz Heater, covering safety, mounting, operation, and specifications. Learn how to safely install and use your heater.</p>
	<p><a href="#">Sealey IR15 Infrared Halogen Heater User Manual and Safety Instructions</a></p> <p>Comprehensive guide to the Sealey IR15 Infrared Halogen Heater, covering safety, operation, specifications, assembly, and maintenance for optimal performance and safe use.</p>
	<p><a href="#">Sealey IR55 Infrared Paraffin/Kerosene/Diesel Heater 45.5kW 230V User Manual</a></p> <p>Comprehensive user manual for the Sealey IR55 45.5kW Infrared Heater. Includes safety instructions, specifications, operating procedures, maintenance, and troubleshooting for paraffin, kerosene, and diesel fuels.</p>
	<p><a href="#">Sealey IR55 Infrared Paraffin/Kerosene/Diesel Heater 45.5kW 230V User Manual &amp; Safety Instructions</a></p> <p>Comprehensive user manual and safety instructions for the Sealey IR55 Infrared Paraffin/Kerosene/Diesel Heater (45.5kW, 230V). Covers safety, operation, maintenance, troubleshooting, and specifications for professional use.</p>