

Coleman 2000020275

Coleman Pack-Away Deluxe Portable Kitchen

Model: 2000020275

INTRODUCTION

The Coleman Pack-Away Deluxe Portable Kitchen is designed to provide a convenient and functional cooking and food preparation area for outdoor activities. This portable unit features a spacious food prep surface, a removable sink, a side stand for stoves or coolers, and various storage options. Its foldable design allows for easy transport and compact storage.

SAFETY INFORMATION

- Always ensure the kitchen is stable on a flat, level surface before use to prevent tipping.
- Exercise caution to avoid pinch points when unfolding the frame and handling the removable sink.
- Do not exceed the maximum weight recommendation of 100 kilograms (220 lbs) for the entire unit.
- Keep heat sources, such as stoves, at a safe distance from flammable materials.
- Supervise children around the portable kitchen.

SETUP INSTRUCTIONS

Follow these steps to properly set up your Coleman Pack-Away Deluxe Portable Kitchen:

1. **Unfold the Frame:** Place the folded kitchen on a flat surface. Release the latches and carefully unfold the aluminum frame until it is fully extended and locked into place.
2. **Attach Main Surfaces:** Secure the main food prep surface onto the frame. Ensure all connection points are firmly engaged.
3. **Install Side Stand:** Attach the side stand to the main frame. This stand is designed to accommodate most Coleman stoves or coolers.
4. **Insert Removable Sink:** Place the removable sink basin into its designated slot on the food prep area.
5. **Assemble Shelves and Accessories:** Install the wire shelves, utensil hooks, and paper towel holder as desired. The lantern hook can be extended and secured for overhead lighting.



Image: The Coleman Pack-Away Deluxe Portable Kitchen fully assembled and in use at a campsite.

OPERATING INSTRUCTIONS

Utilize the various features of your portable kitchen for an efficient outdoor cooking experience:

- **Food Prep Area:** The 39.4 x 19.7-inch surface provides ample space for chopping, mixing, and other food preparation tasks.
- **Side Stand:** Position your Coleman stove or cooler on the 26.4 x 15-inch side table for easy access during cooking or meal service.
- **Removable Sink:** Use the integrated sink for washing dishes or hands. It can be easily removed for emptying and cleaning.



Image: The removable sink in use for washing dishes.

- **Storage:** Hang utensils on the provided hooks, place a paper towel roll on the holder, and store ingredients or small items on the wire shelves.
- **Lantern Hook:** Hang a lantern from the hook for illumination during evening cooking or meal times.

MAINTENANCE

Proper care will extend the life of your portable kitchen:

- **Cleaning:** After each use, wipe down all surfaces with a damp cloth and mild soap. The removable sink can be thoroughly washed and rinsed. Ensure all components are dry before folding for storage.
- **Storage:** Fold the kitchen into its compact case. Store in a dry place away from extreme temperatures.



Image: The portable kitchen folded into its compact, self-contained case.

TROUBLESHOOTING

- **Instability:** If the kitchen feels wobbly, ensure it is placed on a firm, level surface. Check that all frame components are fully extended and locked into their proper positions.
- **Difficulty Folding/Unfolding:** Ensure no components are obstructing the folding mechanism. Apply gentle, even pressure. Do not force parts.
- **Missing Components:** Verify all included components are present by checking the 'What's in the Box' section. Contact customer support if items are missing.

SPECIFICATIONS

Brand	Coleman
Model Name	2000020275
Product Dimensions (D x W x H)	7.48"D x 21.66"W x 40.95"H (folded)
Item Weight	14.3 Kilograms (31.5 lbs)
Maximum Weight Recommendation	100 Kilograms (220 lbs)
Frame Material	Metal (Aluminum)
Color	Aluminum
Is Foldable	Yes

Required Assembly	Yes
Included Components	Camp Kitchen with paper towel holder, condiment racks, removable sink basin, pantry shelf and laundry hook

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the manufacturer's official documentation or visit the Coleman website. Contact details for support are typically provided with your product packaging.