

WOLTU 9108

WOLTU Adjustable Swivel Bar Stools with Backrest and Footrest - Set of 2, White Faux Leather (Model 9108)

Instruction Manual

INTRODUCTION

Thank you for choosing the WOLTU Adjustable Swivel Bar Stools. This manual provides essential information for the safe assembly, operation, and maintenance of your new bar stools. Please read these instructions carefully before use and retain them for future reference.

SAFETY INSTRUCTIONS

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or faulty.
- Assemble the stools on a soft, clean surface to prevent scratches.
- Always remove the protective cap from the gas lift before assembly.
- Do not exceed the maximum load capacity of 120 kg (264 lbs).
- Keep children away from the assembly area. Small parts can be a choking hazard.
- Periodically check all screws and connections to ensure they remain tight.
- Avoid standing on the stool or using it as a ladder.
- Use the stool only on a flat, stable surface.

PACKAGE CONTENTS

Please verify that all components listed below are included in your package:

- 2 x Seat with backrest (White Faux Leather)
- 2 x Gas Lift Cylinder
- 2 x Base Plate (Chrome Metal)

- 2 x Footrest Ring (Chrome Metal)
- Mounting Hardware (screws, washers, Allen key)
- Instruction Manual



Image: Two WOLTU white faux leather bar stools, showcasing the complete product. These stools feature a comfortable seat, backrest, and a chrome-plated base with a footrest.

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your WOLTU bar stools. It is recommended to have two people for assembly.

1. **Prepare the Base:** Place the chrome base plate on a soft, flat surface. Insert the gas lift cylinder into the central hole of the base plate. Ensure the anti-slip rubber ring is securely attached to the bottom of the base.
2. **Attach the Footrest:** Slide the chrome footrest ring over the gas lift cylinder.
3. **Prepare the Seat:** Carefully place the seat upside down on a soft surface. Attach the mounting plate (usually pre-attached to the seat) to the top of the gas lift cylinder. Ensure the lever for height adjustment is facing the back of the seat.
4. **Secure the Seat:** Align the holes and use the provided screws and Allen key to firmly attach the seat to the gas lift cylinder. Do not overtighten.

5. **Final Check:** Once assembled, gently test the stability of the stool before full use. Ensure all connections are secure.



Practical foot rest



Maximum load capacity of 150kg



Anti-slip Rubber Ring

Image: Exploded view of the bar stool components, highlighting the practical footrest, the maximum load capacity (120 kg), and the anti-slip rubber ring on the base. This image aids in understanding the assembly process. Note: Some visual elements in the image may indicate 150kg, but the product specifications confirm 120kg.

Important Note: Before inserting the gas lift into the seat mechanism, ensure you remove the small black protective cap from the top of the gas lift cylinder. Failure to do so will prevent the height adjustment mechanism from functioning.

OPERATING INSTRUCTIONS

- **Height Adjustment:** To raise the seat, lift the lever while standing up. To lower the seat, lift the lever while seated. The seat height is adjustable between 62 cm and 84 cm.
- **Swivel Function:** The seat can rotate 360 degrees for ease of movement and access.
- **Footrest:** Utilize the integrated footrest for added comfort and support.

360° Swivel and Height Adjustable



Image: This diagram visually explains the 360-degree swivel capability and the height adjustment range of the stool. The seat height can be adjusted by 22 cm, from a minimum of 62 cm to a maximum of 84 cm.

MAINTENANCE

- **Cleaning:** Wipe the faux leather seat with a soft, damp cloth. For stubborn stains, use a mild soap solution and dry immediately. Avoid abrasive cleaners or harsh chemicals.
- **Metal Parts:** Clean chrome metal parts with a soft, dry cloth. Do not use abrasive materials that could scratch the finish.
- **Inspection:** Periodically check all screws and connections for tightness. Retighten if necessary to maintain stability and safety.
- **Floor Protection:** Ensure the anti-slip rubber ring on the base remains intact to protect your floor from scratches.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Stool does not adjust height.	Protective cap still on gas lift.	Disassemble the seat from the gas lift and remove the black protective cap from the top of the gas lift cylinder. Reassemble.
Stool is wobbly or unstable.	Loose screws or uneven surface.	Check and tighten all assembly screws. Ensure the stool is on a flat, level floor.
Scratching noise when moving.	Anti-slip ring damaged or missing.	Inspect the anti-slip rubber ring on the base. Replace if damaged. Ensure the floor is clean.

SPECIFICATIONS

- **Brand:** WOLTU
- **Model Number:** 9108
- **Color:** White
- **Material:** Faux Leather (seat), Chrome Metal (frame, base)
- **Product Dimensions (L x W x H):** 38 x 44 x 114 cm (approx. 15 x 17.3 x 44.9 inches)
- **Adjustable Seat Height:** 62 - 84 cm (approx. 24.4 - 33.1 inches)
- **Base Diameter:** 39 cm (approx. 15.4 inches)
- **Item Weight:** 15 kg (approx. 33 lbs) per stool
- **Maximum Load Capacity:** 120 kg (approx. 264 lbs)
- **Features:** 360° Swivel, Height Adjustable, Ergonomic Backrest, Footrest, Anti-slip Base



Image: A comprehensive diagram illustrating the key dimensions of the WOLTU bar stool, including overall height (93-114cm), adjustable seat height (62-84cm), seat width (44cm), seat depth (37cm), and backrest height (32cm). Note: Some visual elements in the image may indicate 150kg, but the product specifications confirm 120kg.

WARRANTY AND SUPPORT

WOLTU products are designed for quality and durability. For warranty information or customer support, please refer to the purchase documentation or contact your retailer. Keep your proof of purchase for any warranty claims. For further assistance, you may visit the official WOLTU brand store: [WOLTU Store](#)